### GRUNDIG SERVICE MANUAL



Btx \* 32700 #

Service Manual

LC 345 E

Sach-Nr./Part No 72010-513.10

Zusätzlich erforderliche Unterlagen für den Komplettservice:

Additionally required Service Manuals for the Complete Service:

#### Service Manual

LC 235 E

Sach-Nr./Part No. 72010-513.25

#### Service Manual

A-Mechanik

Sach-Nr./Part No. 72010-512.16

#### Service Manual

NA 8-3

Sach-Nr/Part No. 72010-512.65

**LC 345 E** 



LC 345 E

(75.8590-1000 / G.MD 7300)

Der Camcorder LC345E ist im Vergleich zur LC235E mit einem Farbsucher ausgestattet. Dieses Service Manual enthält Schaltpläne, Platinenabbildungen und Abgleichanweisungen, die sich gegenüber dem Service Manual LC 235 E (Sach-Nr. 72010-513.25) änderten. Die Bausteinbestückung und die Sach-Nummern der einzelnen Bausteine entnehmen Sie bitte der Ersatzteilliste.

Grundlage für den Service an dem Camcorder LC 345 E sind folgende Service Manuals:

- LC 235 E (Sach-Nr. 72010-513.25)
- A-Mechanik (Sach-Nr. 72010-512.16)
- Netzteil NA 8-3 (Sach-Nr. 72010-512.65)

Compared with the model version LC 235 E, this camcorder, LC 345 E, is provided with a colour view finder. This Service Manual contains only the circuit diagrams, circuit boards and adjustment procedures which differ from those illustrated in the Service Manual LC 235 E (Part No. 72010-513.25).

For the modules and the part numbers of the individual modules please refer to the spare parts list.

The following Service Manuals are to be used as a basis for servicing the LC 345 E camcorder:

- LC235 E (Part No. 72010-513.25)
- A-Mechanics (Part No. 72010-512.16)
- Power Supply NA 8-3 (Part No. 72010-512.65)



#### **Inhaltsverzeichnis**

	Seite
Allgemeiner Teil	0-20-4
Meßgeräte	0-2
Sicherheitsausgangsprüfung	0-2
Technische Daten	
Servicemittel	
Explosionszeichnungen und Ersatzteilliste	0-50-13
Linkes Gehäuseteil	
Rechtes Gehäuseteil	0-6 0-7
Service Manual CCD-TR333E (LC 3	

#### Allgemeiner Teil

#### Meßgeräte

Zweikanaloszilloskop Digitalmultimeter Tongenerator Frequenzzähler Vektorskop Regeltrenntrafo Millivoltmeter Stabilisiertes Netzgerät Farbgenerator

Beachten Sie bitte unser Meßtechnik-Programm, das Sie unter folgender Adresse erhalten:

Grundig AG Geschäftsbereich Industrieelektronik Würzburger Str.150 90766 Fürth/Bay. Tel. 0911/7330-0 Telefax 0911/7330-479

#### Sicherheitsausgangsprüfung

Nachdem Sie die Reparatur beendet haben, überprüfen Sie folgende Punkte, bevor Sie das Gerät an den Kunden zurückgeben:

- Überprüfen Sie den Bereich Ihrer Reparatur auf fehlende oder schlechte Lötstellen. Kontrollieren Sie die ganze Platinenoberfläche auf Zinnspritzer und Kurzschlüsse.
- Überprüfen Sie die Platinenverbindungen, und stellen Sie sicher, daß keine Leitungen eingequetscht werden oder Hochlast-Widerstände berühren.
- Achten Sie auf unerlaubte Ersatzteile, insbesondere Transistoren, die bei früheren Reparaturen eingebaut wurden. Weisen Sie den Kunden darauf hin und empfehlen Sie den Austausch.
- Achten Sie auf Teile, die zwar noch funktionieren, aber offensichtliche Abnutzungserscheinungen zeigen. Weisen Sie den Kunden darauf hin und empfehlen Sie den Austausch.

#### **Table of Contents**

	Page
General	0-20-4
Test Equipment	0-2
Technical Data	0-3
Safety Check-Out	0-3
Service Jigs and Tools	0-4
<b>Exploded Views</b>	
and List of Spare Parts	0-50-13
Cabinet (L) and F Panel Assemblies	
Cabinet (R) and EVF Assemblies	0-6
Main Board Assembly	0-7
List of Spare Parts	0-8
Service Manual CCD-TR333E (LC	345 F)

#### General

#### **Test Equipment**

Dual channel oscilloscope Digital multimeter AF generator Frequency counter Vectorscope Variable isolating transformer Millivoltmeter

Stabilized power supply Colour generator

Please note our Catalog "Test and Measuring Equipment" obtainable from:

Grundig AG Geschäftsbereich Industrieelektronik Würzburger Str.150 90766 Fürth/Bay. Tel. 0911/7330-0 Telefax 0911/7330-479

#### Safety Check-out

After correcting the original service problem, perform the following safety checks before releasing the set to the customer:

- Check the area of your repair for unsoldered or poorly-soldered connections. Check the entire board surface for solder splashes and bridges.
- Check the interboard wiring to ensure that no wires are "pinched" or contact high-wattage resistors.
- Look for unauthorized replacement parts, particulary transistors, that were installed during a previous repair. Point them out to the customer and recommend their replacement.
- Look for parts which, though functioning, show obvious signs of deterioration. Point them out to the customer and recommend their replacement.

0-3

#### **Technische Daten**

GRUNDIG Service-Technik

Camera  Aufnahmelement: "'/3" CCD Halbleiter-Chip  Auflösung: 320 000 Bildpunkte  Beleuchtungsbereich: 2 - 100 000 Lux  Mindestbeleuchtung: 2 Lux  Zoombereich: 10-fach Motor-Zoom 6,2 - 62 mm  Auto-Fokus-System: TTL Full Range Autofokus  Filtergewindedurchmesser: 37mm  Lichtstärke (Optik): 1 : 1,6 bis 1 : 2,9
Video
Aufnahmesystem:2 rotierende Köpfe,
Schrägspurverfahren, PAL
Bandformat:
Bandgeschwindigkeiten:Standard play (SP) 20,051 mm/s
Longplay (LP) 10,058 mm/s
Longplay (LP) 10,000 miles
Audio
Aufzeichnungsverfahren: Schrägspurverfahren FM
Mikrofon: Elektret-Kondensator-Mikrofon (Mono)
TAIRLOTOTI LIERUET-TOTACHSZIOT-TAIRLOTOTI (MOTIO)
Anschlußmöglichkeiten
Videoausgangsbuchse: Cinchbuchse, 1Vss, 75 $\Omega$ ,
unsymmetrisch, Video positiv
Audioausgangsbuchse: Cinchbuchse, -7,5dBm,
Impedanz < 2,2kΩ bei
einer Belastung von 47kΩ
RFU-DC-Spannungsausgangsbuchse: Spezial-Minibuchse 5V
Fernbedienbuchse: Stereoklinkenbuchse 2,5mm
Mikrofonbuchse: Monoklinkenbuchse 3,5mm,
-66dBm, niedrige Impedanz, mit
2,5 - 3V Gleichspannungsausgang, Impedanz 6,8k $\Omega$
Betriebsspannung
Akkubetrieb: 6.0V
Netzteilbetrieb: 7,5V
1,01
Leistungsaufnahme Aufnahmebetrieb (mit Monitor):
Administration (ITHE MOTHER)
Allgemeines
Gewicht: ca. 770g (ohne Akkusatz, Lithiumbatterie,
Schulterriemen und Cassette)
Sucher:
Arbeitstemperatur:

#### **Technical Data**

Camera Image device:
Video recording system:
Tape format: 8 mm Cassette tape Tape speed: Standard play (SP) 20.051 mm/s Longplay (LP) 10.058 mm/s
Audio Audio recording system: Helical scanning FM system Microphone: Electret condenser microphone (mono)
Connections  Video output socket:
Audio output socket:
RFU DC OUT:
Power requirements  Battery pack:
Power consumption Camera recording (with viewfinder): approx. 6.0W
General Weight:

Notizen /	Notizen / Notes							

#### LC 345 E Servicemittel / Service Jigs and Tools

Stück Piece	Bezeichnung Description	Sach-Nr. Part No.	Sony-Nr. Sony No.
1	Testband / Alignment Tape WR 5-1 C P	75987-561.62	8-967-995-07
1	Testband / Alignment Tape WR 5-6 C	75987-526.56	8-967-995-17
1	Testband / Alignment Tape WR 5-5 CSP	75987-526.57	8-967-995-47
1	Testband / Alignment Tape WR 5-4 CL	75987-526.58	8-967-995-56
1	Farbtestbild für Lichtbox / Colour Chart for Pattern Box	_	J-6020-250-A
1	Lichtbox / Pattern box PTB-500	_	J-6029-140-A
1	Filter / Filter for colour temperature correction (C14)	75987-536.43	J-6080-058-A
1	ND-Filter / ND Filter (0.4)	75987-532.02	J-6080-806-A
1	ND-Filter / ND Filter (0.1)	75987-532.03	J-6080-807-A
2	ND-Filter / ND Filter (1.0)	75987-532.04	J-6080-808-A
1	ND-Filter / ND Filter (0.3)	75987-536.44	J-6080-818-A
1	Bedieneinheit für Einstellarbeiten (RM 95B) / Adjustment Remote Contro	75987-561.68	J-6082-053-B
1	GRUNDIG-Testbildsatz / GRUNDIG-Set of Test Charts	75987-358.56	_
1	Schwarz-weiß Testbild / Black-white Test Pattern (1189mm x 841mm)	_	
1	Verlängerungskabel / Extension Cable (10P) 1,0mm	75987-536.51	J-6082-064-A
1 -	Verlängerungskabel / Extension Cable (16P) 0,8mm	75981-274.01	J-6082-136-A
1	Verlängerungskabel / Extension Cable (20P) 0,5mm	75981-274.03	J-6082-138-A
1	Messadapter für das Kamerateil / Measuring Pin for Camera Section	75981-274.06	J-6082-139-A
1	Verlängerungskabel / Extension Cable (10P) 0,8mm (neu! / new!)	75981-297.01	J-6082-150-A
1	Messadapter für den Monitor / Measuring Pin for Viewfinder Section (neu! / new!)	75981-297.02	J-6082-151-A
1	Verlängerungskabel / Extension Cable (6P) 1,5mm	75981-291.53	J-6082-152-A
1	Verlängerungskabel / Extension Cable (30P) 0,8mm	75981-282.01	J-6082-167-A
1	Verlängerungskabel / Extension Cable (21P) 0,5mm	75981-284.03	J-6082-176-A
1	Verlängerungskabel / Extension Cable (42P) 0,8mm	75981-290.06	J-6082-195-A
1	Verlängerungskabel / Extension Cable (20P) 0,8mm	75981-290.07	J-6082-196-A


Die Servicemittel für die Mechanik des Camcorders LC 345 E sind im Service Manual (Sach-Nr. 72010-512.16) A-Mechanik aufgelistet.

The Service Jigs and Tools for the mechanic of the camcorder LC 345 E are listed in the Service Manual (Part No. 72010-512.16) for the A-Mechanic.

#### **Explosionszeichnungen / Exploded Views**

Linkes Gehäuseteil / Cabinet (L) and F Panel Assemblies

1




#### Rechtes Gehäuseteil / Cabinet (R) and EVF Assemblies

. W991 W986 62. 57. not supplied W971 

#### Hauptplatinen / Main Board Assembly

3



### GRUNDIG

#### Ersatzteilliste List of spare parts



Btx \* 32700 #

4/93

**LC 345 E** 

SACH-NR. / PART NO.: 75.8590-1000 BESTELL-NR. / ORDER NO.: G.MD 7300

					BESTELL-NR. / ORDER NO.: G.MD /300
POS.	ABB	SACHNUMMER	ANZ.		
NR.	NR.		7 11 4422	BEZEICHNUNG D	DESCRIPTION
POS.		PART NUMBER	QUA.	BEZEIOTINONG B	DESCRIPTION
NO.	NO.				
			-		
0004 000					
0001.000	1 1	75981-290.05		GEHAEUSETEIL, LINKS	HOUSING PART, LEFT
0002.000	1	75987-535.08		HALTERIEMEN	HAND STRAP
0003.000	1	75987-535.22		DRUCKFEDER	PRESSURE SPRING
0004.000	1	75981-274.09		KNOPF, STAND-BY	KNOB, STAND-BY
0005.000	1	75987-535.25	1	FEDER	SPRING
0007.000	1	75981-274.10	1	HALTER	HOLDER
0008.000	1	75981-274.18	_	HALTER	HOLDER
0010.000	1	75987-560.60	7	SCHRAUBE M2	SCREW M2
0011.000	1	75981-297.07		CASSAETTENFACHDECKEL	LID CASSETTE
0013.000	1	75987-560.50	2	SCHRAUBE M2X6	SCREW M2X6
0014.000	1	75981-290.08		FLEXIBLE LEITUNG	FLEXIBLE CABLE
0015.000	1	75981-290.09		MIKROFONVERSTAERKER,MA149	P.C. BOARD ASSY
0018.000	1	75981-290.10	1 1	MIKROFON	MICROPHONE
0019.000	1	75981-290.03	1	GEHAEUSEVORDERTEIL	CABINET FRONT
0020.000	1	75981-290.11	1	SCHENKELFEDER	LEG SPRING
0021.000	1	75981-290.12		KNOPF	KNOB
0022.000	1	75981-273.01		FERNBEDIENUNG RC 8-4	REMOTE CONTROL
0023.000	1	75981-284.20		BATTERIEFACHDECKEL	BATTERY COMP. COVER
0051.000	2	75981-290.13		ADAPTERPLATTE, CN-65	BOARD LINK, CN-65
0052.000	2	75981-290.14	1 1	BEDIENPLATTE CAMERAPROGR.CF-32	
0053.000	2	75981-290.15	1 1	BEDIENPLATTE, REC. VK-27	VTR FUNCTION SWITCH, VK-27
0054.000	2	75981-290.16	1 . 1	BEDIENPL.CAMERA, ED-35	VTR FUNCTION CAMERA, ED-35
0055.000	2	75987-560.50	2	SCHRAUBE M2X6	SCREW M2X6
0057.000	2	75981-297.06		GEHAEUSETEIL RECHTS,	HOUSING PART, RIGHT
0058.000	2	75981-273.08		PLATTE (M.STATIVGEWINDE)	PLATE (W.TRIPOD THREAD)
0059.000	2	75981-290.17		VERRIEGELUNG	LOCKING
0060.000	2	75981-274.24		DRUCKFEDER	PRESSURE SPRING
0062.000	2	75987-560.17	1 1	DRUCKFEDER	PRESSURE SPRING
0063.000	2	75981-283.94		TASTE	KEY
0064.000	2	75981-290.18		ABDECKUNG	COVER
0065.000	2	75981-282.50	l I	TASTE	KEY
0071.000	2	75981-290.19	! I	DECKEL	LID
0076.000	2	75981-290.20	1 1	KNOPF, BATTERIE	KNOB, BATTERY
0077.000	2	75981-290.21	1 1	BATTERIEDECKEL, LITHIUM	BATTERY LID, LITHIUM
0078.000	2	75987-562.39	1 1	SCHRAUBE M2X3	SCREW M2X3
0079.000	2	75981-290.22		FOKUS-SCHALTERPL. MF-191	MANUAL FOCUS SWITCH MF-191
000.0800	2	75981-290.23		WIPPE	ROCKER
0001.000	2	75981-290.01	l í	ABDECKUNG	COVER
0082.000	2	75981-297.37		OKULAR	OCULAR
0083.000	2	75981-297.09		AUGENMUSCHEL	EYE CAP
0084.000	2	75981-297.04		SCHIEBER (OBEN), MONITOR	SLIDE UPPER
0085.000	2	75981-297.05		SCHIEBER (UNTEN), MONITOR	SLIDE LOWER
000.8800	2	75981-297.03		GEHAEUSETEIL (L), MONITOR	HOUSING PART (L) MONITOR
000.000	2	75981-297.08		GEHAEUSETEIL (R), MONITOR	HOUSING PART (R) MONITOR
0090.000	2	75981-297.10		DRUCKPLATTE, CL-29	P.C.BOARD ASSY, CL-29
0091.000	2	75981-297.11	,	ZWISCHENSTECKER	CONNECTOR BOARD TO BOARD
0092.000	2	75981-297.12	🛆	DRUCKPLATTE, IV-10	P.C.BOARD ASSY, IV-10
0093.000	2	75981-297.13		HALTER	HOLDER
0094.000	2	75981-297.14		FILTER (FOLIE)	FILTER
0095.000	2	75981-297.15		SCHEIBE	WASHER
0096.000	2	75981-297.16		DRUCKPLATTE, LB-33	P.C.BOARD ASSY, LB-33
0097.000	2	75981-297.17	,	HALTER	HOLDER
0099.000	2	75981-297.18	4	FLUORESCENT-ROEHRE BL 991	TUBE FLUORESCENT BL991
0100.000	2	75981-297.19	,	LC-DISPLAY LCD 901	LCD 901
0101.000	3	75981-290.28	Δ.	NETZTEILPLATTE, DD-48	POWER, DD-48
0102.000	3	75987-562.39	12	SCHRAUBE M2X3	SCREW M2X3
0104.000	3	75981-290.29		CCD-PLATTE, CD-92	CCD IMAGER, CD-92
			-		

		SACHNUMMER	ANZ.	BEZEIGUNUNG (F)	DESCRIPTION
	NR. FIG.	PART NUMBER	QUA.	BEZEICHNUNG D	DESCRIPTION
NO.	NO.				
0106.000	3	75981-282.71		IR-FILTER	IR-FILTER
0108.000 0110.000	3	75981-290.30 75987-560.50		OPTIK KPL. SCHRAUBE M2X6	OPTIC CPL. SCREW M2X6
0111.000	3	75981-290.31		STUETZBATTERIE-PL. LI-44	LITHIUM BATTERY HOLDER , LI-44
0112.000	3	75981-290.32		HALTER, LITHIUM	HOLDER, LITHIUM
0113.000	3	75981-290.33		CAMERAPLATTE, VC-122	CAMERA, LENS DRIVE, VC-122
0114.000	3	75987-562.42		SCHRAUBE B2X5	SCREW B2X5
0115.000	3	75981-297.20		DRUCKPLATTE, VS-95	P.C. BOARD ASSY, VS-95
0117.000	3	75981-290.35		BEDIENPLATTE, START/STOP SW-205	CAMERA FUNCTION SWITCH SW-205
0118.000	3	75981-290.36		KONTROLLPL.MECHANIK,SL-27	MECH CONTROL, SL-27
0119.000 0122.000	3	75981-290.37 75981-290.38		AV-BUCHSENPLATTE, JK-91 TONPLATTE, AU-138	VIDEO/AUDIO JACK, JK-91 AFM AUDIO, AU-138
0124.000	3	75987-526.75		HALTER-BATTERIE H 516	HOLDER BATTERY H 516
0125.000	3	75987-580.74	lli	ANSCHLUSSBUCHSE J 517	CONNECTING SOCKET J 517
0126.000	3	75981-288.34		CCD-EINHEIT IC 875	CCD - UNIT IC 875
0127.000	3	75987-525.61	Δ	SICHERUNG PRF1600 PS 901	FUSE PS 901
0128.000	3	75987-525.61	Δ	SICHERUNG PRF1600 PS 902	FUSE PS 902
0129.000	3	75981-290.40		FLEXIBLE LEITUNG, FP-588 W001	FLEXIBLE CABLE, FP-588 W001
0130.000	3	75981-290.41		FLEXIBLE LEITUNG, FP-572 W005 FLEXIBLE LEITUNG, FFC-85 W517	FLEXIBLE CABLE, FP-572 W005
0131.000 0132.000	3	75981-290.42 75981-290.43		FLEXIBLE LEITUNG, FFC-85 W517 FLEXIBLE LEITUNG, FCC-92 W519	FLEXIBLE CABLE, FCC-85 W517 FLEXIBLE CABLE, FCC-92 W519
0132.000	3	75981-282.75		FLEXIBLE PLATTE, FP-437 W521	FLEXIBLE CABLE, PCC-92 W319 FLEXIBLE PLATE, FP-437 W521
0134.000	3	75981-290.44		FLEXIBLE LEITUNG, FP-589 W522	FLEXIBLE CABLE, FP-589 W522
0135.000	3	75981-290.39		KONTAKTPLATTE J901	CONTACT PLATE J901
0151.000	4	75981-282.76		CASSETTENSCHACHT	CASSETTE COMPARTMENT
0153.000	4	75981-282.77	li	SCHENKELFEDER	LEG SPRING
0154.000	4	75981-282.78		DAEMPFUNG	DAMPING OR ATTENUATION
0155.000 0157.000	4	75987-527.43 75981-282.79	1 1	SCHEIBE KOPFREINIGER KPL.	WASHER HEAD CLEANER CPL.
0158.000	4	75981-282.81		ZUGFEDER	TENSION SPRING
0159.000	4	75987-527.48		SCHEIBE	WASHER
0160.000	4	75981-282.82		KOPFREINIGERBUERSTE	HEAD CLEANER BRUSH
0161.000	4	75981-282.83		PLATTE	PLATE
0201.000	5	75981-282.84		WICKELTELLER	SPOOL CARRIER
0203.000	5 5	75981-282.85	i I	ANDRUCKROLLE	PINCH ROLLER
0206.000 0209.000	5	75981-282.86 75981-282.87		UMLENKROLLE HEBEL	PIVOTING ROLLER LEVER
0210.000	5	75987-527.44	2	SCHEIBE	WASHER
0211.000	5	75981-282.88		ZAHNRAD	GEAR WHEEL
0212.000	5	75981-282.89		HEBEL	LEVER
0213.000	5	75987-552.84		SCHEIBE	WASHER
0214.000	5	75981-282.90		ZAHNRAD	GEAR WHEEL
0216.000 0217.000	5	75981-282.91		RIEGEL	LATCH,BOLT
0217.000	5	75981-282.92 75981-282.93		WICKELTELLER SCHNUR	SPOOL CARRIER CORD
0219.000	5	75981-282.94		BREMSHEBEL	BRAKE LEVER
0221.000	5	75981-282.95		ZUGFEDER	TENSION SPRING
0222.000	5	75981-282.96		UMLENKBOLZEN	THREADING BOLT ASSEMBLY
0223.000	5	75981-282.97		SCHENKELFEDER	LEG SPRING
0224.000	5	75981-282.98		BREMSHEBEL CHASSIS KRILLS	BRAKE LEVER
0226.000 0227.000	5 5	75981-282.99		CHASSIS KPL. LS FUEHRUNG	CHASSIS CPL. LS GUIDE
0228.000	5	75981-283.00 75981-283.01		UMLENKROLLE	PIVOTING ROLLER
0230.000	5	75981-283.02		HEBEL KPL.	LEVER
0231.000	5	75981-283.03		SCHIEBER	SLIDE
0233.000	5	75981-283.04		SCHALTER S002	SWITCH S002
0250.000 0251.000	6	75981-283.12 75981-283.05		BANDTROMMEL KPL. M901 KOPFRAD	TAPE DRUM CPL. M901 HEAD WHEEL
	~			· · · · · · · · · · · · · · · · · · ·	
0252.000	6	75981-283.06		BLATTFEDER	LEAF SPRING
0253.000	6	75981-283.07		UMLENKHEBEL, TG7	REVERSE LEVER
0256.000	6	75981-283.08		HEBEL	LEVER
0259.000   0261.000	6	75981-283.09		HEBEL BANDELIEHBLINGSBOLZEN	LEVER
0262.000	6	75981-283.10 75981-283.11		BANDFUEHRUNGSBOLZEN DRUCKFEDER	TAPE GUIDE PIN PRESSURE SPRING
0263.000	6	75987-561.01		SCHRAUBE	SCREW
0264.000	6	75981-283.13		CAPSTAN-MOTOR M902	CAPSTAN MOTOR M902
0265.000	6	75981-283.14		FAEDELMOTOR M903	LOADING MOTOR M903
			. 1		
0301.000	7	75981-283.15		HEBEL	LEVER

GRUNDIG Service-Technik

POS. NR.	ABB SACHNUMME NR.		BEZEICHNUNG <b>D</b>	DESCRIPTION	(GB)
POS. NO.	NO.	R QUA.			
POS.	FIG. PART NUMBE	8 6 6 4 7 7 8 9 0 1 2 7 0 5 5 6 7 8 9 0 1 2 7 0 5 6 7 0 1 2 7 0 5 6 6 7 0 1 2 7 0 5 6 6 7 0 1 2 7 0 5 6 6 7 0 1 2 7 0 5 6 6 7 0 1 2 7 0 5 6 7 0 1 2 7 0 5 6 7 0 1 2 7 0 5 6 7 0 1 2 7 0 1 2 7 0 5 6 7 0 1 2 7 0 5 6 7 0 1 2 7 0 5 6 7 0 1 2 7 0 5 6 7 0 1 2 7 0 1 2 7 0 5 6 7 0 1 2 7 0 5 6 7 0 1 2 7 0 5 6 7 0 1 2 7 0 5 6 7 0 1 2	SCHRAUBE HEBEL SCHEIBE HEBEL DRUCKFEDER ANTRIEBSRAD ANTRIEBSRIEMEN RIEMENSCHEIBE SCHIEBER KURVENRAD HEBEL GRUNDSCHASSIS HEBEL LEBEL ZAHNRAD ZAHNRAD ZAHNRAD FLEXIBLE PLATTE FP-444 SCHALTER S001 SCHALTER S005 FLEXIBLE LEITUNG, FP-442 OPTIK KPL. SCHIEBEREGLER FLEXIBLE LEITUNG OPTOKOPPLER BLENDENEINHEIT M904 MOTOR-FOCUS M905 MOTOR-ZOOM M906  ZUBEHOER NETZTEIL NA 8-3 ACCU BP 8-1 MODULATOR M 81 SCHULTERRIEMEN SH 8-1 FERNBEDIENUNG RC 8-4 HALTER FERNBEDIENUNG BEDIENUNGSANLEITUNG GB BEDIENUNGSANLEITUNG J/ NL / S SERVICE MANUAL	SCREW LEVER WASHER LEVER PRESSURE SPRING DRIVE WHEEL DRIVE BELT BELT PULLEY SLIDE CURVED WHEEL LEVER MAIN CHASSIS LEVER LEVER GEAR WHEEL GEAR WHEEL FLEXIBLE CABLE, FP-444 SWITCH S001 SWITCH S005 FLEXIBLE CABLE, FP-442 OPTIC CPL. SLIDING-CONTROL FLEXIBLE CABLE OPTOCOUPLER LENS UNIT M904 MOTOR-FOCUS M905 MOTOR-ZOOM M906  ACCESSORIES  POWER SUPPLY NA 8-3 ACCU BP 8-1 MODULATOR M 81 SHOULDER BELT SH 8-1 REMOTE CONTROL HOLDER INSTRUCTION MANUAL GB INSTRUCTION MANUAL I / F / E INSTRUCTION MANUAL I / NI / S SERVICE MANUAL	GB .

	I			1	
POS. NR.	SACHNUMMER	BEZEICHNUNG D	POS. NR.	SACHNUMMER	BEZEICHNUNG D
POS.	PART NUMBER	DESCRIPTION GB	POS.	PART NUMBER	DESCRIPTION (GB)
NO.			NO.	<del> </del>	
	75981-283.74	BUZZER, PIEZOELECTRIC SP991	IC 403	75981-290.68	IC UPD 75316 GF-318-3B9
	75987-581.31	BUCHSE J902	IC 404	75981-290.69	IC CXA 1481 AR
	75987-536.06	BUCHSE J551	IC 405	75981-290.70	IC BR 9011 BF-RE 2
			IC 406	75981-290.71	IC UPD 6456 GS 620
CT 801	75987-559.14	TRIMMER	IC 407 IC 408	75987-559.95 75981-272.11	IC UPD 7564 G 540 IC MCD 004 BM
			IC 409	75987-560.11	IC TL 1596 CDB
	75007 505 00	DIODE 4 00 000	IC 410	75981-290.72	IC MPC 1720 VM
D 001 D 101	75987-525.86 75987-559.68	DIODE 1 SS 226 DIODE FC 805	IC 521 IC 551	75981-283.82 75987-553.58	IC LB 8111 V IC LA 7293 M-TE-L
D 102	75987-521.15	DIODE IMN 10	IC 601	75987-581.40	IC CXA 1488 R
D 103	75987-458.80	DIODE 1 SS 250	IC 602	75981-283.71	IC RS 20 E-T
D 121 D 152	75981-286.52 75987-586.69	DIODE MA 142 WK DIODE MA 142 WA	IC 701 IC 702	75987-511.62 75981-284.69	IC TC 7 SU 04 FT 85 R IC MB 88346 BPFV
D 159	75981-286.52	DIODE MA 142 WK	IC 702	75987-528.70	IC NJM 2234 M
D 160	75981-286.52	DIODE MA 142 WK	IC 704	75981-273.78	IC CXD 2101 AR
D 161 D 162	75987-458.27 75981-286.52	DIODE MA 110 DIODE MA 142 WK	IC 705	75981-283.57	IC CXD 2103 AR-T 6
D 163	75981-286.52	DIODE MA 142 WK	IC 706	75981-290.57 75981-284.70	IC CXD 2104 BN IC CXD 2100 AQ
D 401	75987-458.42	DIODE MA 728	IC 709	75981-290.58	IC CXP 80624-434 R
D 402 D 403	75981-286.52	DIODE MA 142 WK DIODE MA 110	IC 712	75981-290.59	IC BR 9021 AF
D 552	75987-458.27 75987-458.27	DIODE MA 110	IC 801 IC 802	75981-283.59 75981-283.60	IC CXD 1257 AR-T 5 IC CXA 1507 BR
D 875	75987-534.09	DIODE 1 SS 123	IC 803	75981-273.71	IC CXA 1399Q
D 876	75987-458.27	DIODE MA 110	IC 804	75981-273.74	IC CXD 1250 N
D 877	75981-273.15 75987-458.27	DIODE 1 SS 181 DIODE MA 110	IC 805 IC 851	75981-273.73 75987-521.02	IC CXA 1390 AR IC NJM 3414 M
D 901	75981-297.21	DIODE GL 3 PR 43 BOARD CL-29	IC 852	75987-560.09	IC LM 324 D
D 901	75987-559.68	DIODE FC 805 BOARD DD-48	IC 853	75981-290.60	IC MPC 1724 VMEL
D 902 D 903	75987-525.90 75981-297.22	DIODE GL 1 HD 51 DIODE MA 8033 L	IC 854 IC 856	75981-273.96 75987-560.10	IC LB 1830 M IC LM 358 D
D 904	75981-273.15	DIODE 1 SS 181	IC 875	75981-288.34	CCD-EINHEIT
D 905	75981-297.23	DIODE 1 T 363 BOARD CL-29	IC 901	75981-297.24	IC IR 3 P 961 BOARD CL-29
D 905 D 906	75987-458.27 75987-458.27	DIODE MA 110 DIODE MA 110	IC 901	75981-283.76	IC MB 3785 APFV-G-BND-ER BOARD DD-48
D 907	75987-536.09	DIODE MA 8082 M	IC 902	75981-297.25	IC ETM 3011 FOA
D 908	75987-536.09	DIODE MA 8082 M	IC 903	75981-297.26	IC ETM 3021 FOA
D 971 D 976	75987-458.27 75987-458.27	DIODE MA 110 DIODE MA 110			
D 986	75987-458.27	DIODE MA 110	L 001	75987-525.32	SPULE 10UH
D 987	75987-459.16	DIODE MA 121	L 002	75981-273.39	CHIP-SPULE 220UH
D 992	75987-458.27	DIODE MA 110	L 003 L 005	75981-273.39 75981-290.73	CHIP-SPULE 220UH CHIP-SPULE 22UH
			L 005	75987-533.10	CHIP-SPULE 220H CHIP SPULE 10UH
CF 151	75981-273.51	FILTER	L 008	75987-521.31	CHIP SPULE 220UH
FL 121 FL 152	75987-525.13 75987-559.24	FILTER 4.43MHZ FILTER	L 009	75987-525.31	SPULE 8.2UH
FL 152	75987-539.24 75987-525.12	FILTER 4.43MHZ	L 010 L 011	75987-535.98 75987-581.41	CHIP SPULE 120 UH SPULE 330UH
FL 154	75987-581.36	FILTER	L 012	75987-525.37	SPULE 33UH
FL 155 FL 401	75987-559.23 75981-284.67	FILTER FILTER	L 013	75987-525.47	SPULE 180UH
FL 701	75987-581.48	FILTER, LOW PASS	L 015 L 101	75987-525.32 75987-525.51	SPULE 10UH SPULE 47UH
FL 702	75987-581.49	FILTER	L 102	75987-525.51	SPULE 47UH
			L 103	75987-525.50	SPULE 10UH
IC 001	75987-526.26	IC CXA 1202 R	L 104 L 121	75987-553.19 75987-525.32	CHIP SPULE 22 UH SPULE 10UH
IC 003	75981-273.70	IC CXA 1211 M	L 150	75987-525.35	SPULE 18UH
IC 101	75981-297.31	IC MB 3776 APNF-G-BND	L 152	75987-525.36	SPULE 22UH
IC 102 IC 103	75987-560.08 75987-560.10	IC LM 393 D IC LM 358 D	L 154 L 155	75987-525.40 75987-525.40	SPULE 56UH SPULE 56UH
IC 121	75987-526.45	IC CXA 1203 N	L 160	75987-533.10	CHIP SPULE 10UH
IC 151	75981-290.65	IC CXA 1207 AR	L 161	75987-525.36	SPULE 22UH
IC 152 IC 154	75987-559.82 75987-559.85	IC CXA 1208 R IC CXL 1506 M	L 162 L 163	75987-581.41 75987-525.25	SPULE 330UH SPULE 820UH
IC 155	75981-273.70	IC CXA 1211 M	L 163	75987-525.47	SPULE 8200H SPULE 180UH
IC 156	75981-288.40	IC M 62353 GP	L 169	75987-525.42	SPULE 82UH
IC 158 IC 159	75981-288.40 75981-273.93	IC M 62353 GP IC CXA 1452N	L 170	75987-525.32	SPULE 10UH
IC 401	75981-273.93 75981-290.66	IC CXA 1452N IC S 8420 AF	L 171 L 175	75987-525.35 75987-525.43	SPULE 18UH SPULE 100UH
IC 402	75981-290.67	IC CXP 80624-428 R	L 176	75987-525.46	SPULE 150UH
L	L				

GRUNDIG Service-Technik

POS.	SACHNUMMER	BEZEICHNUNG D	POS.	SACHNUMMER	BEZEICHNUNG	D
POS.	PART NUMBER	DESCRIPTION GB	POS.	PART NUMBER	DESCRIPTION	GB
NR. POS. NO.  L 177 L 178 L 179 L 180 L 181 L 182 L 185 L 401 L 402 L 403 L 404 L 405 L 406 L 407 L 571 L 701 L 703 L 704 L 705 L 706 L 708 L 710 L 711 L 712 L 714 L 715 L 717 L 720 L 801 L 701 L 801 L 802 L 803 L 804 L 805 L 803 L 804 L 851 L 805 L 901 L 902	75987-533.10 75987-559.36 75987-559.30 75987-559.30 75987-525.43 75987-525.43 75987-533.10 75987-533.10 75987-533.10 75987-533.10 75987-533.10 75987-533.10 75987-533.10 75987-559.35 75987-525.27 75987-525.27 75987-525.27 75987-525.35 75981-273.38 75987-533.10	CHIP SPULE 10UH CHIP SPULE 47 UH CHIP SPULE 6,8 UH SPULE 100UH SPULE 100UH SPULE 10UH CHIP SPULE 120 UH CHIP SPULE 10UH SPULE 1 UH CHIP SPULE 10UH SPULE 1 UH CHIP-SPULE 10UH CHIP-SPULE 4.7UH SPULE 2,2UH	NR. POS. NO.  Q 024 Q 025 Q 026 Q 101 Q 102 Q 103 Q 104 Q 105 Q 106 Q 107 Q 108 Q 121 Q 123 Q 124 Q 125 Q 126 Q 151 Q 152 Q 154 Q 158 Q 160 Q 161 Q 161 Q 162 Q 166 Q 161 Q 166 Q 167 Q 177 Q 178 Q 177 Q 177 Q 178 Q 178 Q 189 Q 189 Q 191 Q 192 Q 194	75987-525.94 75981-290.74 75981-290.74 75981-297.32 75987-536.23 75987-536.23 75987-536.22 75987-525.91 75987-434.50 75981-297.33 75987-459.49 75987-459.49 75981-279.92	TRANS.2 SC 2223 TRANS.RN 2302 TRANS.2 SD 1819 / TRANS.2 SD 1622 TRANS.XN 4113 TRANS.XN 4213 TRANS.2 SC 1623 TRANS.2 SC 1623 TRANS.2 SK 1299 TRANS.2 SK 1299 TRANS.2 SK 1299 TRANS.2 SK 1299 TRANS.2 SC 1623 TRANS.2 SK 1299 TRANS.2 SC 1623 TRANS.2 SD 1819 / TRANS.2 SC 4178 TRANS.2 SD 1819 / TRANS.2 SD 1819 / TRANS.2 SC 1819 / TRANS.2 SC 1819 / TRANS.2 SD 1819 / TRANS.2	GB F 13 A-R S CR S XN 4401 CR UN 5113 UN 5113 AR
L 903 L 903 L 904 L 904 L 905 L 905 L 906 L 909 L 910 L 911 L 912 L 913 L 914 L 915 L 916	75981-297.28 75981-273.22 75981-292.80 75981-273.22 75981-273.29 75981-273.23 75981-273.21 75981-273.21 75981-273.21 75981-273.21 75981-273.20 75981-283.78 75981-283.78 75981-273.21	SPULE 82UH BOARD CL-29 SPULE 10UH BOARD DD-48 SPULE 12UH BOARD DD-48 SPULE 10UH BOARD DD-48 SPULE 27UH BOARD CL-29 SPULE 10UH BOARD DD-48 SPULE 22UH CHIP-SPULE 4.7UH CHIP-SPULE 4.7UH SPULE 47UH SPULE 47UH SPULE 47UH CHIP-SPULE 330UH CHIP-SPULE 4.7UH SI-WIDERST.0,4A SICHERUNG	Q 195 Q 196 Q 199 Q 200 Q 203 Q 204 Q 205 Q 207 Q 208 Q 210 Q 212 Q 214 Q 219 Q 220 Q 221 Q 222 Q 223 Q 223 Q 230 Q 231 Q 231 Q 231 Q 232	75981-290.54 75987-459.49 75987-533.46 75981-290.62 75981-290.54 75981-279.92 75987-459.49 75981-290.54 75981-290.54 75987-536.22 75987-459.51 75987-536.22 75981-297.92 75981-290.54 75981-279.92 75981-290.54 75981-279.92 75981-279.92	TRANS.2 SA 1586 Y TRANSWIDERST.U TRANS.2 SB 1295 U TRANS.RN 1302 TRANS.2 SA 1586 Y TRANS.2 SD 1819 A TRANSWIDERST.U TRANSWIDERST.U TRANSWIDERST.U TRANSWIDERST.U TRANSWIDERST.U TRANSWIDERST.U TRANS.2 SA 1586 Y TRANSWIDERST.U TRAN	G JN 5113 JL 6 G R JN 5213 JN 5213 G JN 5212 JN 5212 JN 5212 JN 5213 G R JN 5213 G R
Q 001 A Q 003 Q 008 Q 010 Q 019 A Q 020 A Q 021 Q 022	75981-290.54 75981-279.92 75987-459.49 75987-553.45	TRANS.2 SA 1162 TRANS.2 SA 1586 YG TRANS.2 SD 1819 AR TRANSWIDERST.UN 5113 TRANS.2 SC 1623 TRANS.2 SC 1623 TRANS.2 SA 1576 QR TRANS.2 SA 1586 YG	Q 233 Q 234 Q 236 Q 237 Q 401 Q 403 Q 405 Q 409	75981-279.92 75981-290.54 75981-290.75 75981-290.61 75987-459.59 75987-459.49 75981-290.62 75981-290.76	TRANS.2 SD 1819 A TRANS.2 SA 1586 Y TRANS.UN 511 E TRANS.2 SB 1462 Q TRANSWIDERST.L TRANSWIDERST.L TRANS.RN 1302 TRANS.2 SB 1574	G JN 521 E

POS.	SACHNUMMER	BEZEICHNUNG D	Γ	POS.	SACHNUMMER	BEZEICHNUNG	<b>D</b>
NR.				NR.	PART NUMBER	DESCRIPTION	(GB)
POS. NO.	PART NUMBER	DESCRIPTION GB		POS. NO.	PARTNUMBER	DESCRIPTION	GB
			Ī				
Q 521	75987-480.69	TRANSWIDERST.XN 4501		S 991	75981-283.69	SCHALTER	
Q 551	75981-290.54	TRANS.2 SA 1586 YG		S 993 S 995	75981-283.69 75981-283.69	SCHALTER SCHALTER	
Q 701 Q 702	75981-273.68 75987-551.71	TRANS.DTC 124 EE TRANS.XP 4601		S 996	75981-283.69	SCHALTER	
Q 702	75987-551.71	TRANS.XP 4601		S 997	75981-290.51	SCHALTER	
Q 704	75981-290.61	TRANS.2 SB 1462 Q					
Q 706 Q 707	75981-290.50 75987-550.88	TRANS.2 SD 2216 Q TRANSWIDERST.UN 9111		T 101	75981-297.34	TRAFO	
Q 708	75981-290.50	TRANS.2 SD 2216 Q		T 102	75981-297.35	TRAFO	
Q 709	75987-551.70	TRANS.XP 4501		T 901	75981-283.80	TRANSFORMER	
Q 801 Q 802	75981-290.50 75987-551.69	TRANS.2 SD 2216 Q TRANS.XP 4401					
Q 851	75981-290.50	TRANS.2 SD 2216 Q		X 151	75981-273.48	QUARZ	
Q 852	75981-290.62	TRANS.RN 1302		X 401	75981-284.77	QUARZ 4,19 MHZ	
Q 853	75987-551.69	TRANS.XP 4401 TRANS.2 SD 2216 Q		X 402 X 403	75987-563.56 75981-273.49	QUARZ 32.768 KHZ QUARZ	
Q 875 Q 876	75981-290.50 75987-551.70	TRANS.XP 4501		X 404	75981-283.67	QUARZ 700 KHZ	
Q 877	75981-273.18	TRANS.2 SK 1875 BL/VTE 85		X 701	75981-283.68	QUARZ 10 MHZ	
Q 901	75987-480.69	TRANSWIDERST.XN 4501 CL-29		X 801	75981-290.78	QUARZ 28.375 MHZ	
Q 901 Q 902	75987-480.68 75987-459.47	TRANSWIDERST.XN 4401 DD-48 TRANSWIDERST.UN 5213		X 901	75981-297.30	QUARZ 4,43 MHZ	
Q 903	75981-273.27	TRANS.FP 102					
Q 904	75987-573.81	TRANS.2 SB 1122-S					
Q 905 Q 906	75981-273.24 75981-273.24	TRANS.FP 101 TRANS.FP 101					
Q 907	75987-480.69	TRANSWIDERST.XN 4501					
Q 908	75987-526.06	TRANS.2 SB 1121					
Q 909 Q 910	75987-526.06 75981-290.52	TRANS.2 SB 1121 TRANS.RN 2304					
Q 910	7 390 1-290.32	Thans.niv 2504					
		T.   T.					
R 073 R 113	75981-290.77 75981-290.77	THERMISTOR, NTC THERMISTOR, NTC					
R 151	75987-585.74	WIDERST.0 5% 1/8W					
R 243	75987-585.62	WIDERST.1000HM 5% 1/16W					
R 359 R 491	75987-585.74 75987-585.74	WIDERST.0 5% 1/8W WIDERST.0 5% 1/8W					
RV 101	75987-559.27	ESTR.2,2KOHM					
RV 102	75981-273.36	ESTR.10 KOHM					
RV 151 RV 901	75987-535.86 75981-297.29	ESTR.1 KOHM ESTR.22 KOHM					
RV 902	75987-536.41	ESTR.22 KOHM					
RV 903	75981-297.29	ESTR.22 KOHM					
RV 905 RV 906	75987-535.91 75987-536.41	ESTR.100 KOHM ESTR.22 KOHM	1 1				
RV 907	75987-536.41	ESTR.22 KOHM					
			J				
S 001	75981-283.31	SCHALTER					
S 002	75981-283.04	SCHALTER					
S 005 S 519	75981-283.32 75987-525.62	SCHALTER SCHALTER					
S 520	75987-525.62 75987-525.72	SCHALTER					
S 901	75981-290.53	SCHALTER			1		
S 971	75981-290.55 75981-290.56	SCHALTER SCHALTER					
S 972 S 973	75981-290.56	SCHALTER			1		
S 976	75981-283.93	SCHALTER					
S 977 S 978	75981-290.63	SCHALTER SCHALTER					
S 978 S 979	75981-290.64 75981-283.93	SCHALTER					
S 980	75981-283.93	SCHALTER					
S 981	75981-290.64	SCHALTER					
S 983 S 984	75981-283.93 75981-283.93	SCHALTER SCHALTER					
S 986	75987-581.18	SCHALTER					
S 987	75981-283.69	SCHALTER			1		
S 988 S 989	75987-581.18 75981-283.69	SCHALTER SCHALTER			}		
S 990	75987-283.69	SCHALTER					
	L		ן נ	L	L	l	

GRUNDIG Service-Technik 0 -



## CCD-TR333E **RMT-507**

**SERVICE MANUAL** 



AEP Model UK Model E Model

### Video8 Handycam

A MECHANISM

CCD-TR333E is based on model CCD-TR303E/TR303EP.

( Main differences)

is only avaiable.

· Color View Finder is carried.

For MECHANISM ADJUSTMENTS, refer to the "8 mm Video MECHANICAL ADJUSTMENT MANUAL IV " (9-973-199-11).

In this service manual, only the differences from CCD-TR303E/TR303EP are mentioned. When servicing, see the CCD-TR303E/TR303EP service manual(9-973-321-11) with this.

#### **SPECIFICATIONS**

#### Video Camera Recorder

#### System

Video recording system

Two rotary heads, Helical

scanning FM system

Audio recording system

Two rotary heads, Helical

scanning FM system PAL colour, CCIR standards

Video signal

Usable cassette 8 mm video format cassette

Tape speed

Playback time

SP mode: Approx. 20.051 mm

(13/16 inch)/s

LP mode: Approx. 10.058 mm (13/32 inch)/s

Recording time

SP mode: 1 h and 30 min (P5-90) LP mode: 3 h (P5-90)

SP mode: 1 h and 30 min (P5-90) LP mode: 3 h (P5-90)

Fast-forward/rewind time

Image device

Viewfinder Lens

Approx. 6.5 min (P5-90) CCD (Charge Coupled Device)

Electronic viewfinder (colour) Combined 10 x power zoom lens

f = 6.2 to 62 mm (1/4 to 2 1/2

inches)

F 1.6 to F 2.9

(45 to 450 mm (1 13/16 to 17 5/8

inches) when converted to a

35-mm still camera)

Filter diameter 37 mm (1 1/2

inches)

Autofocus sytem

TTL autofocus system inner focus wide macro system

Colour temperature

Automatic

Minimum illumination

2 lx (F 1.6)

Illumination range

2 lx to 100,000 ix

(0.2 to 9,290 footcandles)

Recommended illumination

More than 100 lx (9.3 footcandes)

#### **Output connector**

Video output

RFU DC OUT

MIC jack

Phono jack, 1 Vp-p, 75 Ω

unbalanced sync negative

Audio output

Phono jack

-7.5 dBs (at impedance 47 kΩ

impedance less than 2.2 kΩ

Special minijack, DC 5 V

♣ Remote jack Stereo mini-minijack (ø2.5 mm)

Minijack, -66 dBs, low impedance

with 2.5-3 V DC output,

impedance 6.8 kΩ

- Continued on neg t page -





#### General

Power requirements

On battery mounting surface 6.0 V (battery pack) 7.5 V (AC power adaptor)

9.0 V (alkaline batteries)

Average power consumption

6.0 W (camera recording) including the viewfinder Vertically, Horizontally

Installation Vertic

0 °C to 40 °C (32 °F to 104 °F)

Storage temperature

-20 °C to +60 °C (-4 °F to

+140 °F)

Dimensions Approx.  $109 \times 109 \times 197 \text{ mm (w/h/d)}$ 

(4 3/8 × 4 3/8 × 7 7/8 inches) Mass Approx. 770 g (1 lb 11 oz)

excluding the battery pack, lithium battery, cassette, and shoulder

strap

Approx. 1,000 g (2 lb 3 oz)

including the battery pack NP-55, lithium battery CR2025, cassette

P5-90, and shoulder strap

Microphone

Electret condenser microphone,

manaural type

#### AC power adaptor

Power requirements

110-240 V AC, 50/60 Hz

Power consumption

15 W

Output voltage DC OUT: 7.5 V, 1.2 A in operating

mode

Battery charge terminal: 10 V, 1.1

A in charge mode

Sony battery packs NP-55,

NP-55H, NP-66H, NP-77, NP-77H,

NP-77HD

Operating temperature

Application

Mass

0°C to 40°C (32°F to 104°F)

Storage temperature

-20°C to +60°C (-4°F to

+ 140°F)


Dimensions Approx.  $103 \times 49 \times 63$  mm (w/h/d)

(4 1/8×1 15/16×2 1/2 inches) including projecting parts and

controls

Approx. 290 g (10 oz)

#### Supplied accessories



- 1 Wireless Remote Commander (1) and Remote Commander holder (1)
- 2 Battery pack NP-55 (1)
- 3 AC power adaptor AC-V25 (1)
- 4 Lithium battery CR2025 (2) (for the camcorder/for the Remote Commander)
- 5 RFU adaptor
  RFU-80E (1) (AEP model)
  RFU-89EA with an aerial selector and
  a screw driver (1) (UK/E model)
- 6 Shoulder strap (1)

#### SAFETY CHECK-OUT

After correcting the original service problem, perform the following safety checks before releasing the set to the customer:

- Check the area of your repair for unsoldered or poorly-soldered connections. Check the entire board surface for solder splashes and bridges.
- Check the interboard wiring to ensure that no wires are "pinched" or contact high-wattage resistors.
- Look for unauthorized replacement parts, particularly transistors, that were installed during a previous repair. Point them out to the customer and recommend their replacement.
- Look for parts which, though functioning, show obvious signs of deterioration. Point them out to the customer and recommend their replacement.
- 5. Check the B+ voltage to see it is at the values specified.

#### SAFETY-RELATED COMPONENT WARNING!!

COMPONENTS IDENTIFIED BY MARK A OR DOTTED LINE WITH MARK ON THE SCHEMATIC DIAGRAMS AND IN THE PARTS LIST ARE CRITICAL TO SAFE OPERATION. REPLACE THESE COMPONENTS WITH SONY PARTS WHOSE PART NUMBERS APPEAR AS SHOWN IN THIS MANUAL OR IN SUPPLEMENTS PUBLISHED BY SONY.

#### **TABLE OF CONTENTS**

Section	<u>on</u>	<u>Title</u>	Page	Sect	<u>ion</u>	<u>Title</u>	<u>Page</u>
1.	GENERAL			5.	EXPLODED V	/IEWS	
Identif	ving the Parts ·····		4	5-1.	Cabinet (L) and	F Panel Assemblies ·······	57
Inserti	ng the Lithium Batteries ···		В	5-2.	Cabinet (R) and	EVF Assemblies ······	58
Conne	ecting the Power Sources.		7	5-3.	Main Boards As	sembly	59
Settin	the Date and Time ······		В				
Adius	ting the Viewfinder Lens		9	6.	ELECTRICAL	PARTS LIST	60
Check	ing the BEEP Switch		9				
Notes	and Precautions		9	7.	CAMERA SEC	CTION ADJUSTMENTS	;
Indica	tors inside the Viewfinder		10				
				7-1.	Preparations Be	efore Adjustment (Camera	Section) ····· 72
2.	DISASSEMBLY			7-1-		ce Tools······	
				7-1-		s ·····	
2-13.	Removal of EVF Assemble	ly (CL-29 Board)·····	11	7-3.		finder System Adjustment-	
				1.		sumption Adjustment (IV-1	
3.	DIAGRAMS			2.		Supply Adjustment (IV-10 I	•
				3.		ly Voltage Check (CL-29 E	•
3-1.	Circuit Boards Location ···		12	4.		Itage Check (CL-29 Board	
3-2.	Overall Block Diagram ···	************************	13	5.		ment (CL-29 Board) ······	
3-6.	Video (1) Block Diagram		17	6.		eset Adjustment (CL-29 Bo	
3-14.	EVF Block Diagram ·······		21	7.		Adjustment (CL-29 Board	
3-15.	Power Block Diagram ····	*************************	25	8.		R Adjustment (CL-29 Boar	
				9.		B Adjustment (CL-29 Boar	
4.	PRINTED WIRING BO	ARDS AND		10.		ice Adjustment (CL-29 Boa	
	SCHEMATIC DIAGRA	MS		11.		ustment (CL-29 Board) ····	
				12.		ing Adjustment (CL-29 Boa	
4-1.		m ·····		7-4.	Arrangement D	iagram for Adjustment Par	ts 80
4-2.		d Schematic Diagrams · · · · ·	32				
	<ul> <li>VS-95 Board (REC/PE</li> </ul>						
	Servo/System Control	)	33				
	<ul> <li>VS-95 Board (REC/PE</li> </ul>	3 Head Amp) ······	37				
	<ul> <li>VS-95 Board (Video) ·</li> </ul>		···· 41				
	<ul> <li>VS-95 Board (Servo/S</li> </ul>	system Control) · · · · · · · · · · · · · · · · · · ·	45				
	<ul> <li>MA-149 Board ········</li> </ul>	,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,	49				
	<ul> <li>CL-29, IV-10, LB-33 B</li> </ul>	oards ·····	51				
4-3.	Semiconductors ······	,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,	··· 56				

#### **SERVICE NOTE**

### [SEMICONDUCTOR FOR CORRECTION LIST DISPLAY]

Part code and part name of the semiconductor for correction of the print board is discribed in the space of each print figure. Use this list when ordering parts.


#### [SEMICONDUCTOR LOCATION]

In this service manual, the mounted locations of the semiconductors (IC, transistor, diodes) are indicated in red as shown below. This enables to find the location on the board easily when servicing.

### [PARTS LOCATION DIAGRAM RELATED TO POWER SUPPLY]

The parts location diagram for the power supply which are often checked and replaced when repairing the fuse and IC link and so on. (See pages 34 and 47.)

This diagram is useful for repair.



# SECTION 1

# GENERAL

For details on the use of each part, refer to the pages indicated in the parentheses.

(B-2)

(8-1)

1 EDITSEARCH button (26)

REWG - PLAY - GBFF PAUSE

[2]

2 Tape transport buttons (37), (38)

☐ STOP (stop)

← REW (rewind)

▷ PLAY (playback)

►► FF (fast forward)

II PAUSE (pause)

3 Built-in microphone (monaural)

5 Camera recording/battery lamp (24) 4 Remote sensor (7)

6 LENS COVER switch (23)

阜

8 FOCUS button (27) 7 Focus dial (27)

9 Power zoom button (25), (27)

10 POWER switch

11 Viewfinder (22)
You can monitor the colour picture being recorded or played back.

它

13 Lithium battery compartment (9)

[2]

(E)

This section is extracted from instruction manual.

# Identifying the Parts

(B-2)

14] REC MODE (recording mode)/EDIT switch (23), (39)

Mode	Recording	Playback	Editing
Setting	SP LP REC MODE	EDIT	EDIT
Function	Recording mode switch	EDIT switch	5

15 REMOTE COMMANDER IS ON/OFF switch (7)

16 BEEP switch (22)

17 TIME (NEXT) button (19), (24), (31) 18 DATE(+) button (19), (24), (31)

19 PROGRAM AE dial (28) 20 FADER button (30)

[21] BATT (battery eject) knob (12)


22 COUNTER RESET button (23)

23 Viewfinder lens control (22)

24 SUMMERTIME button (19), (31)

26 Battery mounting surface (12) 25 AREA button (31)

27 Hooks for shoulder strap



# dentifying the Parts

(B-3)



(B-5)

28 EJECT knob (21)

32

29 C\* remote control Jack (stereo mini-minijack)

30 START/STOP button (23)

31 STANDBY switch (19), (23)

(8)

8

32 Cassette compartment (21)

8

[33] MIC (microphone) jack (PLUG IN POWER) (monaural minijack) Connect an external microphone (not

34 Jack cover

supplied).

35 Video/Audio output Jack (phono jacks) (36), (39) 36 RFU DC OUT (DC output) Jack (34), (35)

(%)

37 Grip strap

38 Tripod receptacle

(%)

\* About (CANC)

But System. The de (LANC) connector is used for controlling the tape transport of video equipment and the petipherals connected to it.

This connector has the same function as the connectors indicated as CONTROL L or REMOTE. C (LANC) stands for Local Application Control

37


阛

(8)


6



(<u>8</u>4)



(B-6)



# Identifying the Parts

# Wireless Remote Commander

The buttons on the Remote Commander with the You can remotely record or play back a tape. same name or same mark as those on the camcorder have the same function.

4

When you use the Remote Commander
Be sure to insert the supplied lithium battery
into it (page 10) and to set REMOTE
COMMANDER IS ON/OFF on the camcorder to "NO

(B-5)

1 Transmitter

2 Power zoom button (25), (27)

3 Tape transport buttons (37), (38) 4 START/STOP button

(v)

(e)

5 HOLD switch\*
Slide in the direction of the arrow to prevent the buttons from being accidentally

6 DATA SCREEN button\* (38) Press to erase or display the on-screen

Note

The \* indicates the function which is operable only with the Remote Commander. Remotely controllable area (B-6)
Point the Remote Commander towards the

remote sensor [a].

 Keep the remote sensor away from strong light sources such as direct sunlight or illumination.
 Otherwise the remote control may not be Notes on the Remote Commander

we recommend you change the commander mode or cover the remote sensor of the VTR with black paper. commander mode "VTR 2". A commander mode is used to distinguish this camoorder from other Sony VTR to avoid misoperation. If you use another Sony VTR at commander mode "VTR 2", Be sure that there is no obstacle between the remote sensor and the Remote Commander. This camcorder works through the signals of

# dentifying the Parts


# Using the Remote Commander holder

(B-7)

You can clip the Remote Commander holder on your coat pocket or belt, or also slide it onto the shoulder belt before attaching the Remote Commander to it. (8-7)



other is for the Remote Commander. Note that the lithium battery has a positive (+) side and a negative (-, no mark) side as illustrated. Be sure to install the lithium battery with the correct polarity. (C-1) Your camcorder is supplied with two lithium batteries. One is for the camcorder, and the



# Inserting the Lithium Battery the Camcorder


### (C-2)

This camoorder uses a lithium battery to activate the clock. At first install the supplied lithium battery.

- 1 Detach the lid of the lithium battery compartment at the bottom.
- 2 Install the supplied CR2025 lithium battery with the positive (+) side facing out.

## 3 Replace the lid.

To change the lithium battery
Detach the lid of the lithium battery
compartment, and replace the lithium battery
with a new one.
When replacing the lithium battery, keep the
battery pack or other power source attached.
Otherwise, resetting of the date and time will be



(C-2)


[b] When detaching the Remote Commander from the Remote Commander holder

(B-8)

<u>a</u> (B-8)

0

2



necessary.

3

 $\infty$ 

<u>s</u>

# nserting the Lithium Batteries

Power

Connecting

Sources

First, Choose the Power Source.

Accessory to be used

Power Battery

Place

## nserting the Lithium Battery into the Remote Commander

(C-3)

- Commander.
  - (+) side facing upward.



(supplied), NP-55H, NP-66H, NP-77, NP-77H, NP-77HD

pack

Outdoors

Battery pack NP-55

For details, see the operation manual of the accessory you want to use.

battery cord DCC-16AE and

the car battery charger

car

DC-S10

# Using the Battery Pack

Step 1 Charge the battery pack. (D-1)

Connect the power cord to wall. The POWER lamp (green) will light up.

2 Align the right side of the battery pack with the white line on the AC power adaptor.

3 Slide the battery pack in the direction of the Set the selector to CHARGE.
When the charging is completed, the CHARGE lamp goes out. Set the VTR (DC OUT)/CHARGE selector to STANDBY. аггом.

NP-55	70	20
NP-77 NP-66H NP-55H NP-55	80	09
NP-66H	120	100
NP-77	140	105
NP-77H/ 77HD	160	135
	Required charging time *	Battery life * *

- Approximate minutes using AC-V25
   \*\* Approximate minutes using fully charged battery pack, continuous recording indoors

Slide the battery pack in the direction opposite to the arrow. To remove the battery pack

### Notes

The POWER lamp will remain lit for a while even if the battery pack is removed and the power cord is unplugged after charging the battery pack. This is normal.

if the POWER tamp does not light, set the selector to STANDBY and disconnect the power cord. After about one minute, reconnect the power cord and set the selector to CHARGE again.


(0-3)

Pull out the lithium battery holder from the

2 Install the lithium battery with the positive

Put the lithium battery holder back into the Commander. ന





## (0-1)

# Lithium battery life (under normal operation)

The battery for the camcorder lasts for

about 5 seconds (when the POWER switch is set approximately 1 year. When the battery becomes weak, the ⇔ indicator will flash inside the viewfinder for to CAMERA).

瀨

The battery for the Remote Commander lasts for approximately 6 months. When the battery becomes weak or dead, the Commander does In either case, replace the battery with a Sony not work.

### CAUTIONS

CR2025 battery. Use of any other type of battery may present the risk of fire or explosion.

Should the battery be swallowed, immediately Keep the lithium battery out of the reach of children.

Do not hold the battery with the metallic

tweezers, otherwise a short-circuit may occur. The battery may explode if mistreated. Do not recharge, disassemble, or dispose of in fire.

(C-4-4)

## the Date and Setting

**E** 

Œ

Make sure that a power source and lithium battery are installed. While pressing the green button, set the POWER switch to CAMERA, and turn STANDBY up.

simultaneously for more than 2 seconds until "1 LONDON" flashes inside the viewfinder. DATE (+) now functions as + (to advance numbers) and TIME (NEXT) functions as NEXT (to execute). N

If you leave the camcorder in the standby mode for 5 minutes or more, the camcorder will go off automatically. Turn STANDBY down once and

slide it up again.

the date and time

SUMMERTIME

DATE(+) TIME(NEXT)

Countries	Area name	Area number
The United Kingdom and Portugal (GMT)	TONDON	-
Other European countries (CET)	PARIS	2
Finland, Greece, etc.	CAIRO	m

ተ

ተ

E8827

4

Choose one of the following options to set the clock:

(a) To set to summer time, press SUMMERTIME. Then press TIME (NEXT). The ★ indicator appears inside the viewfinder.

[b] To set to standard time, press TIME (NEXT).

First adjust the flashing digits with DATE (+) 5 Set the year\*, month, day, hour and minute, in this order.

Meinex Meinex

1

# 2 \*, PARIS 7 \$993

OATE(+)

S S

<u>@</u>

\* To set the year to 1993, no need to press DATE (+) in step 5 - . and then press TIME (NEXT).

1

BOATE(+)

Press TIME (NEXT).

The clock starts operating.

ተ

THE STATE OF

ተ

17,3000

9

Press TIME (NEXT) repeatedly until the digits of minute stop flashing. Then repeat step 2 to 6. To correct the date and time setting

press the same button again, the indicator goes

To check the preset date and time Press DATE (+) or TIME (NEXT). When you

To advance the digits faster Keep DATE (+) pressed.

Setting the Date and Time

To reset to standard time Press SUMMERTIME. The ★ Indicator goes off. If the camcorder goes off abruptly while setting

Press DATE (+) and TIME (NEXT)

3 Press DATE (+) until your area name and number appear and then press TIME (NEXT).

# djusting the Viewfinder

The position of the viewfinder lens for optimum vision varies depending on the person. Adjust it when you use the camcorder for the first time, or when you use it after someone else did. £


 $\widehat{\Xi}$ 

While pressing the green button, set the POWER switch to CAMERA.

1 Make sure that the power source is connected and that the cassette is inserted.

3 Turn STANDBY up.

Slide the viewfinder lens control so that "STBY" displayed in the viewfinder screen comes into sharp focus.



(S-2)



## Checking the BEEP Switch

No #P BEEP

If you do not want to hear the beep sound, set Several beeps also sound as a warning of any unusual condition of the camcorder. Note that A beep sounds when you start recording and the beep sound is not recorded on the tape. two beeps sound when you stop recording, confirming the operation.

the BEEP switch to OFF.

O

1

## (S-1)

Notes and Precautions

Notes on Moisture Condensation

inside the camcorder, on the surface of the tape, stick to the head drum and be damaged or the camcorder may not operate correctly. To prevent possible damage under these circumstances, the If the camcorder is brought directly from a cold place to a warm place, moisture may condense camcorder is furnished with a moisture sensor. or on the lens. In this condition, the tape may

If moisture condenses inside the camcorder

However, take the following precautions:

viewfinder flash, moisture condenses inside the camcorder. In this case, no function except for When the 🗗 and 📤 indicators inside the cassette ejection will work. (S:1)

Eject the tape, turn off the camcorder, and leave it with the cassette holder open for about one

The camcorder can be used again if \_ indicator does not appear when the power is turned on If moisture condenses on the surface of the tape

button ([>, ▶▶, etc.) is pressed, the ▲ indicator In this case, no function except for tape ejection If moisture is present on the surface of the tape when the tape is inserted and a tape transport flashes inside the viewfinder. (S-2)

Eject the tape and let it sit for about one hour. The tape can be used again if the ≜ indicator does not appear when the tape is inserted and a tape transport button is pressed. will work.

No indicator will appear, but the picture if moisture condenses on the lens

Turn off the power and leave the camcorder unused for about one hour. becomes dim.

to a warm place, put the camcorder in a plastic When bringing the camcorder from a cold place bag and allow it to adapt to room conditions How to prevent moisture condensation over a period of time.

1 Be sure to tightly seaf the plastic bag

2 Remove the bag when the air temperature inside it has reached the temperature surrounding it (after about one hour). containing the camcorder.

3

1

€

# Notes and Precautions

idicators inside the

# Notes on Video Head Cleaning

ε

## (8-3)

<u>e</u>

(8-3)

To ensure clear picture, clean the video heads periodically.

When playback pictures are noisy or hardly visible, the video heads may be dirty.

[a] Slight contamination [b] Critical contamination In such cases,

V8-25CLH cleaning cassette (not supplied), 1 Clean the video heads with the Sony referring to its instructions.

2 After cleaning, check if the picture is clear by recording or playing back with an ordinary

3 If the picture is still noisy, repeat cleaning. (Do not repeat cleaning more than 5 times.)

9

(8-4)

Do not use a commercially availabale wet-type cleaning cassette, it may damage the video heads.

If the V8-25CLH cleaning cassette is not available in your area, consult your Sony service facility. Note

2

# Removing Dust from inside the Viewfinder

[o] "Clean video heads ( )" or "trouble has

occurred ( ♣ )".

[p] World clock indicator [q] Auto date indicator

[n] Remaining battery indicator

[m] The lens cover is closed.

<u>.</u> Ė

[s] Lights up during recording.When flashing: "Replace battery."

[r] Date or time

"Exchange tape or no cassette inside."

[k] Remaining tape length indicator

[j] Tape counter

٥

<u>s</u> 호

1 While pressing down the hook (III), slide the viewfinder barrel in the direction of the arrow (III) and remove it from the viewfinder.

2 Remove dust using the blower. (a) Blower brush

# Adjustment of Picture Quality

(8.5)

viewfinder screen in everyday operation.

If you want to change it, turn the screws on the viewfinder slowly using the philips screwdriver (not supplied). brightness of the picture displayed on the You do not need to adjust the colour and


	Turn clockwise	Turn counterclockwise
COLOUR	More colour intensity	Less colour intensity
BRT (brightness)	More brightness	More brightness Less brightness


[b] Setting of PROGRAM AE mode


[a] Manual focusing

E

ė Ē










[d] Power zoom indicator

[e] "Replace battery."

[c] FADER is pressed.







FADER Ė

0.00.25

Ę

AUTO DATE 12:00:00 哥 Ė Ė ġ


(i) Tape transport and camera recording mode

[h] Recording/Playback mode (LP/SP)

[f] "Moisture has condensed." [g] "Replace lithium battery."

COLOUR BRT


(8-5)



42


### SECTION 2 DISASSEMBLY

#### 2-13. REMOVAL OF EVF ASSEMBLY (CL-29 BOARD)




### SECTION 3 DIAGRAMS


#### 3-1. CIRCUIT BOARDS LOCATION





#### 3-6. VIDEO (1) BLOCK DIAGRAM


< >: The pages above correspond to CCD-TR303E/TR303EP SERVICE MANUAL, ( ): Pages of CCD-TR333E.






















**SECTION 4** PRINTED WIRING BOARDS AND SCHEMATIC DIAGRAMS 4 6 7 8 9 4-1. FRAME SCHEMATIC DIAGRAM A W986 13P W986 13P K OUT II 1 K DUT 0 CN993 8P K OUT 1 K OUT 1 W987 13P K OUT 0 K DUT 4 K IN 4 K OUT 4 K OUT 5 5 K IN 0 6 K IN 1 K OUT 1 K DUT 5 K IN O K 1N 5 CAM PWR SW COM K OUT O CAM PWR SW COM CF-32 K IN 6 ĐSV FOCUS 1 95V FOCU 7 K IN 2 8 K IN 3 9 K IN 4 10 K IN 5 11 K IN 6 K DUT D K IN 2 **BOARD** В K IN 3 K IN 4 K IN 4 K IN 4 K IN 3 FOCUS 2 N.C K IN 5 CAM PWR SW COM CAM PWR SW COM 0 K IN 1 1 K IN 2 2 K OUT 2 K IN 1 CHASSIS GN K 1N 2 | K 0U1 0 | K 0U1 1 | K 0U1 2 | K 0U1 2 | K 0U1 2 | K 0U1 3 | K 0U1 4 | K 0U1 5 | K 0U1 5 | K 0U1 5 | K 0U1 6 | K 0U CHASSIS GND C VK-27 BOARD ED-35 BOARD VIEW FINDER CHECK PIN CAM PWR PCO 1 BRIGHT 9 B 0UT -3V -3V -8V 9V 9V G 0UT C 0MD LC COM D CN903 20P CN-65 **BOARD** LC COM VIO-B VIÐ-R EVF UNREG EVF UNREG GNO VÐÐX EVF 5V EVF GND COLOR CL-29 Ε CLX4 CLX4 EVF OUT LCD **BOARD** | K OUT 0 | C OUT 0 | C OUT 0 | C OUT 1 | C OU CLX1 CLX1 CN102 6P EVF UNREG EVF UNREG GND
EVF 5V
EVF GND F CN991 12P CN102 12P EVF UNREG GND
H SYNC
EVF GND
EVF GND
EVF SV
EVF SV N.C 1 N.C V HIGH 2 V HIGH BOARD CN101 G N.C 7 N.C N.C 8 N.C .B-33 N.C 10 N.C GND 11 GND V RETURN 12 V RETURN IV-10 BOARD Н **В** міс 31M W N -INT MJC N.C MIC A G ZOOM SWITCH ı UNIT MA-149 BOARD (LITHIUM BATTERY) L1-44 FFC~90 BOARD J 200M W 200M FW 200M T 200M FT SS GND K AU-138 PB RF 20 20 PB RF REC AFM 1.5 IR AUÐIO FAÐER REC AFM **BOARD** 1.5 IR AUÐID FAÐER 1.5 ĐEV AUĐIO GNĐ 1.5 ĐEV AUĐIO GNĐ R/P AMP AUDIO GNB AUĐIO GNĐ SHIELD CASE AU010 5V PG (+)
PG/FG CDM 2
CDM 4
V 5 VA PB MODE L VA PB MOĐE AUÐIÐ SV RF SWP SP/LP RF SWP AUDIO MUTE AUÐIO MUTE AUÐIO L OUT W001 13P 1CH A (G) 1CH A (X) 1CH A (Y) AUBIO GNB SS GNB SIRCS SIG AUÐ10 GNÐ SS GNÐ HEAĐ 1CH A (Y) 2CH A (9) 2CH A (9) 2CH A (X) 2CH A (X) 1CH (G) 1CH (X) SIRCS SIG 2CH A (G) 2CH A (Y) SS 5V ZODM SW M FP-588 2CH A (X)
\*CH (G)
\*CH (X) I DE  $\mathcal{P}$ \*CH (Y) FE (G) FE (Y) FE (G) FE (Y) FE (X) M901 BRUM MOTOR FE (X) VIĐEO GUT **Q** VIĐEO GNE VIĐEO DUT JK-91 N DC OUT RF ĐC ĐƯT **BOARD** TUD DIGUA AUDIO GNE AUĐIO L OUT A-MECHA **FRAME FRAME** 0 **— 29** — -30



18 19 20



### 4-2. PRINTED WIRING BOARDS AND SCHEMATIC DIAGRAMS

## THIS NOTE IS COMMON FOR PRINTED WIRING BOARDS AND SCHEMATIC DIAGRAMS. (In addition to this, the necessary note is printed in each block.)

- For printed wiring boards.
- $\bullet \quad \bigcirc \quad :$  indicated a lead wire mounted on the component side.
- \_\_\_\_ : indicated a lead wire mounted on the conductor side.
- Parts mounted on the conductor side.
- Pattern from the side
- which enables seeing.

(The other layers'patterns are not indicated.)

- Circled numbers refer to waveforms.
- (B) or (F), etc. of capacitors indicate the temperature characteristics.
- • : Through hole.

### Caution:

Pattern face side: (Conductor Side) Parts on the pattern face side seen from the pattern face are indicated.

Parts face side: (Component side) Parts on the parts face side seen from the parts face are indicated.

- · For schematic diagrams.
- Caution when replacing chip parts.

New parts must be attached after removal of chip.

Be careful not to heat the minuts side of tantalum capacitor,

because it is damaged by the heat.

• All resistors are in ohms, 1/4W unless otherwise noted. Chip resistor are 1/10W unless otherwise noted.  $k\Omega$ :  $1000\Omega$ ,  $M\Omega$ :  $1000k\Omega$ .

- All capacitors are in μF unless otherwise noted. pF: μμF.
   50V or less are not indicated except for electrolytics and tantalums.
- All variable and adjustable resistors have characteristic curve B, unless otherwise noted.
- : nonflammable resistor.
- fusible resistor.
- \_\_\_\_: panel designation.
- : internal component.
   : adjustment for repeair.\*
- --- : B+ Line.\*
- ---: B-- Line.\*
- IN/OUT direction of (+, ) B LINE.\*
- Circled numbers refer to waveforms.\*
- \*: indicated by the color red.


### Note:

The components identified by mark  $\triangle$  or dotted line with mark  $\triangle$  are critical for safty.

Replace only with part number specified.

When indicating parts by reference number, ilease include the board name.

- Measuring conditions voltage value and waveform. (CAMERA, DIGITAL TITLE block)
- The object is color bar chart of pattern box.
- Voltages are dc between ground and measurement points. Readings are taken with a digital multimeter (DC 10M $\Omega$ ).\*
- Voltage variations may be noted due to normal production tolerances.\*
- 1. Connection



2. Adjust the distance so that the output waveform of Fig. a and the Fig. b can be obtain.




Fig. a (Video output terminal output waveform)




Fig. b (Picture on monitor TV)

## (VIDEO, SERVO/SYSTEM CONTROL, LCD CONTROL, VIEW FINDER block)

- Voltages are dc between ground and measurement points.\*
- Readings are taken with a color-bar signal input.\*
- Readings are taken with a digital multimeter (DC10M $\Omega$  ).\*
- Voltage variations may be noted due to normal production tolerances.\*

### VS-95 (REC/PB HEAD AMP, VIDEO, SERVO/SYSTEM CONTROL) PRINTED WIRING BOARD

-- Ref. No. VS-95 BOARD: 4000 series --

### • For printed wiring boards.

• VS-95 board is the printed wiring board which has four layers structure but inner two layers' patterns are omitted.

: Through hole is omitted.

Caution:

Parts face side:

Pattern face side: Parts on the pattern face side seen from

Parts on the parts face side seen from the

(Conductor Side) the pattern face are indicated.

(Component side) parts face are indicated.

< IC > < DIODE > 8-719-800-76 DIODE 1SS226 IC001 8-752-033-38 IC CXA1202R **⚠ Q**001 D001 Q003 IC003 8-752-053-21 IC CXA1211M D121 8-719-027-50 DIODE MA142WK Q008 IC121 8-759-605-61 IC CXA1203N 8-719-027-48 DIODE MA142WA D152 8-719-027-50 DIODE MA142WK IC151 8-752-065-54 IC CXA1207AR Q010 D159 **∆**Q019 D160 8-719-027-50 DIODE MA142WK IC152 8-752-065-56 IC CXA1208R 8-719-404-46 DIODE MA110 IC154 8-752-333-24 IC CXL1506M \$\text{Q020} D161 IC155 8-752-053-21 IC CXA1211M Q021 D162 8-719-027-50 DIODE MA142WK IC156 8-759-055-82 IC M62353GP Q022 8-719-027-50 DIODE MA142WK D163 8-719-421-27 DIODE MA728 IC158 8-759-055-82 IC M62353GP Q024 D401 Q025 IC159 8-759-636-33 IC CXA1452N D402 8-719-027-50 DIODE MA142WK D403 8-719-404-46 DIODE MA110 IC401 8-759-056-84 IC S-8420AF Q026 IC402 8-752-838-20 IC CXP80624-428R Q121 IC403 8-759-096-79 IC uPD75316GF-318-3B9 Q123 IC404 8-759-059-42 IC CXA1481AR Q124 IC405 8-759-044-78 IC AK6420F Q125 IC406 8-759-081-96 IC uPD6456GS-620 Q126 IC407 8-759-145-63 IC uPD7564G-540 Q151

IC408 8-759-057-60 IC MCD004BM


IC409 8-759-999-02 IC TL1596CDSB

IC410 8-759-062-02 IC MPC1720VM

Q152

Q154

Q158



< TRANSISTOR >

8-729-101-07 TRANSISTOR 2SB798-DL

8-729-402-32 TRANSISTOR 2SD1819A-R

8-729-402-32 TRANSISTOR 2SD1819A-R

8-729-402-32 TRANSISTOR 2SD1819A-R

Q151

Q152

**EM CONTROL** 

**— 34** —

	⚠Q001 Q003 Q008 Q010 ⚠Q019	8-729-216-22 TRANSISTOR 2SA1162-G 8-729-402-55 TRANSISTOR 2SB1218A-R 8-729-402-32 TRANSISTOR 2SD1819A-R 8-729-403-35 TRANSISTOR UN5113 8-729-120-28 TRANSISTOR 2SC1623-L5L6	Q160 Q161 Q162 Q166 Q168	8-729-403-35 TRANSISTOR UN5113 8-729-402-32 TRANSISTOR 2SD1819A-R 8-729-403-35 TRANSISTOR UN5113 8-729-402-55 TRANSISTOR 2SB1218A-R 8-729-403-35 TRANSISTOR UN5113	Q195 Q196 Q199 Q200 Q203	8-729-402-55 TRANSISTOR 2SB1218A-R 8-729-403-35 TRANSISTOR UN5113 8-729-807-87 TRANSISTOR 2SB1295-UL6 8-729-013-88 TRANSISTOR RN1302-TE85L 8-729-402-55 TRANSISTOR 2SB1218A-R	Q232 Q233 Q234 Q236 Q237	8-729-402-32 TRANSIST 8-729-402-32 TRANSIST 8-729-402-55 TRANSIST 8-729-420-56 TRANSIST 8-729-425-50 TRANSIST
	<b> ∆</b> Q020	8-729-120-28 TRANSISTOR 2SC1623-L5L6	0170	8-729-420-20 TRANSISTOR XN4312	Q204	8-729-402-32 TRANSISTOR 2SD1819A-R	Q401	8-729-402-48 TRANSIST
	Q021	8-729-905-23 TRANSISTOR 2SA1576-R	0171	8-729-117-73 TRANSISTOR 2SC4178-F14	Q205	8-729-402-42 TRANSISTOR UN5213	Q403	8-729-403-35 TRANSIST
	Q022	8-729-402-55 TRANSISTOR 2SB1218A-R	0174	8-729-402-32 TRANSISTOR 2SD1819A-R	Q207	8-729-403-35 TRANSISTOR UN5113	Q405	8-729-013-88 TRANSIST
	Q024	8-729-102-07 TRANSISTOR 2SC2223-F13	0175	8-729-402-32 TRANSISTOR 2SD1819A-R	Q208	8-729-013-88 TRANSISTOR RN1302-TE85L	Q409	8-729-017-67 TRANSIST
	Q025	8-729-014-16 TRANSISTOR RN2302-TE85L	Q176	8-729-402-32 TRANSISTOR 2SD1819A-R	Q210	8-729-402-42 TRANSISTOR UN5213		
	Q026	8-729-402-32 TRANSISTOR 2SD1819A-R	Q177	8-729-402-55 TRANSISTOR 2SB1218A-R	Q212	8-729-402-55 TRANSISTOR 2SB1218A-R		
R	Q121	8-729-403-35 TRANSISTOR UN5113	Q178	8-729-402-55 TRANSISTOR 2SB1218A-R	0214	8-729-420-12 TRANSISTOR XN4213		
18-3B9	Q123	8-729-402-42 TRANSISTOR UN5213	Q180	8-729-422-54 TRANSISTOR XN4215	0219	8-729-810-13 TRANSISTOR 2SA1677		
	Q124	8-729-403-35 TRANSISTOR UN5113	Q182	8-729-402-32 TRANSISTOR 2SD1819A-R	0220	8-729-402-45 TRANSISTOR UN5212		
	Q125	8-729-117-73 TRANSISTOR 2SC4178-F14	Q183	8-729-420-53 TRANSISTOR UN5115	Q221	8-729-420-12 TRANSISTOR XN4213		
0	Q126	8-729-402-32 TRANSISTOR 2SD1819A-R	Q184	8-729-402-32 TRANSISTOR 2SD1819A-R	Q222	8-729-402-32 TRANSISTOR 2SD1819A-R		
	0151	9 790 101 07 TRANSFORMS SCREEN BY	0.00	0.500 400 00 00 00 000 000 000 000 000				

8-729-402-32 TRANSISTOR 2SD1819A-R

8-729-402-32 TRANSISTOR 2SD1819A-R

8-729-402-32 TRANSISTOR 2SD1819A-R

8-729-402-32 TRANSISTOR 2SD1819A-R

8-729-402-42 TRANSISTOR UN5213

Q230

8-729-402-55 TRANSISTOR 2SB1218A-R

8-729-402-32 TRANSISTOR 2SD1819A-R

8-729-402-55 TRANSISTOR 2SB1218A-R

VIDEO, SERVO/SYSTEM C

- 35 -

Q189


Q192


Q194




```
B1218A-R
                            8-729-402-32 TRANSISTOR 2SD1819A-R
5113
                            8-729-402-32 TRANSISTOR 2SD1819A-R
B1295-UL6
11302-TE85L
                     Q236
                            8-729-420-56 TRANSISTOR UN511E
                            8-729-425-50 TRANSISTOR 2SB1218A-R
B1218A-R
D1819A-R
                            8-729-402-48 TRANSISTOR UN521E
5213
                            8-729-403-35 TRANSISTOR UN5113
                            8-729-013-88 TRANSISTOR RN1302-TE85L
5113
11302-TE85L
                            8-729-017-67 TRANSISTOR 2SB1574
5213
B1218A-R
14213
A1677
5212
14213
D1819A-R
5213
B1218A-R
D1819A-R
```


B1218A-R












### • SIGNAL PATH

		AUDIO		
	CHROMA	Υ	Y/CHROMA	SIGNAL
REC	-	->>	→>>>	Single-
PB		↔	➾	5

	REC	REC/PB	PB
Drum speed servo			
Drum phase servo			
Drum servo (speed and phase)			
Capstan speed servo			
Capstan phase servo			
Capstan servo (speed and phase)			
Ref. signal			$\sum$

### **VS-95** BOARD(1/3)




≺R14 ĐEM IN


--≺R4 REC C CONT ---≺R9 REC Y CONT ---≺R8 MT 1CH


-≺R6 MT 2CH


TO VS-95 BOARÐ


(See Page 44)












27



### • SIGNAL PATH

23

24


25

26

		AUDIO		
	CHROMA Y Y/C		Y/CHROMA	SIGNAL
REC	-	<b>→&gt;</b>		<b>8</b> .4>
РВ				god >


	REC	REC/PB	РВ
Drum speed servo		<b>A</b>	
Drum phase servo		<b>▶</b>	
Drum servo (speed and phase)		<b>&gt;&gt;&gt;</b>	
Capstan speed servo			
Capstan phase servo			$\Sigma$
Capstan servo (speed and phase)		<b>&gt;&gt;&gt;</b>	
Ref. signal		25	In a

### **VS-95** BOARD(3/3)



### MA-149 (MIC JACK, MIC AMP) PRINTED WIRING BOARD

-- Ref. No. MA-149 BOARD: 2000 series --



• For printed wiring boards.

 MA-149 board is the printed wiring board which has four layers structure but inner two layers' patterns are omitted.

Through hole is omitted.

Caution:

Pattern face side: Parts on the pattern face side seen from the pattern face are indicated.

Parts face side: Parts on the parts face side seen from the (Component side) parts face are indicated.

< DIODE >


D552 8-719-404-46 DIODE MA110

< IC >

IC551 8-759-822-37 IC LA7293M-TE-L

< TRANSISTOR >

Q551 -8-729-402-55 TRANSISTOR 2SB1218A-R



**— 49 —** 

AUDIO AUDIO

### CL-29 (COLOR VIEW FINDER), IV-10 (DC/AC CONVERTER), LB-33 (BACK


- Ref. No. LB-33 BOARD: 2000 series, CL-29, IV-10 BOARDS: 9000 series -


### · For printed wiring boards.


### 


Cautio	n:	
Patterr (Condu	ı face side: ıctor Side)	Parts on the pattern face side seen from the pattern face are indicated.
Parts fa (Comp	ace side: onent side)	Parts on the parts face side seen from the parts face are indicated.


		< DIODE	E >			< TRANSISTOR	>
D101 D102 D103	8-719-981-59 8-719-951-22 8-719-802-36	DIODE	FC805 IMN10 1SS250	Q101 Q102 Q103 Q104	8-729-808-01 8-729-421-90 8-729-420-12 8-729-120-28	TRANSISTOR TRANSISTOR	2SD16 XN411 XN421 2SC16
		< IC >		Q105	8-729-905-23		2SA15
IC101 IC102 IC103	8-759-070-30 8-759-998-92 8-759-998-98	IC LA	33776APNF-G-BND 1393D 1358D	Q106 Q107 Q108 Q109	8-729-011-35 8-729-403-27 8-729-120-28 8-729-905-23	TRANSISTOR TRANSISTOR	2SK12 XN440 2SC16 2SA15











s above correspond to CCD-TR303E/TR303EP SERVICE MANUAL.

### SIGNAL PATH

		AUDIO		
	CHROMA	Y	Y/CHROMA	SIGNAL
С				***
3				⇔

000 series, CL-29, IV-10 BOARDS: 9000 series —


### rds.


ted.

on the pattern face side seen from attern face are indicated.


on the parts face side seen from the face are indicated.


E	>			< TRANSISTOR	>
	FC805	Q101	8-729-808-01	TRANSISTOR	2SD1622-S
	IMN10	Q102	8-729-421-90	TRANSISTOR	XN4113
	1SS250	Q103	8-729-420-12	TRANSISTOR	XN4213
		Q104	8-729-120-28	TRANSISTOR	2SC1623-L5L6
		Q105	8-729-905-23	TRANSISTOR	2SA1576-R
B	G776APNF-G-BND	Q106	8-729-011-35	TRANSISTOR	2SK1299S
M:	393D	Q107	8-729-403-27	TRANSISTOR	XN4401
M3	358D	Q108	8-729-120-28	TRANSISTOR	2SC1623-L5L6
		Q109	8-729-905-23	TRANSISTOR	2SA1576-R


















	_		ا مما	ا مد	40	1 40	ا مد ا	1 4-	1 40	ا ہے۔ ا	ا مد ا	ا مما			22	1
/	1 8 I	9	1 70 I	11 1	12	13	1 14	l 15	I 16	17	18 1	l 19 I	20	21	22	1
															'	




### 4-3. SEMICONDUCTORS

#### AK6420F



CXA1202R CXA1208R CXA1481AR ETM3021F0A IR3P90B




**CXA1211M** 




CXA1452N CXL1506M



CXP80624-413R CXP80624-428R/434R



### ETM3011F0A



LM358D LM393D




M62353GP μPD7564G-540



TL1596CDSB



 $\mu$ PD75316GF



XN4213 UMZ1



#### XN4312



GL1HD51



MA110



MA8082



GL3PR43




## SECTION 5 EXPLODED VIEWS

#### NOTE:

- -XX, -X mean standardized parts, so they may have some difference from the original one.
- Items marked " \* " are not stocked since they are seldom required for routine service. Some delay should be anticipated when ordering these items.
- The mechanical parts with no reference number in the exploded views are not supplied.
- Hardware (# mark) list is given in the last of this parts list.


The components identified by mark  $\triangle$  or dotted line with mark  $\triangle$  are critical for safety.
Replace only with part number specified.

### 5-1. CABINET (L) AND F PANEL ASSEMBLIES




Ref. No.	Part No.	Description	Remark	Ref. No.	Part No.	Description	Remark
1 2 3 4	3-736-807-01 3-578-221-00	SPRING, COMPRESSION KNOB, STAND-BY		* 12 13 14	3-713-790-21 1-696-487-12	STICKER, SONY SYMBOL (10) SCREW (M2X6), TAPPING, P3 CABLE, FLAT (FFC-90)	
6 7 8 * 9	4-602-490-00 3-942-895-01 3-943-154-11	SPRING SPRING, TENSION STOPPER, BELT HOLDER (B), REMOTE CONTROL LABEL, MODEL NUMBER (AEP)		15 16 * 17 18 19	3-719-601-01 3-949-000-01 A-7091-800-A	MA-149 BOARD, COMPLETE SCREW (B2X5), TAPPING RETAINER, MICROPHONE MICROPHONE UNIT PANEL ASSY, F	
* 9 10 11	3-952-616-01 3-719-381-01	LABEL, MODEL NUMBER (UK, E, Austral SCREW (M2X4) LID ASSY, CASSETTE	ian)	20 21 22 23	3-945-269-01 1-465-927-81	SPRING, TORSION KNOB, S REMOTE COMMANDER (CAM CORDER) (RM LID, REMOTE COMMANDER	1T-507)

### 5-2. CABINET (R) AND EVF ASSEMBLIES



Ref. No.	Part No.	Description		Remark	Ref. No.	Part No.	Description	Remark
51 52 53 54 55	A-7071-655-A A-7071-653-A A-7071-654-A	CN-65 BOARD, COMPLETE CF-32 BOARD, COMPLETE VK-27 BOARD, COMPLETE ED-35 BOARD, COMPLETE SCREW (M2X6), TAPPING,	Р3		76 77 78 79 80	3-948-843-01 3-713-786-51 A-7071-656-A	KNOB, BATTERY LID, BATTERY CASE, LITHIUM SCREW (M2X3) MF-191 BOARD, COMPLETE SWITCH, PUSH (ZOOM)	
56 57 58 59 60	X-3942-156-1 3-942-911-01 3-948-990-01	SCREW (M2X10.5) CABINET (R) ASSY SCREW, TRIPOD LOCK, BATTERY SPRING, COMPRESSION			81 82 83 84 85	X-3942-758-1 3-948-162-01 X-3942-633-1	LID ASSY, LS HOLDER ASSY, FINDER EYE CUP SLIDER (UPPER) ASSY SLIDER (LOWER) ASSY	
61 62 63 64 65	3-303-973-00 3-946-186-01 3-948-975-01	BLIND, POWER SPRING, COMPRESSION PUSH BUTTON, POWER POWER (BASE) BUTTON, POWER			86 87 88 89 90	3-944-591-01 X-3942-757-1 3-944-590-71	SCREW (M2X3) SCREW (M2X7), TAPPING CABINET (L) ASSY, EVF CABINET (R), EVF CL-29 BOARD, COMPLETE	
66 67 68 69 70	3-747-111-01 3-747-110-01 3-747-178-01	SPRING, LEAF, VK PLATE, LOCK, TILT SPRING, LEAF, TILT REINFORCEMENT, TILT LC SCREW (B2X5), TAPPING	CK		91 192 * 93 * 94 95	A-7063-224-A 3-952-611-01 3-952-612-01	CONNECTOR, BOARD TO BOARD 10P 1V-10 BOARD, COMPLETE (AC/DC CONVER HOLDER (F), BL PROTECTOR, LCD SPONGE, SEAL	TER)
71 * 72 73 74 75	3-948-976-01 3-948-987-01 3-747-112-01 3-747-109-01 3-949-008-01	RING, TILT SLEEVE, EVF				3-944-610-01 3-704-235-01 1-519-667-11	LB-33 BOARD, COMPLETE HOLDER (R), BL LABEL, CAUTION (UK) TUBE, FLUORESCENT DISPLAY MODULE, LIQUID CRYSTAL	

### 5-3. MAIN BOARD ASSEMBLY



Ref. No.	Part No.	Description	Remark	Ref. No.	Part No.	Description	Remark
<b>1</b> 01 102 103	3-713-786-51	DD-48 BOARD, COMPLETE SCREW (M2X3) SCREW (B TIGHT) (2), TAPPING		119 120		JK-91 BOARD, COMPLETE SCREW (M2X4)	
104 105	A-7063-318-A	CD-92 BOARD, COMPLETE RUBBER (S), SEAL		* 121 122 123	A-7063-321-A	FRAME (M), JACK AU-138 BOARD, COMPLETE SHIELD, DRUM	
106 107 108	3-946-856-01	FILTER BLOCK, OPTICAL ADAPTOR (H), CCD FITTING LENS, ZOOM (VCL-6210WC)		H516	1-550-104-32	HOLDER, BATTERY CCD BLOCK ASSY (ICX055AK-2)	(CCD IMAGER)
* 109 110	3-949-001-01	FRAME, LENS SCREW (M2X6), TAPPING, P3		J901	1-537-281-41	TERMINAL BOARD TERMINAL BOARD LINK, IC 1.6A/90V	
111 112 113	3-948-842-01	LI-44 BOARD, COMPLETE HOLDER, LI VC-122 BOARD, COMPLETE		<u></u> <b>♠</b> PS902	1-532-841-21	LINK, IC 1.6A/90V FP-588 FLEXIBLE BOARD	
114 115	3-719-601-01	SCREW (B2X5), TAPPING VS-95 BOARD, COMPLETE		W517	1-696-482-11	FP-572 FLEXIBLE BOARD CABLE, FLAT (FFC-85) CABLE, FLAT (FFC-92)	
* 116 117 118	A-7071-651-A	FRAME (UPPER LOWER) ASSY SW-205 BOARD, COMPLETE SL-27 BOARD, COMPLETE		₩521	1-642-186-11	FP-437 FLEXIBLE BOARD FP-589 FLEXIBLE BOARD	

#### NOTE:

specified.

The components identified by mark ⚠ or dotted line with mark ⚠ are critical for safety. Replace only with part number

When indicating parts by reference number, please include the board name.

### **SECTION 6 ELECTRICAL PARTS LIST**

- Due to standardization, replacements in the parts list may be different from the parts specified in the diagrams or the components used on the set.
- · -XX, -X mean standardized parts, so they may have some difference from the original one.
- RESISTORS All resistors are in ohms METAL: Metal-film resistor METAL OXIDE: Metal Oxide-film resistor F: nonflammable
- Hardware (# mark) list is given in the last of this
- Items marked "\*" are not stocked since they are seldom required for routine service. Some delay should be anticipated when ordering these items.
- SEMICONDUCTORS In each case, u:  $\mu$ , for example: uA...:  $\mu$  A..., uPA...:  $\mu$  PA..., uPB...:  $\mu$  PB..., uPC...:  $\mu$  PC... uPD...: *μ* PD...
- CAPACITORS  $\mathsf{uF}:\mu\,\mathsf{F}$
- COILS  $uH: \mu H$

Ref. No.	Part No.	Description			Remark	Ref. No.	Part No.	Description Remark
RC1, NO.	1410 1101	<del>2000112101</del>						
	A-7063-502-A	CL-29 BOARD,				C940		TANTAL CHIP 1.5uF 20% 20V
		**********		No 0	000 Series)	C941 C942		CERAMIC CHIP 0.0047uF 10% 25V CERAMIC CHIP 0.01uF 50V
			(hei	. 140 3,	000 361 163/	0342	1 102 374 11	Chimic City 0, old
	1-573-989-11	CONNECTOR, BOA	ARD TO BOA	RD 10P				< CONNECTOR >
	3-944-643-01	HOLDER, LED				CNOOL	1 572 205 11	CONNECTOR DOADN TO DOADN 10D
		< CAPACITOR >						CONNECTOR, BOARD TO BOARD 10P PIN, CONNECTOR (1.5MM) (SMD)6P
		Children on a						CONNECTOR, ZIF (I TYPE) 20P
C902		CERAMIC CHIP		10%	10V	CN904	1-573-984-11	CONNECTOR, BOARD TO BOARD 10P
		CERAMIC CHIP			50V			< TRIMMER >
C904 C906		CERAMIC CHIP		10%	50 <b>V</b>			( IRIMMER )
		TANTAL. CHIP		20%	20V	CT901	1-141-423-61	CAP, ADJ
C908		CERAMIC CHIP			50V			< DIODE >
C909 C910		CERAMIC CHIP			16V 25V	D901	8-719-980-83	DIODE GL3PR43
C911		TANTAL. CHIP		20%	6. 3V	D902	8-719-941-34	
C912		CERAMIC CHIP		10%	25V		8-719-421-18	
0010	1 100 070 11	CEDANIC CUID	0.01E	1.09/	25V		8-719-820-05 8-719-002-81	
C913 C914		CERAMIC CHIP		10% 10%	6. 3V	D303	, 0-119-002-01	DIODE 11303
C915		CERAMIC CHIP		20/0	25 <b>V</b>	D906	. 8-719-404-46	DIODE MA110
		TANTALUM CHIP		10%	35V	D907	8-719-420-14	
C917	1-162-970-11	CERAMIC CHIP	0. 01uF	10%	25V	D908	8-719-420-14	DIODE MA8082-M
C918	1-162-917-11	CERAMIC CHIP	15PF	5%	50V			< IC >
		CERAMIC CHIP	12PF	5%	50V			
C920			luF	<b>5</b> 84	16V		8-759-070-66	
C921 C922		CERAMIC CHIP		5% 10%	50V 50V		8-759-513-06 8-759-159-97	
0022	1 102 000 11	CEITING CITT	0. 002241	2010		10000	0 100 100 01	
C923		CERAMIC CHIP		10%	25V			< COIL >
C924		CERAMIC CHIP	0. 047uF 1uF		16V 16V	L901	1_412_022_11	INDUCTOR CHIP 4. 7uH
C925 C926		CERAMIC CHIP			25V		1-412-026-11	
C927		CERAMIC CHIP			25V	L903	1-412-962-11	
						L904	1-412-952-11	
C928		CERAMIC CHIP		5%	50V 16V	L905	1-412-956-21	INDUCTOR 27uH
C929 C930			0. 1uF		25V			< TRANSISTOR >
C931			0. 1uF		25V			
C932	1-162-964-11	CERAMIC CHIP	0. 001uF	10%	50V	Q901	8-729-402-81	TRANSISTOR XN4501
C933	1-162-951-11	CERAMIC CHIP	68PF	5%	50V			< RESISTOR >
C934		CERAMIC CHIP		10%	50V			, indicator ,
C935		TANTALUM CHIP		20%	10V	R901	1-216-841-11	
C936 C937		CERAMIC CHIP			16V 25V	R902 R903	1-216-841-11 1-216-841-11	
C331	1-104-130-11	CENTRIC CHIP	v. 1ur		431	R904	1-216-840-11	
C938			33PF	5%	50V	R905	1-216-840-11	
C939	1-164-156-11	CERAMIC CHIP	0. 1uF		25V			
					6	U —		

## CL-29 IV-10

Ref. No.	Part No.	Description				Remark	Ref. No.	Part No.	Description			Remark
R906	1-216-843-11		68K	5%	1/16W			A-7063-224-A	IV-10 BOARD,	COMPLETE		
	1-216-841-11			5%	1/16W				********	******		
R908	1-216-838-11			- 5%	1/16W					(Ref	. No 9,	000 Series)
R909	1-216-838-11	METAL CHIP	27K	5%	1/16W							
R910	1-216-846-11	METAL CHIP	120K	5%	1/16₩		*		CASE (UPPER), CASE (LOWER),			
R911	1-216-812-11	METAL CHIP	180	5%	1/16W							
R912	1-216-843-11	METAL CHIP	68K	5%	1/16W				< CAPACITOR >			
R913	1-216-843-11		68K	5%	1/16W							
R914	1-216-857-11		1M	5%	1/16W		C101	1-162-953-11	CERAMIC CHIP	100PF	5%	50V
R915	1-216-834-11		12K	5%	1/16W		C102		CERAMIC CHIP		10%	25V
		MDITID OTTI		0.0	2, 2011		C103		CERAMIC CHIP		10,0	16V
R916	1-216-836-11	METAL CHIP	18K	5%	1/16W				CERAMIC CHIP			16V
R917	1-216-844-11		82K	5%	1/16W		C105		TANTAL. CHIP		20%	16V
R918	1-216-846-11		120K		1/16W		0100	1 100 110 21	IMMIND. CHII	a. au	20%	101
R921	1-216-826-11		2. 7K		1/16W		C106	1_135_170_21	TANTAL, CHIP	2 2017	20%	16V
R924	1-216-855-11		680K		1/16W		C100		CERAMIC CHIP		10%	25 <b>V</b>
N324	1 210 055 11	METAL CITI	OOOM	370	1/10#		C108		CERAMIC CHIP		10/0	16 <b>V</b>
R925	1-216-839-11	METAL CUID	33K	5%	1/16W				CERAMIC CHIP		5%	16 <b>V</b>
R927	1-216-833-11		10K	5%	1/16W		C110		CERAMIC CHIP		10%	50V
R928	1-216-833-11		10K	5%	1/16W		C110	1-104 232-11	CERTAILC CITT	o. orar	10/0	301
R930	1-216-857-11		1M	5%	1/16W		C111	1_164_232_11	CERAMIC CHIP	0.0105	10%	50 <b>V</b>
R931	1-216-837-11		22K	5%	1/16W		C111			6. 8uF	10/0	
1,991	1-210-031-11	MEIAL CHIF	ZZN	3/6	1/10#		C112		CERAMIC CHIP	0. 1uF		16V 16V
R932	:1-216-837-11	METAL CUID	22K	5%	1/16W		C113			0. 1uF		
R934	1-216-837-11		22K	5%	1/16W		C114		CERAMIC CHIP		100	16V
R935	1-216-821-11		22K 1K	5%	1/16W		CIIS	1-102-970-11	CERAMIC CHIP	0. 01ur	10%	25V
R937							C116	3 19E 177 91	TANTALIM CHID	1	200	0.510
R938	1-218-897-11		68	0. 50% 5%	1/16W		C116 C117	1	TANTALUM CHIP CERAMIC CHIP	0. luF	20%	25V
11330	1-216-807-11	MEIAL CHII	00	3/0	1/10#		C118			luF		16V
R939	1-216-845-11	METAL CUID	100K	F0/	1/16₩		ı	1-165-178-11				16V
	1-216-845-11		100K				C119			6. 8uF	E <b>0</b> /	16V
R941	1-216-845-11		4. 7K		1/16W 1/16W		C120	1-102-353-11	CERAMIC CHIP	JJUPP	5%	50 <b>V</b>
							C121	1 100 170 11	CERAMIC CHIP	C 0D		1017
R942	1-216-822-11 1-216-812-11		1. 2K 180	5%	1/16W		(121	1-103-110-11	CERAMIC CHIP	o. our		16 <b>V</b>
1743	1-210-012-11	WEINE CHIL	100	3/0	1/10#				< CONNECTOR >			
R944	1-218-883-11	METAL CHIP	33K	0.50%	1/16W							
R945	1-220-397-91	METAL GLAZE	4.7M	5%	1/16W		CN101	1-573-305-11	CONNECTOR, BO	ARD TO BOAT	RD 10P	
R946	1-216-015-00	METAL CHIP	39	5%	1/10W		CN102	1-573-811-11	CONNECTOR, BO	ARD TO BOAR	RD 12P	
R947	1-216-823-11	METAL CHIP	1.5K	5%	1/16\							
<b>R9</b> 50	1-216-821-11	METAL CHIP	1K	5%	1/16W				< DIODE >			
R951	1-216-821-11	METAL CHIP	1K	5%	1/16W		D101	8-719-981-59	DIODE FC805			
	1-216-864-11		0	5%	1/16W			8-719-951-22				
	0 001				-,		ı	8-719-802-36		)		
		< VARIABLE R	ESISTOR >									
B.110.00				(==c)					< IC >			
	1-241-556-11			(BRT)								
	1-238-091-11						1	8-759-070-30		NF-G-BND		
	1-241-556-11				)		1	8-759-998-92				
	1-238-093-11						IC103	8-759-998-98	IC LM358D			
KV906	1-238-091-11	RES, ADJ, CE	RMET 22K						< COIL >			
RV907	1-238-091-11	RES, ADJ, CE	RMET 22K				1101	1. 419 091 11		4711		
		< VIBRATOR >					L101		INDUCTOR CHIP	47uH		
		/ ATDIVATOR >					L102		INDUCTOR CHIP	47uH		
X901	1-579-661-21	OSCILLATOR	CRVCTAI (	V VSWIT	<sub>7</sub> )				INDUCTOR CHIP	10uH		
7501	1 3/3-001-21	OCTUDATON,	CUISINE (	4. 40MH	<i>L)</i>		L104	1-412-030-11	INDUCTOR CHIP	22uH		
******	*****	********	*******	*****	*****	******						

## IV-10 LB-33 MA-149

Ref. No.	Part No.	Description				Remark	Ref. No.	Part No.	Description			Remark
		< TRANSISTOR	>				*	A-7071-789-A	LB-33 BOARD,			
Q101 Q102	8-729-808-01 8-729-421-90	TRANSISTOR	2SD1622-S XN4113	S							. No 2	,000 Series)
Q103 Q104	8-729-420-12 8-729-120-28	TRANSISTOR	XN4213 2SC1623-I						< CONNECTOR >			_
Q105	8-729-905-23	TRANSISTOR	2SA1576-I	?			CN991	1-573-812-11	CONNECTOR, BO	ARD TO BOA	RD 12	P
Q106 Q107	8-729-011-35 8-729-403-27		2SK1299S XN4401				******	**********	**********	*******	****	********
Q108 Q109	8-729-120-28 8-729-905-23	TRANSISTOR	2SC1623-1 2SA1576-1				*	A-7063-322-A	MA-149 BOARD,			
6103	0-123-303-23		20/10/0	ı.					,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,		No 2	,000 Series)
		< RESISTOR >							< CAPACITOR >			
R101 R102	1-216-832-11 1-216-832-11		8. 2K 8. 2K		1/16W 1/16W	i	C551	1-162-964-11	CERAMIC CHIP	0. 001uF	10%	50V
R103	1-218-740-11			0.50%			C552		CERAMIC CHIP		10%	50V
R104	1-218-708-11			0.50%			C553	1-162-960-11	CERAMIC CHIP	220PF	10%	50V
R105	1-216-797-11	METAL CHIP	10	5%	1/16W		C554	1-162-964-11	CERAMIC CHIP	0.001uF	10%	50V
							C555	1-162-587-11	CERAMIC CHIP	0. 039uF	10%	25V
R106	1-216-833-11	METAL CHIP	10K		1/16W							
R107	1-216-845-11		100K		1/16₩				CERAMIC CHIP		10%	25V
R108	1-218-883-11	METAL CHIP	33K	0.50%						100PF	5%	50V
R109	1-218-883-11	METAL CHIP	33K	0.50%	1/16W		C558			1uF		16V
R110	1-216-849-11	METAL CHIP	220K	5%	1/16W		C562		CERAMIC CHIP			16V
							C563	1-126-205-11	ELECT CHIP	47uF	20%	6. 3V
R111	1-216-845-11		100K		1/16W							
R112	1-216-833-11		10K	5%	1/16W				CERAMIC CHIP			16V
R113	1-216-845-11		100K		1/16W		C569	1-164-492-11	CERAMIC CHIP	0. 15uF	10%	16V
R114	1-216-804-11		39	5%	1/16W							
R115	1-216-845-11	METAL CHIP	100K	5%	1/16W				< CONNECTOR >			
R116	1-216-836-11	METAL CHIP	18K	0.5%	1/16W		CN551	1-566-537-11	CONNECTOR, FPO	C (NON ZIF	) 5P	
R117	1-216-837-11		22K	5%	1/16₩				PIN, CONNECTOR		,	
R118	1-216-833-11			5%	1/16W							
R119	1-216-838-11		27K	5%	1/16₩				< DIODE >			
R120	1-216-845-11		100K	5%	1/16₩							
				0 =00	1 (100		D552	8-719-404-46	DIODE MA110			
R121	1-218-708-11			0. 50%					/ TC >			
R122	1-216-846-11			0.5%					< IC > ,			
R123 R124	1-218-883-11 1-218-732-11			0. 50% 0. 50%			10551	8-750-822-37	IC LA7293M-TE	_ī		
R124 R125	1-216-845-11		100K		1/16W		10331	0 133 022 31	TC LA7255M-TE	L		
	2 210 010 11				-,				< JACK >			
	1-216-833-11		10K	5%	1/16W							
	1-216-833-11		10K	5%	1/16W		J551	1-568-027-11	JACK, SMALL T	YPE 1P (MIC	C)	
R128	1-216-839-11	METAL CHIP	33K	5%	1/16W				< COIL >			
		< VARIABLE R	ESISTOR >									
			DATEM A AIR						INDUCTOR CHIP			
	1-238-854-11						L572	1-410-192-51	INDUCTOR CHIP	luH		
KV 1 UZ	1-238-856-11	NEO, MUJ, CE	VMICI IOV						< TRANSISTOR :	>		
		< TRANSFORME	R >				0551	8-729-402-55	TRANSISTOR 2SI	R12184-R		
T101	1-450-974-21	TRANSFORMER	D-D			İ	#OOT	. 0 120 102 30	inmotoron Zol	JIBION N		
	1-450-975-21								< RESISTOR >			
							DE	3 010 000	MDM41 CVVV	1 6		. /10T
******	*******	*********	********	******	*****	*****	R551	1-216-822-11	METAL CHIP	1. 2K 59	ъ	1/16W

## MA-149 VS-95

Ref. No.	Part No.	Description			Remai	k Ref. No.	Part No.	Description			Rema	ark_
R552 R553	1-216-830-11 1-216-838-11		5. 6K 27K		1/16W 1/16W	C065 C066		CERAMIC CHIP	0. 01uF 0. 01uF		50V 50V	
R554	1-216-838-11		27K	5%	1/16W							
R555	1-216-864-11	METAL CHIP	0	5%	1/16W	C067		CERAMIC CHIP	0. 22uF		16V	
						C068		CERAMIC CHIP	47PF	5%	50V	
R556	1-216-864-11		0		1/16W	C069		CERAMIC CHIP	39PF	5%	50V	
R558	1-216-831-11		6. 8K		1/16W	C070		CERAMIC CHIP	100PF	5%	50V	
R564	1-216-295-00		0		1/10W	C072	1-162-943-11	CERAMIC CHIP	15PF	5%	50V	
R565	1-216-821-11		1K		1/16W	C071	-1 100 OE1 11	CEDAMIC CITE	CODE	Ε0/	FOW	
R566	1-216-864-11	METAL CHIP	0	5%	1/16W	C073	1-162-951-11		68PF 180PF	5 <b>%</b>	50V	
******		*********			*****	* C074		CERAMIC CHIP	12PF	5% 5%	50V 50V	
*****	*****	******	*****	*****	*****	C077		CERAMIC CHIP	0. 022uF	10%	25V	
*	4-7063-316-4	VS-95 BOARD, (	COMPLETE			C078		CERAMIC CHIP	3PF	0. 25PF		
Τ	V 1000-210 V	*********				0010	1 102 334 11	CERAMIC CITT	JI I	0. 231 F	304	
		***************************************		f. No 4	,000 Series	c080	1-162-970-11	CERAMIC CHIP	0. 01uF	10%	25V	
			(		, 000 001 10	C081		CERAMIC CHIP	18PF	5%	50V	
	1-691-471-11	CONNECTOR, TRA	ANSLATION	N 11P		C082		CERAMIC CHIP		10%	25V	
						C083	1-164-227-11	CERAMIC CHIP	0. 022uF	10%	25V	
		< CAPACITOR >				C085	1-162-947-11	CERAMIC CHIP	33PF	5%	50V	
C001	1-162-974-11	CERAMIC CHIP	0. 01uF		50V	C086	1-162-970-11	CERAMIC CHIP	0.01uF	10%	25V	
C002		CERAMIC CHIP		5%	50V	C091			0.01uF		50V	
C003		CERAMIC CHIP		5%	50 <b>V</b>	C092		CERAMIC CHIP			50V	
C004		CERAMIC CHIP		5%	50V	C121		CERAMIC CHIP			50V	
C005	1-162-953-11	CERAMIC CHIP	100PF	5%	50V	C122	1-162-974-11	CERAMIC CHIP	0. 01uF		50V	
2002	1 104 000 11	OPPANIO CILID	0. 1. D	100	001	6100	1 125 101 01	TANKALINA CUID	4. 7. D	000	0.077	
		CERAMIC CHIP		10%	25V 16V	C123		TANTALUM CHIP CERAMIC CHIP		20%	6. 3V	
C009 C010		CERAMIC CHIP TANTALUM CHIP		20%	6. 3V	C124 C125		CERAMIC CHIP			16V 50V	
C010		CERAMIC CHIP		10%	25V	C125		CERAMIC CHIP		10%	50V	
C012		CERAMIC CHIP		10%	25V	C127		CERAMIC CHIP		5%	50V	
0012	1 104 000 11	CDRAWIC CITI	V. 101	10/0	201	(12)	1 104 145 11	CLIMATE CITT	33011	570	301	
C013	1-164-633-11	CERAMIC CHIP	0. luF	10%	25V	C128	1-162-943-11	CERAMIC CHIP	15PF	5%	507	
C014		CERAMIC CHIP		10%	25V	C129				10%	507	
C018		CERAMIC CHIP			50V	C130		TANTAL. CHIP		20%	6. 3V	
C019		CERAMIC CHIP		10%	25V	C131		CERAMIC CHIP			50Y	
C020	1-164-633-11	CERAMIC CHIP	0. 1uF	10%	- 25V	C132	1-163-118-00	CERAMIC CHIP	110PF	5%	50Y	
C021	1-162-974-11	CERAMIC CHIP	0 01nF		50V	C133	1-135-149-21	TANTALUM CHIP	2 2uF	20%	6 ₹V	
C022		CERAMIC CHIP			50V	C135		CERAMIC CHIP		2070 .	50°	
C023		CERAMIC CHIP			50V	C136		CERAMIC CHIP			50°	
C024	1-162-974-11	CERAMIC CHIP	0. 01uF		50V			CERAMIC CHIP			507	
C025		TANTAL. CHIP		20%	6. 3V	C150		CERAMIC CHIP		5%	507	
		CERAMIC CHIP			16V	C151		CERAMIC CHIP			507	
		CERAMIC CHIP			16V .	C156		CERAMIC CHIP	39PF	5%	50/	
		CERAMIC CHIP			50V	C159			27PF	5%	50/	
C029		CERAMIC CHIP		0.00/	16V	C161		CERAMIC CHIP		5%	50/	
C030	1-135-259-11	TANTAL. CHIP	10uF	20%	6. 3V	C167	1-162-974-11	CERAMIC CHIP	0. 01uF		50	
C035	1-135-157-21	TANTALUM CHIP	10uF	20%	6. 3V	C168	1-162-974-11	CERAMIC CHIP	0 01nF		50	
C049		CERAMIC CHIP		-074	50V	C170		CERAMIC CHIP			25	
C057		CERAMIC CHIP			50V	C171		CERAMIC CHIP			16	
C058		CERAMIC CHIP			50V	C173		CERAMIC CHIP	0. 01uF		501	
C059		CERAMIC CHIP			50V	C175	1-128-004-11		10uF	20%	16	
000												
C061		CERAMIC CHIP			50V	C176		CERAMIC CHIP			501	
C063		CERAMIC CHIP			50V	C177		CERAMIC CHIP		E0/	501	
C064	1-102-995-11	CERAMIC CHIP	u. uzzur		50V	C178	1-104-145-11	CERAMIC CHIP	390PF	5%	501	

Ref. No.	Part No.	Description			Remark	Ref. No.	Part No.	Description			Remark
C179 C180		CERAMIC CHIP CERAMIC CHIP	0. 01uF 33PF	5%	50V 50V	C255 C256		CERAMIC CHIP	0.01uF 0.01uF		50V 50V
C181 C182		CERAMIC CHIP	0. 0015uF 270PF	10% 5%	50V 50V	C257 C259		CERAMIC CHIP	47PF 0. 01uF	5%	50V 50V
C187 C188	1-162-958-11	CERAMIC CHIP		5% 5%	50V 50V	C260 C261	1-162-974-11	CERAMIC CHIP	22PF 0. 01uF	5%	50V 50V
C189		CERAMIC CHIP	470PF	5%	50V	C262		CERAMIC CHIP	120PF	5% 5%	50V
C192 C193 C194	1-162-953-11	CERAMIC CHIP CERAMIC CHIP TANTAL, CHIP	270PF 100PF 10uF	5% 5% 20%	50V 50V 6. 3V	C263 C264 C265	1-162-950-11	CERAMIC CHIP CERAMIC CHIP CERAMIC CHIP	68PF 56PF 220PF	5% 5% 5%	50V 50V 50V
C199 C205	1-135-149-21	TANTALUM CHIP CERAMIC CHIP	2. 2uF	20% 5%	6. 3V 50V	C266 C267	1-162-953-11	CERAMIC CHIP CERAMIC CHIP	100PF 0. 01uF	5%	50V 50V
C206	1-164-360-11	CERAMIC CHIP	0. 1uF		16V	C268		CERAMIC CHIP	150PF	5%	50 <b>Y</b>
C207 C208		CERAMIC CHIP	82PF 0. 0033uF	5% 10%	50V 50V	C269 C270		CERAMIC CHIP	0. 1uF 33PF	5%	16V 50V
C209	1-135-259-11	TANTAL, CHIP	10uF	20%	6. 3V	C271	1-128-004-11	ELECT CHIP	10uF	20%	16V
C213	1-164-222-11	CERAMIC CHIP	0. 22uF		25V	C272	1-162-974-11	CERAMIC CHIP	0. 01uF		50V
C214		CERAMIC CHIP		0.00	25V	C273	1-126-205-11		47uF	20%	6. 3V
C216 C217	1-128-004-11	TANTALUM CHIP	10uF 4. 7uF	20% 20%	16V 6. 3V	C278 C280		CERAMIC CHIP	1uF 0. 022uF		16V 50V
C218	1-162-974-11	CERAMIC CHIP	0. 01uF		50V	C281		TANTALUM CHIP		20%	25V
C219	1-135-259-11	TANTAL. CHIP	10uF	20%	6. 3V	C282	1-135-091-00	TANTALUM CHIP	luF	20%	16V
C220	1-126-246-11		220uF	20%	4V	C283		TANTALUM CHIP		20%	16V
C221 C222		CERAMIC CHIP	0. 0033uF 0. 01uF	10%	50V 50V	C284 C285		CERAMIC CHIP	0.0068uF 10uF	10% 20%	25V 6. 3V
C223	1-128-004-11		10uF	20%	16V	C286		CERAMIC CHIP		20%	50V
C225		TANTAL. CHIP	10uF	20%	6. 3V	C288		CERAMIC CHIP			50 <b>V</b>
C226		CERAMIC CHIP	0. 47uF		25V	C289		CERAMIC CHIP	0. 1uF		16V
C227		TANTAL. CHIP	10uF	20%	6. 3V	C290		CERAMIC CHIP	0. 01uF		50V
C228 C229		TANTAL. CHIP	10uF 3 3uF	20% 20%	6. 3V 6. 3V	C291 C292		CERAMIC CHIP		20%	50V 6. 3V
C230			10uF	20%	6. 3V	C294			luF	2070	16V
C231		CERAMIC CHIP		• • • •	50V	C295		TANTAL. CHIP	10uF	20%	6. 3V
C232 C233	1-135-180-21 1-128-004-11	TANTALUM CHIP	3. 3uF 10uF	20% 20%	6. 3V 16V	C296 C297		CERAMIC CHIP	0. 01uF	20%	50V 6. 3V
C234		CERAMIC CHIP		20%	50V	C298		CERAMIC CHIP	33PF	5%	50V
C235		CERAMIC CHIP			507	C299		CERAMIC CHIP	47PF	5%	50V
C236	1-135-259-11	TANTAL. CHIP	10uF	20%	6. 3V	C300	1-162-953-11	CERAMIC CHIP	100PF	5%	50V
C237		TANTAL. CHIP		20%	6. 3V	C301			10uF	20%	6. 3V
C238 C239		CERAMIC CHIP		5%	25V 50V	C302 C303		CERAMIC CHIP		20%	50V 6. 3V
C240		CERAMIC CHIP	330PF	5%	50V	C304		CERAMIC CHIP		2070	50V
C241	1-126-607-11		47uF	20%	4V	C305		TANTAL. CHIP		20%	6. 3V
C242 C245		CERAMIC CHIP	220PF 0 047uF	10%	50V 50V	C306 C307		CERAMIC CHIP		20%	50V 16V
C245 C246		TANTALUM CHIP		20%	6. 3V	C401		CERAMIC CHIP		2U%	16V
C247		TANTAL. CHIP		20%	6. 3V	C402		TANTAL. CHIP		20%	6. 3V
C248		CERAMIC CHIP		F8/	50V	C404			luF		16V
C249 C250		CERAMIC CHIP	330PF 390PF	5% 5%	50V 50V	C406 C407		CERAMIC CHIP			16V 50V
				-		•					•

Ref. No.	Part No.	Description			Remark	Ref. No.	Part No.	Description			Re	mark
C408 C409		TANTAL. CHIP CERAMIC CHIP	10uF 0. 0022uF	20% 10%	6. 3V 50V	C463 C464		TANTAL. CHIP TANTALUM CHIP		20% 20%	16V 6. 3V	
C412		CERAMIC CHIP	0. 022uF	10%	25V	C465			0. luF	10%	25 <b>V</b>	
C413		CERAMIC CHIP	0. 01uF	10%	25V	C466			0. 15uF	10%	25V	
C414			22PF	5%	50V	C467			0. 01uF	10%	25V	
C415 C416		CERAMIC CHIP	0. 22uF 12PF	5%	16V 50V	C468 C469		CERAMIC CHIP	0. 15uF 0. 0033uF	10% 10%	25V 50V	
C417		CERAMIC CHIP	0. 1uF		16V	C470			0.0033uF	10%	50V	
C418		TANTAL, CHIP	10uF	20%	6. 3V	C471		CERAMIC CHIP	0. 01uF	000	50V	
C420			0. 022uF	20%	50V	C472 C473		TANTAL. CHIP CERAMIC CHIP	10uF 0. 047uF	20% 10%	6. 3V 16V	
C421 C422		TANTAL. CHIP	10uF 10uF	20%	6. 3V 6. 3V	C474		CERAMIC CHIP	0. 047ur 0. 0033uF	10%	50V	
C423	1-164-361-11	CERAMIC CHIP	0. 047uF		16V	C475	1-162-995-11	CERAMIC CHIP	0. 022uF		507	
C424		CERAMIC CHIP	0. 022uF		50V	C476		TANTAL, CHIP	2. 2uF	20%	167	
C425		CERAMIC CHIP	0. 022uF		50V	C477		CERAMIC CHIP	0.01uF		507	
C426			0. 022uF	10%	25V	C478		CERAMIC CHIP	33PF	5%	507	
C427	1-162-974-11	CERAMIC CHIP	0. 01uF		50V	C481	1-164-360-11	CERAMIC CHIP	0. luF		167	
C428	1-162-995-11	CERAMIC CHIP	0. 022uF		50 <b>V</b>	C482	1-164-360-11	CERAMIC CHIP	0. 1uF		167	
C429	1-162-964-11	CERAMIC CHIP	0.001uF	10%	50V	C483	1-162-970-11	CERAMIC CHIP	0.01uF	10%	25 V	
C430	1-164-360-11	CERAMIC CHIP	0. 1uF		16V	C484		TANTAL, CHIP	10uF	20%	6. 3V	
C431		CERAMIC CHIP	0. 0015uF	10%	50V	C485		TANTAL. CHIP	10uF	20%	6. 3V	
C432	1-164-173-11	CERAMIC CHIP	0. 0039uF	10%	50V	C486	1-162-974-11	CERAMIC CHIP	0.01uF		50¥	
C433			18PF	5% 5%	50V	C487	1-128-530-11	ELECT CHIP	33uF	20%	107	
C434 C435		CERAMIC CHIP	15PF 0. 01uF	<b>3</b> 76	50V 50V			< FILTER, CER	AMIC >			
C435			0. 01uF		50V			Y FILIER, CER	AMIC /			
C437		CERAMIC CHIP	0. 022uF		50V	CF151	1-579-371-11	FILTER, CERAM	IC			
C438	1-162-995-11	CERAMIC CHIP	0. 022uF		50V			< CONNECTOR >				
C439		CERAMIC CHIP	2PF	0. 25PF	50V							
C440	1-162-964-11	CERAMIC CHIP	0.001uF	10%	50V	CN002	1-569-775-21	PIN, CONNECTOR	R 5P			
C441	1-162-964-11	CERAMIC CHIP	0.001uF	10%	50V			CONNECTOR, FPO	,	6P		
C442	1-162-995-11	CERAMIC CHIP	0. 022uF		50V			PIN, CONNECTOR				
								CONNECTOR, BOA				
C444		CERAMIC CHIP	0. 022uF		50V	CN403	1-573-338-11	CONNECTOR, BOA	ARD TO BOAR	RD 20P		
C445			10uF	20%	6. 3V	CN140.4	1 005 005 11	COMMEGTOR DO	DD TO DOLL	100		
C446		CERAMIC CHIP			50V			CONNECTOR, BOX				
C447 C449		CERAMIC CHIP			50V 16V			CONNECTOR, BOA		1D 30P		
C450	1-164-360-11	CERAMIC CHIP	0. 1pF		16V			< DIODE >				
C451		CERAMIC CHIP			25V			. 5.755 /				
C452		TANTAL. CHIP		20%	6. 3V	D001	8-719-800-76	DIODE 1SS226				
C453		CERAMIC CHIP		5%	50V	D121		DIODE MA142WK				
C454		CERAMIC CHIP		5%	50V	D152		DIODE MA142WA				
						D159		DIODE MA142WK				
C455		CERAMIC CHIP		10%	25V	D160		DIODE MA142WK				
C456		CERAMIC CHIP		10%	25V							
C457		CERAMIC CHIP		10%	25V	D161	8-719-404-46					
C458		CERAMIC CHIP			16V	D162		DIODE MA142WK				
C459	1-162-964-11	CERAMIC CHIP	0. 001uF	10%	50V	D163		DIODE MA142WK				
0400	1 100 0	ODDANIA CONT	0.01.5		F07/	D401	8-719-421-27					
C460		CERAMIC CHIP		100	50V	D402	8-719-027-50	DIODE MA142WK				
C461		CERAMIC CHIP		10%	25V	D 100	0 710 40: 15	DIADD MATE				
C462	1-162-964-11	CERAMIC CHIP	v. uvluf	10%	50V	D403	8-719-404-46	DIODE MAILO				

Ref. No.	Part No.	Description	Remark	Ref. No.	Part No.	Description		Remark
		< FILTER >		L162	1-412-280-31	INDUCTOR	330uH	
FL121	1-236-188-11	FILTER, BAND PASS		L163	1-410-167-41	INDUCTOR CHIP	820uH	
FL152	1-236-849-21	FILTER, BAND PASS		L164	1-410-657-21	INDUCTOR CHIP	180uH	
FL153	1-236-186-11	FILTER, BAND PASS		L169	1-410-392-11	INDUCTOR CHIP	82uH	
FL154	1-239-055-21	FILTER, LOW PASS (CCD, PAL, Y)		L170	1-410-381-11	INDUCTOR CHIP	10uH	
FL155	1-236-848-21	FILTER, LOW PASS		L171	1-410-384-31	INDUCTOR CHIP	18uH	
FL401	1-406-452-11	COIL, OSC		L175		INDUCTOR CHIP		
						INDUCTOR CHIP		
		< IC >		L177		INDUCTOR CHIP		
* * * * * * * * * * * * * * * * * * * *	0 ==0 000 00	TO OVALADOD				INDUCTOR CHIP		
	8-752-033-38			L179	1-410-379-31	INDUCTOR CHIP	6. 8uH	
	8-752-053-21			* 100	3 410 000 11	THE HOMOD AND	100 11	
	8-759-605-61			L180		INDUCTOR CHIP		
	8-752-065-54			L181		INDUCTOR CHIP		
IC152	8-752-065-56	IC CXA1208R		L182		INDUCTOR CHIP		
						INDUCTOR CHIP		
	8-752-333-24			L186	1-412-052-21	INDUCTOR CHIP	luH	
	8-752-053-21							
	8-759-055-82			L401		INDUCTOR CHIP		
	8-759-055-82			L402		INDUCTOR CHIP		
IC159	8-759-636-33	IC CXA1452N				INDUCTOR CHIP		
				L404		INDUCTOR CHIP		
	8-759-056-84			L405	1-412-058-11	INDUCTOR CHIP	10uH	
		IC CXP80624-428R						
		IC uPD75316GF-318-3B9		L406		INDUCTOR CHIP		
	8-759-059-42			L407	1-412-052-21	INDUCTOR CHIP	luH	
TC405	8-759-044-78	IC AK642UF				< LINK, IC >		
IC406	8-759-081-96	IC uPD6456GS-620						
IC407	8-759-145-63	IC uPD7564G-540		<b>⚠</b> PS401	1-576-122-21	LINK, IC (CCP2	2E10 O. 4A)	
IC408	8-759-057-60	IC MCD004BM		<b>⚠</b> PS402	1-576-123-21	LINK, IC (CCP2	2E20 O. 8A)	
		IC TL1596CDSB						
IC410	8-759-062-02	IC MPC1720VM				< TRANSISTOR >	>	
		< COIL >		<b></b> ∆Q001		TRANSISTOR 25/		
1.001	1 410 501 11	INDUCTOR OUTR 10 H		Q003		TRANSISTOR 2SI		
L001		INDUCTOR CHIP 10uH		Q008		TRANSISTOR 2SI		
L002		INDUCTOR CHIP 220uH		Q010		TRANSISTOR UNS		
L003		INDUCTOR CHIP 220uH		<b>∆</b> Q019	8-729-120-28	TRANSISTOR 2SO	C1623-L5L6	
LO05		INDUCTOR CHIP 22uH		A 0000	0 700 100 00	TDANCICTOD OC	31000 1510	
L007	1-412-058-11	INDUCTOR CHIP 10uH		<b></b> ∆Q020		TRANSISTOR 2SC		
1.000	1 410 650 01	INDUCTOR CHIR GOOD		Q021		TRANSISTOR 2SA		
L008		INDUCTOR CHIP 220uH		Q022		TRANSISTOR 2SE		
L009		INDUCTOR CHIP 8. 2uH		Q024		TRANSISTOR 2SC		
LO10		INDUCTOR CHIP 120uH		Q025	8-729-014-16	TRANSISTOR RN2	2302-TE85L	
L011	1-412-280-31			2000	0 700 400 10	TO ANOTOTOD OO	10104 D	
LO12	1-410-381-11	INDUCTOR CHIP 33uH		Q026		TRANSISTOR 2SI		
1010	1 410 007 01	INDUCTOR CUIT 190		Q121		TRANSISTOR UNS		
L013		INDUCTOR CHIP 180uH		Q123		TRANSISTOR UNS		
L015		INDUCTOR CHIP 10uH		Q124		TRANSISTOR UNS		
L121		INDUCTOR CHIP 10uH INDUCTOR CHIP 18uH		Q125	0-129-111-13	TRANSISTOR 2SC	.4118-114	
L150				0100	0 700 100 00	TOANCIOTOR COT	10104 D	
L152	1-410-385-11	INDUCTOR CHIP 22uH		Q126		TRANSISTOR 2SE		
1151	1 410 200 11	INDUCTOR CUID COU		Q151		TRANSISTOR 2SE		
L154		INDUCTOR CHIP 56uH		Q152		TRANSISTOR 2SD		
L155		INDUCTOR CHIP 56uH		Q154		TRANSISTOR 2SD		
L160		INDUCTOR CHIP 10uH		Q158	8-729-402-32	TRANSISTOR 2SD	01819A-K	
L161	1-410-385-11	INDUCTOR CHIP 22uH	I					

The components identified by mark  $\triangle$  or dotted line with mark  $\triangle$  are critical for safety.

Replace only with part number specified.

Ref. No.	Part No.	Description	Remark	Ref. No.	Part No.	Description			Remark
Q160	8-729-403-35	TRANSISTOR UN5113				< RESISTOR >			
Q161		TRANSISTOR 2SD1819A-R							
Q162		TRANSISTOR UN5113		R001	1-216-801-1	1 METAL CHIP	22	5%	1/16W
Q166		TRANSISTOR 2SB1218A-R		R002		1 METAL CHIP	560	5%	1/16W
Q168		TRANSISTOR UN5113		R002		1 METAL CHIP	330	5%	1/16W
ATOO	0 120 400 00	TRANSISTOR UNSITS		· R005		1 METAL CHIP	470		1/16W
0170	0 720 420 20	TRANSISTOR VNAS19				1 METAL CHIP			
Q170		TRANSISTOR XN4312		R006	1-210-031-1	I METAL CHIP	22K	5%	1/16W
Q171		TRANSISTOR 2SC4178-F14		B007	1 010 000 1	1 METAL CULD	2017	ΕN	1 /1 CW
Q174		TRANSISTOR 2SD1819A-R		R007		1 METAL CHIP	33K	5%	1/16W
Q175		TRANSISTOR 2SD1819A-R		R012		1 METAL CHIP	15K	5%	1/16W
Q176	8-729-402-32	TRANSISTOR 2SD1819A-R		R013	1-216-841-1		47K	5%	1/16W
				R016		1 METAL CHIP	22K	5%	1/16W
		TRANSISTOR 2SB1218A-R		R017	1-216-837-1	1 METAL CHIP	22K	5%	1/16W
Q178		TRANSISTOR 2SB1218A-R							
Q180		TRANSISTOR XN4215		R020		1 METAL CHIP	1.5K		1/16W
Q182	8-729-402-32	TRANSISTOR 2SD1819A-R		R021	1-216-836-1	1 METAL CHIP	18K	5%	1/16W
Q183	8-729-420-53	TRANSISTOR UN5115		R022	1-216-840-1	1 METAL CHIP	39K	5%	1/16W
				R023	1-216-838-1	1 METAL CHIP	27K	- 5%	1/16W
Q184	8-729-402-32	TRANSISTOR 2SD1819A-R		R024	1-216-838-1	1 METAL CHIP	27K	5%	1/16W
Q189	8-729-402-32	TRANSISTOR 2SD1819A-R							
Q191	8-729-402-32	TRANSISTOR 2SD1819A-R		R025	1-216-823-1	1 METAL CHIP	1.5K	5%	1/16W
Q192	8-729-402-32	TRANSISTOR 2SD1819A-R		R026		1 METAL CHIP	8. 2K		1/16W
0194		TRANSISTOR 2SD1819A-R		R027		1 METAL CHIP	47K		1/16W
Q.O.	0 100 100 00	Thundrollon Bobloton in		R028		1 METAL CHIP	22K		1/16W
Q195	8-729-402-55	TRANSISTOR 2SB1218A-R			1-216-824-1		1. 8K		1/16W
Q196		TRANSISTOR UN5113		11023	.1 210 024 1	I METAL CITT	1. 011	070	1/10#
Q199		TRANSISTOR 2SB1295-UL6		R030	1_916_937_1	1 METAL CHIP	22K	5%	1/16W
Q200		TRANSISTOR RN1302-TE85L		R031		1 METAL CHIP	4, 7K		1/16W
Q203		TRANSISTOR 2SB1218A-R		R033					
<b>Q</b> 203	0-129-402-55	N-WOLDING NOIGIGNANI				1 METAL CHIP 1 METAL CHIP	3. 3		1/16W
0004	0 700 400 00	TRANSFERON SCRIOLO D		R049			1. 8K		1/16W
Q204		TRANSISTOR 2SD1819A-R		R050	1-216-832-1	1 METAL CHIP	8. 2K	5%	1/16W
Q205		TRANSISTOR UN5213		2051					
Q207		TRANSISTOR UN5113		R051		1 METAL CHIP	6. 8K		1/16W
Q208		TRANSISTOR RN1302-TE85L		R052		1 METAL CHIP	1.5K		1/16W
Q210	8-729-402-42	TRANSISTOR UN5213		R054		1 METAL CHIP	470		1/16W
				R055	~	1 METAL CHIP	820	5%	1/16W
Q212		TRANSISTOR 2SB1218A-R		R056	1-216-864-1	1 METAL CHIP	0	5%	1/16W
Q214		TRANSISTOR XN4213							
Q219		TRANSISTOR 2SA1677		R057		1 METAL CHIP	560	5%	1/16₩
Q220		TRANSISTOR UN5212		R058		1 METAL CHIP	560	5%	1/16W
Q221	8-729-420-12	TRANSISTOR XN4213		R060	1-216-830-1	1 METAL CHIP	5. 6K	5%	1/16W
				R061	1-216-821-1	1 METAL CHIP	1K	5%	1/16W
Q222	8-729-402-32	TRANSISTOR 2SD1819A-R		R062	1-216-818-1	1 METAL CHIP	560	5%	1/16W
Q223		TRANSISTOR UN5213							
Q229		TRANSISTOR 2SB1218A-R		R063	1-216-830-1	1 METAL CHIP	5. 6K	5%	1/16W
Q230	8-729-402-32	TRANSISTOR 2SD1819A-R		R064		1 METAL CHIP	470	5%	1/16W
Q231	8-729-402-55	TRANSISTOR 2SB1218A-R		R065		1 METAL CHIP	4. 7K		1/16W
•				R066		1 METAL CHIP	100	5%	1/16W
Q232	8-729-402-32	TRANSISTOR 2SD1819A-R		R067		1 METAL CHIP	18K	5%	1/16W
Q233		TRANSISTOR 2SD1819A-R			000 1	VIIII	4011	0,0	2/ 200
Q234		TRANSISTOR 2SB1218A-R		R070	1-216-224-1	1 METAL CHIP	12K	5%	1/16W
Q236		TRANSISTOR UN511E		R071		1 METAL CHIP	1. 5K		1/16W
		TRANSISTOR 2SB1218A-R		R072		1 METAL CHIP	2. 7K		1/16W
4~01	0 120 420 00	THEOLOGICAL EGDILLON IN		R072		1 METAL CHIP	1. 8K		1/16W
Q401	8-720-102-10	TRANSISTOR UN521E		R078	1-216-831-1		1. on 6, 8K		
Q403		TRANSISTOR UN5113	i	1010	;1-610-031-1;	MEIND CHIL	u, on	3/6	1/16₩
Q405		TRANSISTOR RN1302-TE85L		D070	1-216-833-1	I METAL CUID	104	ΕØ	1 /1CW
Q409				R079			10K	5%	1/16W
Ø403	0-149-011-01	TRANSISTOR 2SB1574		R081		METAL CHIP	5. 6K		1/16W
				R082		METAL CHIP	39	5%	1/16W
			ا	R083	1-216-821-1	1 METAL CHIP	1K	5%	1/16₩

Ref. No.	Part No.	Description				Remark	Ref. No.	Part No.	Description			Remark
R085	1-216-821-11	METAL CHIP	1K	5%	1/16W		R191	1-216-864-11	METAL CHIP	0	5%	1/16₩
R086	1-216-817-11	METAL CHIP	470	5%	1/16W		R192	1-216-833-11	METAL CHIP	10K	5%	1/16W
R087	1-216-824-11		1. 8K		1/16W		R193	1-216-841-11	METAL CHIP	47K	5%	1/16W
R088	1-216-808-11		82	5%	1/16W		R194	1-216-833-1		10K	5%	1/16W
R090	1-216-836-11		18K	5%	1/16W		R195		METAL CHIP	680	5%	1/16W
R097	1-216-821-11		16K	5%	1/16W		R196	1-216-815-11		330	5%	1/16W
KUSI			1K	J/6	1/10#		11100					
R122	1-216-833-11	METAL CHIP	10K	5%	1/16W		R198		L METAL CHIP	470	5%	1/16W
R123	1-216-845-11	METAL CHIP	100K	5%	1/16W		R199	1-216-816-11	L METAL CHIP	390	5%	1/16W
R124	1-216-845-11		100K	5%	1/16₩		R200	1-216-821-13	METAL CHIP	1K	5%	1/16W
R125	1-216-845-11	METAL CHIP	100K	5%	1/16W		R201	1-216-815-13	METAL CHIP	330	5%	1/16W
R126	1-216-845-11	METAL CHIP	100K	5%	1/16W		R202	1-216-840-1	METAL CHIP	39K	5%	1/16W
R127	1-216-825-11	METAL CHIP	2. 2K	5%	1/16W		R203	1-216-837-1	METAL CHIP	22K	5%	1/16W
R129	1-216-845-11	METAL CHIP	100K	5%	1/16W		R204	1-216-821-1	L METAL CHIP	1K	5%	1/16W
R130	1-216-833-11	METAL CHIP	10K	5%	1/16W		R205	1-216-824-13	METAL CHIP	1.8K	5%	1/16W
R131	1-216-841-11	METAL CHIP	47K	5%	1/16W		R206	1-216-813-13	L METAL CHIP	220	5%	1/16W
R132	1-216-833-11		10K	5%	1/16W		R208	1-216-864-1	METAL CHIP	0	5%	1/16W
R133	1-216-827-11	METAL CHIP	3. 3K	5%	1/16W		R211	1-216-825-1	METAL CHIP	2. 2K	5%	1/16W
R134	1-216-833-11		10K	5%	1/16W		R213	1-216-835-13	L METAL CHIP	15K	5%	1/16W
R135	1-216-832-11	METAL CHIP	8. 2K	5%	1/16W		R216	1-216-837-13	L METAL CHIP	22K	5%	1/16W
R136	1-216-825-11		2. 2K	5%	1/16W		R217	1-216-837-1	METAL CHIP	22K	5%	1/16W
R137	1-216-821-11		1K	5%	1/16W		R218	1-216-824-1	I METAL CHIP	1.8K	5%	1/16W
R138	1-216-839-11	METAL CHIP	33K	5%	1/16W		R219	1-216-821-1	METAL CHIP	1K	5%	1/16W
R139	1-216-817-11		470	5%	1/16W		R220	1-216-811-13	METAL CHIP	150	5%	1/16W
R140	1-216-833-11		10K	5%	1/16W		R221		METAL CHIP	0	5%	1/16W
R141	1-216-821-11		1K	5%	1/16W		R222		METAL CHIP	6.8K	5%	1/16W
R142	1-216-825-11		2. 2K		1/16W		R223	1-216-835-1		15K	5%	1/16W
R143	1-216-839-11	METAL CHIP	33K	5%	1/16W		R224	1-216-825-1	METAL CHIP	2. 2K	5%	1/16W
R144	1-216-817-11		470	5%	1/16W		R226	1-216-819-1	L METAL CHIP	680	5%	1/16W
R145	1-216-837-11		22K	5%	1/16W		R228	1-216-813-1		220	5%	1/16W
R146	1-216-821-11		1K	5%	1/16W		R230		METAL CHIP	68	5%	1/16W
R150	1-216-864-11		0	5%	1/16W		R231	1-216-821-1		1K	5%	1/16W
R151	1-216-296-00	METAL CHIP	0	5%	1/8W		R232	1-216-833-1	METAL CHIP	10K	5%	1/16W
R152	1-216-830-11		5. 6K		1/16W		R238	1-216-821-1		1K	5%	1/16W
R153	1-216-304-11		3. 3	5%	1/10W		R234		METAL CHIP	0	5%	1/16W
R154	1-216-820-11		820	5%	1/16W		R242		METAL CHIP	560	5%	1/16W
R155	1-216-836-11		18K		1/16₩			1-216-809-11		100		1/16W
R156	1-216-296-00	METAL CHIP	0	5%	1/8W		R244	1-216-835-11	METAL CHIP	15K	5%	1/16W
R158	1-216-829-11		4. 7K	5%	1/16W		R245	1-216-817-11		470	5%	1/16W
R160	1-216-819-11		680	5%	1/16₩		R246	1-216-817-11		470	5%	1/16W
R161	1-216-809-11		100	5%	1/16₩		R247	1-216-296-00		0	5%	1/8₩
R164	1-216-811-11		150	5%	1/16W		R248	1-216-825-11		2. 2K	5%	1/16W
K104			130	J/0	1/10#		11240			2. 2h	0/0	
R167	1-216-820-11	METAL CHIP	820	5%	1/16W		R250	1-216-810-11		120	5%	1/16W
R168	1-216-820-11	METAL CHIP	820	5%	1/16W		R251	1-216-806-11	METAL CHIP	56	5%	1/16W
R170	1-216-822-11	METAL CHIP	1. 2K	5%	1/16W		R253	1-216-821-11	METAL CHIP	1K	5%	1/16W
R175	1-216-810-11		120	5%	1/16W		R254	1-216-818-11	METAL CHIP	560	5%	1/16W
R177	1-216-819-11		680	5%	1/16W		R255	1-216-833-11	METAL CHIP	10K	5%	1/16W
R178	1-216-817-11	METAL CHIP	470	5%	1/16W		R256	1-216-864-11	METAL CHIP	0	5%	1/16W
R179	1-216-820-11		820	5%	1/16W		R257	1-216-818-11	METAL CHIP	560	5%	1/16W
R189	1-216-828-11		3.9K	5%	1/16W		R258	1-216-821-11	METAL CHIP	1K	5%	1/16W
R190	1-216-837-11		22K	5%	1/16₩		R259	1-216-816-11	METAL CHIP	390	5%	1/16W

Ref. No.	Part No.	Description			F	Remark	Ref. No.	Part No.	Description			Rema	ark_
R260	1-216-825-11	METAL CHIP	2. 2K	5%	1/16W		R335	1-216-821-11	METAL CHIP	1K	5%	1/16W	
R263	1-216-864-11	METAL CHIP	0	5%	1/16W		R337	1-216-864-11	METAL CHIP	0	5%	1/16W	
R266	1-216-864-11		0	5%	1/16W		R339	1-216-825-11		2. 2K		1/16W	
R267	1-216-864-11		0	5%	1/16W		R341	1-216-841-11		47K	5%	1/16W	
				5%	1/16W		R342	1-216-829-11		4. 7K		1/16W	
R270	1-216-864-11		0 47V							33K		1/16W	
R271	1-216-841-11	METAL CHIP	47K	5%	1/16W		R343	1-216-839-11	METAL CHIP	SSN	5%	1/10#	
R272	1-216-829-11	METAL CHIP	4.7K	5%	1/16₩		R344	1-216-825-11	METAL CHIP	2. 2K	5%	1/16W	
R276	1-216-822-11	METAL CHIP	1. 2K	5%	1/16₩		R345	1-216-827-11	METAL CHIP	3. 3K	5%	1/16W	
R277	1-216-823-11	METAL CHIP	1.5K	5%	1/16W		R346	1-216-845-11	METAL CHIP	100K	5%	1/16W	
R278	1-216-825-11	METAL CHIP	2. 2K	5%	1/16W		R347	1-216-823-11	METAL CHIP	1.5K	5%	1/16W	
R279	1-216-818-11	METAL CHIP	560	. 5%	1/16W		R349	1-216-834-11	METAL CHIP	12K	5%	1/16W	
R280	1-216-827-11	METAL CHIP	3. 3K	5%	1/16W		R350	1-216-838-11	METAL CHIP	27K	. 5%	1/16W	
R281	1-216-823-11	METAL CHIP	1. 5K	5%	1/16W		R352	1-216-864-11	METAL CHIP	0	5%	1/16₩	
R282	1-216-829-11	METAL CHIP	4.7K	5%	1/16W		R353	1-216-864-11	METAL CHIP	0	5%	1/16W	
R283	1-216-821-11	METAL CHIP	1K	5%	1/16W		R357	1-216-830-11	METAL CHIP	5. 6K	5%	1/16W	
R285	1-216-833-11	METAL CHIP	10K	5%	1/16W		R358	1-216-828-11	METAL CHIP	3. 9K	5%	1/16W	
R286	1-216-833-11	METAL CHIP	10K	5%	1/16W		R359	1-216-296-00	METAL CHIP	0	5%	1/8W	
R290	1-216-821-11		1K	5%	1/16W		R360	1-216-296-00		0	5%	1/8W	
R290	1-216-821-11		820	5%	1/16W		R361	1-216-864-11		0	5%	1/0W	
R293			68	5%	1/16W		R362	1-216-810-11		120	5%	1/16W	
	1-216-807-11		100K		1/16₩		R366	1-216-844-11		82K	5%	1/16W	
R294	1-216-845-11	MEIAL CHIP	100%	3/0	1/10#		пооо	1-210-044-11	METAL CHIF	02 <b>n</b>	3/0	1/10#	
R295	1-216-853-11	METAL CHIP	470K	5%	1/16W		R371	1-216-857-11		1M	5%	1/16W	
R297	1-216-820-11	METAL CHIP	820	5%	1/16W		R373	1-216-817-11	METAL CHIP	470	5%	1/16W	
R298	1-216-820-11	METAL CHIP	820	5%	1/16\		R374	1-216-826-11	METAL CHIP	2. 7K	5%	1/16W	
R299	1-216-829-11	METAL CHIP	4.7K	5%	1/16W		R375	1-216-825-11	METAL CHIP	2. 2K	5%	1/16W	
R300	1-216-822-11	METAL CHIP	1. 2K	5%	1/16W		R376	1-216-817-11	METAL CHIP	470	5%	1/16W	
R301	1-216-827-11	METAL CHIP	3. 3K	5%	1/16₩		R377	1-216-821-11	METAL CHIP	1K	5%	1/16W	
R302	1-216-827-11		3. 3K		1/16W		R378	1-216-825-11		2. 2K		1/16W	
R303	1-216-846-11		120K		1/16W		R379	1-216-821-11		1K	5%	1/16W	
R304	1-216-829-11		4. 7K		1/16W		R380	1-216-839-11		33K	5%	1/16W	
R305	1-216-818-11		560	5%	1/16W		R381	1-216-839-11		33K	5%	1/16W	
1.303	1-210-010-11	METAL CHI	300	570	1/10#		1,001			Jok		1/10#	
R306	1-216-821-11		1K	5%	1/16W		R382	1-216-842-11		56K	5%	1/16W	
R307	1-216-821-11	METAL CHIP	1K	5%	1/16W		R383	1-216-821-11	METAL CHIP	1K	5%	1/16₩	
R308	1-216-819-11	METAL CHIP	680	5%	1/16W		R384	1-216-825-11	METAL CHIP	2. 2K	5%	1/16W	
R309	1-216-826-11		2. 7K		1/16\		R385	1-216-825-11		2. 2K		1/16W	
R310	1-216-848-11	METAL CHIP	180K	5%	1/16W		R386	1-216-842-11	METAL CHIP	56K	5%	1/16₩	
R311	1-216-829-11	METAL CHIP	4. 7K	5%	1/16W		R387	1-216-821-11	METAL CHIP	1K	5%	1/16W	
R312	1-216-829-11	METAL CHIP	4.7K	5%	1/16W		R388	1-216-825-11	METAL CHIP	2. 2K	5%	1/16W	
R314	1-216-829-11		4.7K		1/16W		R389	1-216-821-11	METAL CHIP	1K	5%	1/16W	
R315	1-216-833-11		10K	5%	1/16W		R390	1-216-825-11		2. 2K		1/16W	
R316	1-216-817-11		470	5%	1/16W		R391	1-216-825-11	METAL CHIP	2. 2K		1/16W	
DOYO			1.027	CA'	1 /4 0 ***		DOCA						
R318	1-216-833-11		10K	5%	1/16₩		R392	1-216-837-11		22K	5%	1/16W	
R321	1-216-816-11		390	5%	1/16W		R393	1-216-833-11		10K	5%	1/16W	
R323	1-216-825-11		2. 2K	5%	1/16W		R394	1-216-841-11		47K	5%	1/16W	
R324	1-216-817-11		470	5%	1/16₩		R397	1-216-820-11		820	5%	1/16₩	
R325	1-216-816-11	METAL CHIP	390	5%	1/16W		R398	1-216-829-11	METAL CHIP	4. 7K	5%	1/16W	
R329	1-216-824-11	METAL CHIP	1. 8K	5%	1/16W		R401	1-216-827-11	METAL CHIP	3. 3K	5%	1/16W	
R331	1-216-824-11		1. 8K		1/16W	}	R403	1-216-845-11		100K		1/16W	
R333	1-216-822-11		1. 2K		1/16W		R404	1-216-826-11		2. 7K		1/16W	
R334	1-216-833-11		10K	5%	1/16W		R405	1-216-821-11		1K	5%	1/16W	
	_ === 000 11			2	2, 2011		100	001 11		***	-,-	_,	

Ref. No.	Part No.	Description				Remark	Ref. No.	Part No.	Description	<u>on</u>			<u> i</u>	Remark
R406	1-216-809-11	METAL CHIP	100	5%	1/16W		R463	1-216-827-11	METAL CHI	P	3.3K	5%	1/16W	
R407	1-216-821-11	METAL CHIP	1K	5%	1/16W		R468	1-216-039-00	METAL CHI	P	390	5%	1/10W	
R408	1-216-833-11		10K	5%	1/16W		R469	1-216-838-11	METAL CHI	P	27K	5%	1/16W	
R409	1-216-841-11		47K	5%	1/16W		R470	1-216-838-11			27K	5%	1/16W	
R410	1-216-821-11		1K	5%	1/16W		R471	1-216-838-11			27K	5%	1/16W	
R411	1-216-821-11		1K	5%	1/16W		R472	1-216-833-11			10K	5%	1/16W	
	1 010 001 11		***		.,					•		0.0	2/ 2011	
R412	1-216-841-11	METAL CHIP	47K	5%	1/16W		R473	1-216-833-11	METAL CHI	P	10K	5%	1/16W	
R413	1-216-821-11		1K	5%	1/16W		R474	1-217-671-11			1	5%	1/10W	
R414	1-216-821-11		1K	5%	1/16W		R475	1-217-671-11			1	5%	1/10W	
R415	1-216-821-11		1K	5%	1/16W		R476	1-216-826-11	METAL CHI	P	2.7K	5%	1/16W	
R416	1-216-821-11		1K	5%	1/16W		R479	1-216-845-11			100K		1/16W	
R417	1-216-833-11	METAL CHIP	10K	5%	1/16W		R480	1-217-671-11	METAL CHI	P	1	5%	1/10W	
R418	1-216-829-11	METAL CHIP	4.7K	5%	1/16W		R481	1-217-671-11	METAL CHI	P	1	5%	1/10W	
R419	1-216-845-11	METAL CHIP	100K	5%	1/16W		R484	1-216-845-11	METAL CHI	P	100K	5%	1/16W	
R420	1-216-856-11	METAL CHIP	820K	5%	1/16W		R485	1-216-845-11	METAL CHI	P	100K	5%	1/16W	
R421	1-216-851-11	METAL CHIP	330K	5%	1/16W		R487	1-216-864-11	METAL CHI	P	0	5%	1/16W	
R422	1-216-829-11	METAL CHIP	4.7K	5%	1/16W		R488	1-216-809-11	METAL CHI	P	100	5%	1/16₩	
R423	1-216-837-11	METAL CHIP	22K	5%	1/16W		R489	1-216-831-11	METAL CHI	P	6.8K	5%	1/16W	
R424	1-216-845-11	METAL CHIP	100K	5%	1/16W		R490	1-216-833-11	METAL CHI	P	10K	5%	1/16W	
R425	1-216-849-11	METAL CHIP	220K		1/16W		R491	1-216-296-00	METAL CHI	P	0	5%	1/8W	
R426	1-216-856-11	METAL CHIP	820K	5%	1/16W		R492	1-216-864-11	METAL CHI	P	0	5%	1/16W	
R427	1-216-833-11		10K	5%	1/16W		R493	1-216-864-11	METAL CHI	P	0	5%	1/16W	
R428	1-216-833-11		10K	5%	1/16W									
R429	1-216-821-11		1K	5%	1/16W				< THERMIS	TOR >				
R430	1-216-851-11		330K		1/16₩									
R431	1-216-841-11	METAL CHIP	47K	5%	1/16W			1-809-358-21			•			
R432	1-216-833-11	METAL CHID	10K	5%	1/16W		R113	1-809-358-21	INERWISIO	K, NIC	(2125)	) 500	J	
R432	1-216-821-11		16K	5%	1/16₩				< NETWORK	DEC V				
R435	1-216-821-11		1K	5%	1/16W				\ NEIWORK	, RES /	,			
R436	1-216-864-11		0	5%	1/16W		RR#∩1	1-236-442-11	NETWORK	BEC 330	NV.			
R437	1-216-817-11		470	5%	1/16W			1-236-907-11	-			PF) 1	100K	
11401	1 210 011 11	MEINE CHII	470	570	1/10#			1-236-907-11						
R438	1-216-841-11	METAL CHIP	47K	5%	1/16₩			1-236-908-11						
R439	1-216-864-11		0	5%	1/16W			1-236-436-11				(L)	LOIL	
R441	1-216-864-11		0	5%	1/16W		ND400	1 230 430 11	WEI WORK,	ILLO 100	ın.			
R442	1-216-864-11		0	5%	1/16W		RR406	1-236-908-11	NETWORK	RES (CH	IIP TVI	PE) 1	I OK	
R443	1-216-845-11		100K		1/16W			1-236-907-11						
11710	2 210 010 11	marina Olli	20011	0.10	1, 101			1-236-908-11						
R445	1-216-837-11	METAL CHIP	22K	5%	1/16W	l		1-236-904-11						
R447	1-216-864-11		0	5%	1/16W			1-236-412-11					011	
R448	1-216-809-11		100	5%	1/16W						••			
R449	1-216-845-11		100K	5%	1/16W		RB411	1-236-424-11	NETWORK.	RES 10K				
R450	1-216-833-11	METAL CHIP	10K	5%	1/16W	- 1		1-236-904-11	•			PE) 1	l. 0K	
								1-236-412-11						
R451	1-216-841-11	METAL CHIP	47K	5%	1/16W			1-236-408-11						
R452	1-216-833-11		10K	5%	1/16W			1-236-412-11						
R453	1-216-841-11	METAL CHIP	47K	5%	1/16₩									
R454	1-216-825-11	METAL CHIP	2. 2K	5%	1/16₩		RB420	1-236-904-11	NETWORK, I	RES (CH	IP TY	PE) 1	1. OK	
R456	1-216-833-11	METAL CHIP	10K	5%	1/16W			1-236-908-11	-	•				
						1		1-236-424-11						
R457	1-216-837-11	METAL CHIP	22K	5%	1/16W		RB423	1-236-424-11	NETWORK, 1	RES 10K				
R460	1-216-864-11	METAL CHIP	0	5%	1/16W	ļ	RB424	1-236-424-11	NETWORK, H	RES 10K				
R461	1-216-845-11	METAL CHIP	100K	5%	1/16W	[								
R462	1-216-809-11	METAL CHIP	100	5%	1/16W	- 1	RB425	1-236-424-11	NETWORK, I	RES 10K				

Ref. No.	Part No.	Description	Remark	Ref. No.	Part No.	Description	Remark
RB426	1-236-412-11	NETWORK, RES 1.0K		į		ES & PACKING MATERIALS	
		< VARIABLE RESISTOR >			A-6767-706-	A RFU ADAPTOR (RFU-89EA) (E)	*
RV151	1-238-087-11	RES, ADJ, CERMET 1K			A-6768-254-	A RFU ADAPTOR (RFU-89EA) (UK) A RFU ADAPTOR (RFU-90E) (AEP)	
₩001	1-696-489-11	<pre>&lt; FLEXIBLE BOARD &gt; FP-588 FLEXIBLE BOARD</pre>				A RFU ADAPTOR (RFU-90AS) (Austra) 1 REMOTE COMMANDER (CAM CODER) (F	
₩405		FP-572 FLEXIBLE BOARD				1 SWITCH, ANTENNA CHANGE (CABLE) 1 SCREWDRIVER (UK, E)	(UK, E)
	1	< CRYSTAL >		*	3-756-470-4	1 INSTRUCTION 1 MANUAL, OPERATION (ENGLISH) (AE	EP, UK)
X151 X401 X402	1-579-063-21	VIBRATOR, CRYSTAL (4. 43MHz) VIBRATOR, CERAMIC (4. 19MHz) VIBRATOR, CRYSTAL (32kHz)			3-756-470-5	1 MANUAL, OPERATION (FRENCH, GERMAN, SPANI	ISH) (AEP)
	1-579-368-31	VIBRATOR, CRYSTAL (11.719MHz) VIBRATOR, CERAMIC (700kHz)			3-756-470-6	1 MANUAL, OPERATION (SWEDISH, DUTCH, ITALI	(AEP)
******	******	********	******			* *	ustralian)
		MISCELLANEOUS ************				1 MANUAL, OPERATION (FRENCH, GERMAN, SPA 1 MANUAL, OPERATION (ARABIC) (E)	ANISH) (E)
14		CABLE, FLAT (FFC-90)			3-756-471-9	1 MANUAL, OPERATION (CHINISE) (E)	I
18 80 106	1-692-257-11	MICROPHONE UNIT SWITCH, PUSH (ZOOM) FILTER BLOCK, OPTICAL		*	3-943-154-11	1 BELT, SHOULDER 1 HOLDER (B), REMOTE CONTROL 1 CUSHION (LOWER)	
108		LENS, ZOOM (VCL-6210WC)		*	3-949-006-51	1 INDIVIDUAL CARTON 1 CUSHION, ACC	
IC875	A-7030-369-A	TUBE, FLUORESCENT CCD BLOCK ASSY (ICX055AK-2) (CCD	IMAGER)	**	AC-V25	AC POWER ADAPTOR	
LCD901	1-810-046-11	HOLDER, BATTERY DISPLAY MODULE, LIQUID CRYSTAL DRUM ASSY (DGH-90A-R)		*** Note **	NP-55 MARK PARTS 1	BATTERY PACK  IS AVAILABLE FOR REPAIR SERVICE.	
M902		MOTOR, DC SCE-0101A (CAPSTAN)		***	MARK PARTS 1	IS AVAILABLE AS AN OPTIONAL ACCES	SORY.
M903 M904 M905	3-708-494-01	MOTOR BLOCK ASSY, LM (LOADING) METER ASSY, IG (IRIS) MOTOR ASSY, STEPPING (FOCUS)					
M906	3-708-492-01	MOTOR ASSY, PZ (ZOOM)					
⚠PS901 ⚠PS902 S001	1-532-841-21	LINK, IC 1.6A/90V LINK, IC 1.6A/90V SWITCH, ROTARY (ENCODER)					
	1-572-987-11	SWITCH, PUSH (3 KEY) SWITCH (C DOWN)					
₩517 ₩519		CABLE, FLAT (FFC-85) CABLE, FLAT (FFC-92)					
W971	1-696-484-11	CABLE, FLAT (FFC-87) CABLE, FLAT (FFC-86)					
*******	*******	***************************************	****				

The components identified by mark  $\triangle$  or dotted line with mark  $\triangle$  are critical for safety.

Replace only with part number specified.



# SECTION 7 CAMERA SECTION ADJUSTMENTS

When performing adjustments, refer to the layout diagrams for adjustment related parts beginning from page 80.

### 7-1. PREPARATIONS BEFORE ADJUSTMENT (CAMERA SECTION)

#### 7-1-1. List of Service Tools

- Oscilloscope
- Stabilized power supply
- Vectorscope

- Adjusting driver
- Color monitor
- Digital voltmeter

Ref. No.	Name	Part Code	Usage
J-1	Filter for color temperature correction (C14)	J-6080-058-A	Auto white balance adjustment/check White balance adjustment/check
J-2	ND filter 1.0	J-6080-808-A	Max gain adjustment (2 used) White balance check
	ND filter 0.4	J-6080-806-A	Max gain adjustment
	ND filter 0.3	J-6080-818-A	White balance adjustment
	ND filter 0.1	J-6080-807-A	Max gain adjustment
J-3	Pattern box PTB-500	J-6029-140-A	
J-4	Color chart for pattern box	J-6020-250-A	
J-5	Adjusting remote control unit (RM-95-remodeled in part) <sup>NOBE 1</sup>	J-6082-053-B	
J-6	Extension cord (10P, 1 mm)	J-6082-064-A	For extension of JK-91 board
<b>J</b> -7	Extension cord (20P, 0.8 mm)	J-6082-196-A	For extension of CN-65 board (Cabinet (R)) (For the video and the camera section adjustment) For extension of AU-138 board (During the repair of AU-138 board)
J-8	Extension cord (16P, 0.8 mm)	J-6082-136-A	For the extension of the lens block (During the repair of the camera section)
<b>J-</b> 9	Relay board (21P, 0.5 mm) <sup>Note 2</sup>	J-6082-176-A	For the extension of the lens block (During the repair of the camera section)
J-10	Measuring pin for camera section	J-6082-139-A	For the camera section adjustment
J-11	Extension cord (42P, 0.8 mm)	J-6082-195-A	For the extension of DD-48 board (During the repair of the video section)
J-12	Siemens star	J-6080-875-A	For flange back check
J-13	Extension cord (20P, 0.5 mm) <sup>Note 2</sup>	J-6082-138-A	For extension between the lens block (FPC) a VC-122 board (CN851) (During the repair of the camera section)
J-14	Extension board (30P, 0.8 mm)	J-6082-167-A	For the extension of VS-95 board (For the mecha deck check)
J-15	Extension cord (6P, 1.5 mm)	J-6082-152-A	For extension (6P, 1.5 mm) between the main bo (CN102 of the VS-95 board) and the viewfind (CN902 of the CL-29 board)
J-16	Extension cord (10P, 0.8 mm)	J-6082-150-A	For extension (10P, 0.8 mm) between the CL-board (CN901) and the IV-10 board (CN101)
J-17	Measuring pin for viewfinder section	J-6082-151-A	Almost all the points to be measured when adjustithe viewfinder are concentrated in CN904 of CL-29 board

- Note 1: If the micro processor IC in the adjusting remote control unit is not the new micro processor (UPD7503G-C56-12), the switchover of the page cannot be carried out. In this case, replace with the new micro processor (8-759-148-35).
- Note 2: The extension code (J-6082-138-A) is also attached with a 21P, 0.5 mm code. Connect this code to the relay board (J-6082-176-A) for extensions between the lens block (FPC) and VC-122 board (CN851).
- Note 3: The back light (fluorescent tube) is driven by a 600 Vp-p, 16 kHz AC power supply.

  Therefore, be careful not to touch the back light holder as you may receive an electric shock.
- Note 4: Pay special attention that damages by static electricity do not occur when replacing the LCD unit.




Fig. 7-1.

## 7-1-2. Preparations

**Note:** For further details on how to remove the cabinet and each board, refer to "2. Disassembly".

- 1) Connect the equipments for adjustment as shown in Fig. 7-3.
- The EVF (Electronic viewfinder) is required for checking the white balance mode and shutter speeds. If the EVF is not required, remove the VS-95 board CN102.




Fig. 7-2.




Fig. 7-3.

## 7-3. ELECTRONIC VIEWFINDER SYSTEM ADJUSTMENTS

## [Positions of RVs during adjustment]

Unless specified otherwise, position each RV as follows, and adjust.

RV901 (BRIGHT) ····· Refer to "BRIGHT Preset Adjustment" RV903 (COLOR) ····· Mechanical center




Fig. 7-20.

## [Power supply voltage]

Adjust the power supply voltage to the battery terminal so that Pin ① of CN902 of the CL-29 board (EVF UNREG) becomes  $6.0\pm0.1$  Vdc.

### [Video input signal for adjustment]

When the signal column indicates "color bar signal turning off chroma and burst signals", input the color bar signal turning off the chroma and burst signals to the video input terminal as the video input signal for adjustment. In addition, check that the signal level of Pin  $\odot$  of CN902 of the CL-29 board is  $0.9 \pm 0.12$  Vp-p before adjusting.




Fig. 7-21. Color bar signal turning off chroma and burst signals

### 1. Current Consumption Adjustment (IV-10 Board)

Mode	E-E (VTR POWER ON)
Signal	Color bar signal turning off the chroma and burst signals
Measurement Point	Measure after removing L901 of the CL-29 board +: Pin ① of CN902 -: Pin ① of CN901
Measuring Instrument	Ampere meter
Adjustment Element	RV102
Specified Value	145 ± 3 mA

**Note 1:** Adjust within 30 seconds after turning on the power supply.

Note 2: After adjusting, connect L901 of the CL-29 board.

### Adjusting method:

- 1) Check that the voltage of Pin ① of CN901 of the CL-29 board ( $\pm$  terminal of C907) is 6.0  $\pm$  0.1 Vdc.
- 2) Adjust the current consumption to 145  $\pm$  3 mA with RV102.




Fig. 7-22.

## 2. -8V Power Supply Adjustment (IV-10 Board)

Mode	E-E (VTR POWER ON)
Measuring Instrument	Digital voltmeter
Measurement Point	Pin ⑤ of CN904 of the CL-29 board (-8V)
Adjustment Element	RV101
Specified Value	-8.03 ± 0.03 Vdc

## Adjusting method:

- Check that the UNREG power supply voltage (Pin 1) of CN902 of the CL-29 board) is 6.0 ± 0.1 Vdc.
- Adjust the -8V power supply voltage to the specified value with RV101.

## 3. Power Supply Voltage Check (CL-29 Board)

E-E (VTR POWER ON)
Digital voltmeter
Pin ⑥ of CN904 (-3V)
$-3.11 \pm 0.15 \mathrm{Vdc}$
Pin ④ of CN904 (9V)
8.53 ± 0.4 Vdc

## Checking method:

- 1) Check that the UNREG power supply voltage (Pin ① of CN902) is 6.0+-0.1 Vdc.
- Check that each power supply voltage satisfies the specified value.

## 4. LC COM Voltage Check (CL-29 Board)

Modé	E-E (VTR POWER ON)
Measurement Point	Pin ① of CN904 (LC COM)
Measuring Instrument	Digital voltmeter
Specified Value	$-2.97 \pm 0.15 \mathrm{Vdc}$

## Checking method:

- 1) Check that the UNREG power supply voltage (Pin ① of CN902) is  $6.0 \pm 0.1$  Vdc.
- 2) Check that the LC COM voltage satisfies the specified value.

## 5. VCO Adjustment (CL-29 Board)

Mode	E-E (VTR POWER ON)
Signal	Color bar turning off the chroma and burst signals
Measurement Point	Pin (10) of CN904 (PCO)
Measuring Instrument	Oscilloscope (DC range)
Adjustment Element	RV905
Specified Value	$A=-5.8 \pm 0.1 V$

## Adjusting method

- 1) Check the GND level of the oscilloscope
- Adjust the PCO voltage (A) to the specified value with RV905.




Fig. 7-23.

## 6. BRIGHT Preset Adjustment (CL-29 Board)

Mode	E-E (VTR POWER ON)
Signal	Color bar turning off the chroma and burst signals
Measurement Point	Pin ③ of CN904 (G OUT)
Measuring Instrument	Oscilloscope
Adjustment Element	RV901
Specified Value	$A=6.0 \pm 0.1 V$

## Adjusting method:

 Adjust the potential difference (A) between the reversed waveform pedestal and non-reversed one to the specified value.




Fig. 7-24.

## 7. CONTRAST Adjustment (CL-29 Board)

Mode	E-E (VTR POWER ON)
Signal	Color bar turning off the chroma and burst signals
Measurement Point	Pin ③ of CN904 (G OUT)
Measuring Instrument	Oscilloscope
Adjustment Element	RV902
Specified Value	A=2.1 ± 0.1V

## Adjusting method:

1) Adjust the 100% white level (A) to the specified value with RV902.




Fig. 7-25.

## 8. SUB CONT R Adjustment (CL-29 Board)

Mode	E-E (VTR POWER ON)
Signal	Color bar turning off the chroma and burst signals
Measurement Point	Pin ⑦ of CN904 (R OUT)
Measuring Instrument	Oscilloscope
Adjustment Element	RV906
Specified Value	A=2.1 ± 0.1V

## Adjusting method:

1) Adjust the 100% white level (A) to the specified value with RV906.




Fig. 7-26.

## 9. SUB CONT B Adjustment (CL-29 Board)

Mode	E-E (VTR POWER ON)
Signal	Color bar turning off the chroma and burst signals
Measurement Point	Pin ® of CN904 (B OUT)
Measuring Instrument	Oscilloscope
Adjustment Element	RV907
Specified Value	A=2.1 ± 0.1V

## Adjusting method:

1) Adjust the 100% white level (A) to the specified value with RV907.




Fig. 7-27.

## **CCD-TR303E/TR303EP**

**SERVICE MANUAL** 



Australian

Model Model Model

Model

Video8 Handycam

A MECHANISM

CCD-TR303EP is a model that soft carrying case is added in CCD-TR303E. CCD-TR303EP and CCD-TR303E have different packing material, etc.

For MECHANISM ADJUSTMENTS, refer to the "8 mm Video MECHANICAL ADJUSTMENT MANUAL IV" (9-973-199-11).

### **SPECIFICATIONS**

### System

is only avaiable.

Video recording system

Two rotary heads, Helical scanning FM system

Audio recording system

Two rotary heads, Helical scanning FM system

Video signal

PAL colour, CCIR standards Usable cassette 8 mm video format cassette SP mode: Approx. 20.051 mm Tape speed (13/16 inch)/s

LP mode: Approx. 10.058 mm (13/32 inch)/s SP mode: 1 h and 30 min (P5-90)

Recording time

LP mode: 3 h (P5-90) SP mode: 1 h and 30 min

Playback time

Image device

Viewfinder

(E5/P5-90) LP mode: 3 h (P5-90)

Fast-forward/rewind time

Approx. 8.5 min (E5/P5-90) CCD (Charge Coupled Device) Electronic viewfinder (black and

Lens

Combined 10 x power zoom lens f = 6.2 to 62 mm (1/4 to 2 1/2

inches) F 1.6 to F 2.9

(45 to 450 mm (1 13/16 to 17 5/8 inches) when converted to a 35-mm still camera) Filter diameter 37 mm (1 1/2

inches)

Autofocus sytem

TTL autofocus system

inner focus wide macro system

Colour temperature

**Automatic** 

Phono iack

Minimum illumination 1 lx (F 1.6)

Illumination range

1 lx to 100,000 lx

(0.2 to 9,290 footcandles)

Recommended illumination

More than 100 lx (9.3 footcandles)

### **Output connector**

Video output

Phono jack, 1 Vp-p, 75 Ω unbalanced sync negative

Audio output

-7.5 dBs (at impedance 47 kΩ)

impedance less than 2.2 kΩ

RFU DC OUT ♣ Remote jack

MIC jack

Special minijack, DC 5 V Stereo mini-minijack (ø2.5 mm) Minijack, -66 dBs, low impedance

with 2.5-3 V DC output,

impedance 6.8 kΩ

- Continued on next page -





### General

Power requirements

On battery mounting surface

6.0 V (battery pack) 7.5 V (AC power adaptor) 9.0 V (alkaline batteries)

Average power consumption

5.3 W (camera recording) including the viewfinder

Installation

Vertically, Horizontally

Operating temperature

0 °C to 40 °C (32 °F to 104 °F)

Storage temperature

-20 °C to +60 °C (-4 °F to

+140 °F)

Dimensions Approx.  $109 \times 109 \times 178 \text{ mm (w/h/d)}$ 

(4.3/8×4.3

(4 3/8 × 4 3/8 × 7 1/8 inches) Approx. 770 g (1 lb 11 oz)

excluding the battery pack, lithium battery, cassette, and shoulder

strap

Approx. 1,000 g (2 lb 3 oz) including the battery pack NP-55,

lithium battery CR2025, cassette P5-90, and shoulder strap


Microphone

Weight

Electret condenser microphone,

manaural type

Supplied accessories



## SAFETY CHECK-OUT

After correcting the original service problem, perform the following safety checks before releasing the set to the customer:

- Check the area of your repair for unsoldered or poorly-soldered connections. Check the entire board surface for solder splashes and bridges.
- 2. Check the interboard wiring to ensure that no wires are "pinched" or contact high-wattage resistors.
- Look for unauthorized replacement parts, particularly transistors, that were installed during a previous repair. Point them out to the customer and recommend their replacement.
- Look for parts which, though functioning, show obvious signs of deterioration. Point them out to the customer and recommend their replacement.
- Check the B+ voltage to see it is at the values specified.

### **SAFETY-RELATED COMPONENT WARNING!!**

COMPONENTS IDENTIFIED BY MARK A OR DOTTED LINE WITH MARK ON THE SCHEMATIC DIAGRAMS AND IN THE PARTS LIST ARE CRITICAL TO SAFE OPERATION. REPLACE THESE COMPONENTS WITH SONY PARTS WHOSE PART NUMBERS APPEAR AS SHOWN IN THIS MANUAL OR IN SUPPLEMENTS PUBLISHED BY SONY.

## **TABLE OF CONTENTS**

Sect	<u>ion</u>	<u>Title</u>	Page	Sect	<u>ion</u>	<u>Title</u>	Page
SER	VICE NOTE			3-5.	Camer	a (2) Block Diagram·····	39
				3-6.	Video (	1) Block Diagram ······	41
Semi	conductor for Correcti	on List Display ·····	6	3-7.		2) Block Diagram ······	
		elated to Power Supply ······		3-8.		llock Diagram·····	
				3-9.		Control Block Diagram ······	
					•	nism Control Microprocessor Pin Function	
	Clouming		-	•		on VS-95 Board: CXP80624)	55
				3-11		control Microprocessor Pin Function	-
1.	GENERAL			J-11.		on VS-95 Board: µPD75316) ······	58
٠.	CENTIAL			2-12	•	e ······	
المسامل	fring the Davis		7			em Control – Video/Audio Block Interface	00
		ries ·····		3-12		95 Board) ······	60
Osser	ang the Lithium Batter	nes ·····	9	0.10		•	
Conn	ecting the Power Sou	rces·····	10			em Control – Servo Block Interface ········	
Settir	ig the Date and Time	******************************	12			lock Diagram ······	
		***************************************				ock Diagram·····	
Adjus	ting the Viewfinder Le	ens	13	3-15.	Power	Block Diagram ······	69
		]					
		Automatic Adjustments ······					
				4.	PRINT	ED WIRING BOARDS AND	
Using	Zooming Features ··		15		SCHE	MATIC DIAGRAMS	
		cture inside the Viewfinder					
(EDIT	SEARCH)		15	4-1.	Frame	Schematic Diagram ······	73
Manu	al Focusing	• • • • • • • • • • • • • • • • • • • •	16	4-2.	Printed	Wiring Boards and Schematic Diagrams	76
Using	the PROGRAM AE	Function · · · · · · · · · · · · · · · · · · ·	16		• CD-	92 Board	77
Fade	in and Fade-out·····	***************************************	17		· VC-	22 Board (Camera, Lens Drive)	82
Using	the World Clock ·····	***************************************	18			22 Board (Camera) ······	
Playir	ng Back a Tape ······		19			22 Board (Lens Drive) ······	
		inder ·····				5 Board (REC/PB Head Amp, Video,	
					Sen	o/System Control) ······	95
						5 Board (REC/PB Head Amp)	
2.	DISASSEMBLY					5 Board (Video) ·····	
						5 Board (Servo/System Control) ······	
2-1.	Removal of F Panel	Assembly ·····	21			2, CN-65, ED-35, MF-191, VK-27,	
2-2.	Removal of Cassett	e LID Assembly ······	21			1, LI-44 Boards	111
2-3.	Removal of Cabinet	(L) Assembly ·····	21			7, FP-442, LM-40, LS-33 Boards	
2-4.		(R) Assembly ·····				38, MA-149 Boards	
2-5.		ED-35 and VK-27 Boards ···				2 Board	
2-6.		and SW-205 Boards······				8, SW-205 Boards ······	
				4.0		nductors ······	
2-7.		Assembly		4-3.	Semico	nductors	140
2-8.		nd AU-138 Boards ······					
2-9.		ssembly (CD-92 Board)······		_	EV-01-4		
2-10.		Board ·····		5.	EXPLO	DDED VIEWS	
2-11.		Board ·····					
2-12.		loard ·····		5-1.		(L) and F Panel Assemblies ·····	
2-13.		sembly (VF-42 Board)······		5-2.		(R) and EVF Assemblies ·····	
2-14.	Internal Views ······	***************************************	27	5-3.		ards Assembly ·····	
				5-4.	Cassette	Compartment Assembly	144
				5-5.		sis Assembly······	
3.	DIAGRAMS			5-6.	Mechan	sm Chassis Assembly (1) ······	···· 146
				5-7.	Mechan	sm Chassis Assembly (2)	147
3-1.	Circuit Boards Loca	tion ·····	28	5-8.		ens Assembly (VCL-6210WC)	
3-2.		am				•	
3-3.		iagram					
3-4.		ssor Pin Function (IC709 on		6.	ELECT	RICAL PARTS LIST	149
	•	280624-424R/434R)·····					. •
				HARE	OWARE I	.IST	· 166

7.1. Preparations Before Adjustment (Camera Section) 187 7-1-1. List of Service Tools 187 7-1-1. 2 Preparations Selfore Adjustment (Camera Section) 186 7-1-2. Preparations 186 7-1-3. Precautions 187 7-1-2. Preparations 187 7-1-2. Preparations 187 7-1-3. Precautions 187 7-1-3. Adjustment Procedure 170 9. VIDEO SECTION ADJUSTMENT 7-1-4. Adjusting Remote Control Unit 171 1. Using the adjusting remote control unit 171 2. Precautions upon using the adjusting remote control unit 171 2. Precautions upon using the adjusting remote control unit 171 7-1-5. Page F Address List 172 7-1-6. 8 Page 1 Page Address List 172 7-1-7. Adjustment Connector 179 7-1-8. Data Processing 180 7-1-9. Data Processing 180 7-1-1. Adjustment (Volva Section 181 1. Power Supply Voltage Check (DD-48 board) 182 2. VSUB Adjustment (VC-122 board) 182 3. VSUB Adjustment (VC-122 board) 182 4. VSG Adjustment (VC-122 board) 182 5. VSUB Adjustment (VC-122 board) 183 6. Flange Back Adjustment 184 10. Flange Back Adjustment 186 11. Ris Ilsueval Adjustment (VC-122 board) 188 11. Ris Ilsu NoUT Adjustment (VC-122 board) 188 12. Black Time Risk Adjustment 190 13. AD Offset Adjustment (VC-122 board) 188 14. Carrier Balance Adjustment 190 15. Picture Frame Setting 197 1-1. Adjustment (VC-122 board) 188 16. Ris Ilsueval Adjustment (VC-122 board) 189 17. Auto White Balance Adjustment 190 18. Pre-white Balance Adjustment 190 19. Pre-white Balance Adjus	<u>P</u>	<u>Title</u>	ction	Section	Page	!	Title	tion	Sect
7-1-1. List of Service Tools	DJUSTMENTS	MECHANICAL SECTION ADJUST	N	8.		NTS	MERA SECTION ADJUSTMENT	CA	7.
7-1-1. List of Service Tools   169   7-1-2. Preparations for Adjustment   169   7-1-3. Precautions   169   7-1-3. Precautions   170   9. VIDEO SECTION ADJUSTMENT   2   Adjustment Procedure   170   9. VIDEO SECTION ADJUSTMENT   2   Adjustment Procedure   170   9-1. Preparations Before Adjustment   171   9-1. Equipments to be used   9-1. Service Mode   9-1. How to Set the REC M	•••••	Setting the Track Shift Mode ·····	S	8-1.	167	nera Section) ·····	parations Before Adjustment (Came	Pre	7-1.
7-1-3. Precautions				8-2.	·· 167	***************************************	ist of Service Tools ·····	-1. L	7-1-
1.					·· 169		reparations ······	-2. F	7-1-
2. Adjustment Procedure 170 3. Subject 171-14. Adjusting Remote Control Unit 171 1. Using the adjusting remote control unit 171 2. Precautions upon using the adjusting remote control unit 171 3. Precautions upon using the adjusting remote control unit 171 4. 1-1. Equipments to be used 171 5. Precautions upon using the adjusting remote control unit 171 6. Precautions upon using the adjusting remote control unit 171 7-1-5. Page F Address List 172 7-1-6. 8 Page, 1 Page Address List 178 1. Page 6 178 2. Page 1 179 7-1-7. Adjustment Connector 179 1. Setting the Service mode 179 7-1-18. Data Processing 180 7-1-19. Data Processing 180 7-1-19. Data Processing 180 7-19. Camera System Adjustment 181 1. Power Supply Voltage Check (DD-48 board) 181 1. Power Supply Voltage Check (DD-48 board) 181 1. Power Supply Voltage Check (DD-48 board) 181 1. Page F Data Initialization 181 1. Page F Data Initialization 181 1. Page F Data Initialization 181 1. Page F Data Modification 181 1. Page F Data Initialization 181 1. Page F Data Modification 181 1. Page F D					170	*****************	recautions ······	-3. F	7-1-
Subject	1ENT	VIDEO SECTION ADJUSTMENT	V	9.	·· 170		witch settings ······	9	1.
7-1.4. Adjusting Remote Control Unit: 171 1. Using the adjusting remote control unit: 171 2. Precautions upon using the adjusting remote control unit: 171 3. Precautions upon using the adjusting remote control unit: 171 3. Precautions upon using the adjusting remote control unit: 171 3. Precautions upon adjustment: 172 3. Page F Address List: 172 3. Page 8. 178 3. Page 8. 179 3. Setup during Adjustment: 179 3. Alignment Tape. 1. Setup during Adjustment: 179 3. Setup during Adjustment: 180 3. Page B Page Address List: 179 3. Setup during Adjustment: 181 3. Page B Protect: 181 3. Page Protect: 181 3. Page Protect: 181 3. Page Protect: 181 4. 28 MFt Original Oscillation Adjustment: 181 4. 28 MFt Original Oscillation Adjustment: 182 5. V SUB Adjustment (VC-122 board): 182 6. VRG Adjustment (VC-122 board): 182 6. VRG Adjustment (VC-122 board): 182 7. CCD Imager Correction Data Write: 182 7. CCD Imager Correction Data Write: 184 11. SYNC Level Adjustment (VC-122 board): 185 12. BURST Level Adjustment (VC-122 board): 185 13. A/D Offset Adjustment: 184 14. Carrier Balance Adjustment: 186 15. Picture Frame Settin (VC-122 board): 185 16. RISIS Level Adjustment (VC-122 board): 186 17. MAX GAIN Adjustment (VC-122 board): 188 18. RISI Level Adjustment (VC-122 board): 188 19. Pre-white Balance Adjustment: 189 20. Color Reproduction Adjustment: 189 21. Auto White Balance Adjustment: 189 22. Auto White Balance Adjustment: 189 23. White Balance Check: 189 24. Linear Matrix Adjustment: 189 25. VIDEO OUT Level Check: 194 26. Linear Matrix Adjustment: 189 27. 3. Focos Adjustment: 189 28. December Verwinder System Adjustments: 189 29. Power System Adjustments: 189 20. Color Reproduction Adjustment: 189 21. Auto White Balance Preset Adjustment: 189 22. Auto White Balance Preset Adjustment: 189 23. VIDEO OUT Level					·· 170		djustment Procedure ·····	-	2.
1. Using the adjusting remote control unit	<b></b>	Preparations Before Adjustment	P	9-1.	·· 170		ubject ·····	(	3.
2.   Precautions upon using the adjusting remote control unit	,	. Equipments to be used ·····	l-1.	9-1-1	·· 171		djusting Remote Control Unit	-4. <i>A</i>	7-1-
control unit	***********************	. Connecting the equipments	l- <b>2</b> .	9-1-2	. 171	ınit tini	Ising the adjusting remote control un	t	1.
7-1-5. Page F Address List 172 7-1-6. 6 Page, 1 Page Address List 178 1. Page 6 179 2. Page 1 179 2. Page 1 179 3-1-8. Service Mode 179 3-1-8. Service Mode 179 3-1-8. Data Processing 180 2. Types of Self-diagnostic Feature 181 3. Page D Write Protect 181 3. Page P Write Protect 181 3. Page F Data Initialization 181 3. Page F Data Initialization 181 3. Page F Data Initialization 181 4. 28 MHz Original Oscillation Adjustment (VC-122 board) 182 5. V SUB Adjustment (VC-122 board) 182 6. VRG Adjustment (VC-122 board) 182 7. CCD Imager Correction Data Write 182 7. CCD Imager Correction Data Write 182 8. HALL Adjustment 184 9. Flange Back Adjustment 194 10. Flange Back Adjustment (VC-122 board) 185 11. SYNC Level Adjustment (VC-122 board) 185 12. BURST Level Adjustment (VC-122 board) 186 13. A)D Offset Adjustment (VC-122 board) 188 14. Carrier Balance Adjustment 188 15. Picture Frame Setting 187 17. EDIT Switch, Remote Communicary Switch Check 194 18. IRIS IN/OUT Adjustment (VC-122 board) 188 19. Pre-white Balance Adjustment 199 21. Auto White Balance Adjustment 191 22. Auto White Balance Adjustment 191 23. White Balance Adjustment 191 24. Linear Matrix Adjustment 191 25. VIDEO OUT Level Check 194 17. ELIPS Adjustment 191 17. Setting the Service mode 192 18. Bit value Discrimination 189 18. IRIS IN/OUT Adjustment 190 19. Pre-white Balance Adjustment 190 19. Pre-white Balance Adjustment 190 29. Power System Adjustment 191 29. Power Voltage Check (DD-48 board) 192 20. Cloor Reproduction Adjustment 191 21. Auto White Balance Preset Adjustment 191 22. Auto White Balance Preset Adjustment 191 23. White Balance Preset Adjustment 191 24. Linear Matrix Adjustment 191 25. VIDEO OUT Level Check 194 26. Linear Matrix Adjustment 191 27. Selectronic Viewfinder System Adjustment 195 28. Servos Ajustment 195 29. Servos Ajustment 195 20. Coor Reproduction Adjustment 195 21. Auto White Balance Preset Adjustment 195 21. Servos Adjustment 195 22. Centering Adjustment 195 23. A Decrease 191 24. Linear Matrix Adjustment 191 25. VIDEO OUT	*********************	. How to Set the REC Mode ······	-3.	9-1-3		_			2.
7-1-6. 6 Page, 1 Page Address List  1. Page 6	•••••	. Precautions upon adjustment ·······	-4.	9-1-4					
1.   Page 8	******************************	. Set-up during Adjustment ······	-5.	9-1-5			_		
2.   Page 1		•	-6.	9-1-6					
7-1-7. Adjustment Connector 179 1. Setting the Service mode 7-7-1-8. Data Processing 180 2. Types of Self-diagnosts Feature 7-7-1-8. Data Processing 180 2. Types of Self-diagnosts Feature 7-7-2. Camera System Adjustment 181 3. Page D Write Protect 181 3. Page F Data Initialization 181 4. Page F Write Protect 18-7-2. Camera System Adjustment (VC-122 board) 181 5. Test Mode Setting 181 6. Emergency ode 181 6. Emergency ode 181 6. Emergency ode 181 6. Emergency ode 181 6. Emergency mode (VC-122 board) 182 9. Check of Tape Usitancian Switch, etc. 182 10. Mode Switch Check 182 11. Mechanism Control A/D Port Input Voltage Check 183 12. Tape Top/End separ Correction Data Write 182 11. Mechanism Control A/D Port Input Voltage Check 184 13. Battery Voltage Check 184 14. Individual Operations of the Drum. Capstan, and Loading Motor 185 15. Mode control micro processor key matrix check 184 14. Carrier Balance Adjustment (VC-122 board) 185 16. Wireless Remote Control Unit Reception Content 186 17. Picture Frame Setting 188 18. IRIS IN/OUT Adjustment (VC-122 board) 188 18. IRIS IN/OUT Adjustment (VC-122 board) 189 19. Pre-white Balance Adjustment 189 19. LCD, LED Check, etc. 191 29. System Control System Adjustment 190 2-2. Power System Adjustment 191 2-2. White Balance Preset Adjustment 191 2-2. System Control System Adjustment 191 2-2. Power System Adjustment 191 2-3. Servo System Adjustment 195 1-3-4. Aberration Adjustment 195 1-3-4. Aberration Adjustment 195 1-3-4. Aberration Adjustment 195 1-3-4. Aberration		·	<b>-7</b> .	9-1-7			9		
7-1-8. Data Processing 7-2. Camera System Adjustment 1. Power Supply Voltage Check (DD-48 board) 1. Power Supply Voltage Check (DD-48 board) 1. Power Supply Voltage Check (DD-48 board) 1. Page F Data Initialization 1. Page F Data Modification 1. Max Galn Adjustment (VC-122 board) 1. Page F Data Modification 1. Page F Data Modifica			-8.	9-1-8			•		
7-2. Camera System Adjustment 1							•		
1. Power Supply Voltage Check (DD-48 board) 181							-		
2.         Page F Data Modification         181         5.         Test Mode Setting           3.         Page F Data Modification         181         6.         Emergency code         4.           4.         28 MHz Original Oscillation Adjustment (VC-122 board)         182         8.         Bit value Discrimination           5.         V SUB Adjustment (VC-122 board)         182         9.         Check of Tape Distinction Switch, etc.           6.         VRG Adjustment (VC-122 board)         182         10.         Mode Switch Check.           7.         CCD Imager Correction Data Write         182         11.         Mode Switch Check.           8.         HALL Adjustment         183         12.         Tape Top/End Sensor Condition Check           9.         Flange Back Adjustment         184         13.         Battery Voltage Check           10.         Flange Back Check         184         14.         Individual Operations of the Drum, Capstan, and Loading Motor           11.         SYNC Level Adjustment (VC-122 board)         185         15.         Mode control micro processor key matrix check           13.         A/D Offset Adjustment (VC-122 board)         186         16.         Wireless Remote Control Unit Reception Content           14.         Carrier Balance Adjustment (VC-122 board							*		
3.         Page F Data Modification         181         6.         Emergency code           4.         28 MHz Original Oscillation Adjustment (VC-122 board)         7.         Emergency mode           (VC-122 board)         182         8.         Bit value bicsrimination           5.         V SUB Adjustment (VC-122 board)         182         9.         Check of Tape Distinction Switch, etc.           6.         VRG Adjustment (VC-122 board)         182         10.         Mode Switch Check.           7.         CCD Imager Correction Data Write         182         11.         Mechanism Control A/D Port Input Voltage Check           8.         HALL Adjustment         183         12.         Tape Top/End Sensor Condition Check           9.         Flange Back Adjustment         184         13.         Battery Voltage Check           10.         Flange Back Check         184         14.         Individual Operations of the Drum, Capstan, and Loading Motor           11.         SYNC Level Adjustment (VC-122 board)         185         15.         Mode control micro processor key matrix check.           13.         A/D Offset Adjustment (VC-122 board)         186         16.         Wireless Remote Control Unit Reception Content           14.         Carrier Balance Adjustment (VC-122 board)         188         18. </td <td></td> <td></td> <td></td> <td></td> <td></td> <td>,</td> <td></td> <td></td> <td></td>						,			
4. 28 MHz Original Oscillation Adjustment (VC-122 board) 182 8. Bit value Discrimination (VC-122 board) 182 9. Check of Tape Distinction Switch, etc		•					-		
(VC-122 board)         182         8.         Bit value Discrimination           5.         V SUB Adjustment (VC-122 board)         182         9.         Check of Tape Distriction Switch, etc					- 181				
5.         V SUB Adjustment (VC-122 board)         182         9.         Check of Tape Distinction Switch, etc.           6.         VRG Adjustment (VC-122 board)         182         10.         Mode Switch Check           7.         CCD Imager Correction Data Write         182         11.         Mechanism Control A/D Port Input Voltage Check           8.         HALL Adjustment         183         12.         Tape Top/End Sensor Condition Check           9.         Flange Back Adjustment         184         13.         Battery Voltage Check           10.         Flange Back Check         184         14.         Individual Operations of the Drum, Capstan, and Loading Motor           11.         SYNC Level Adjustment (VC-122 board)         185         15.         Mode control micro processor key matrix check           12.         BURST Level Adjustment (VC-122 board)         186         16.         Wireless Remote Control Unit Reception Content Check           13.         A/D Offset Adjustment         186         16.         Wireless Remote Control Unit Reception Content Check           14.         Carrier Balance Adjustment         186         17.         EDIT Switch, Remote Commander Switch Check           15.         Picture Frame Setting         187         17.         EDIT Switch, Remote Control Alpustment Wish Adjustment					400				4.
6.         VRG Adjustment (VC-122 board)         182         10.         Mode Switch Check*           7.         CCD Imager Correction Data Write         182         11.         Mechanism Control A/D Port Input Voltage Check           8.         HALL Adjustment         183         12.         Tape Top/End Sensor Condition Check           9.         Flange Back Adjustment         184         13.         Battery Voltage Check           10.         Flange Back Check         184         14.         Individual Operations of the Drum, Capstan, and Loading Motor           11.         SYNC Level Adjustment (VC-122 board)         185         15.         Mode control micro processor key matrix check*           12.         BURST Level Adjustment (VC-122 board)         185         15.         Mode control micro processor key matrix check*           13.         A/D Offset Adjustment         186         16.         Wireless Remote Control Unit Reception Content Check           14.         Carrier Balance Adjustment         186         16.         Wireless Remote Control Unit Reception Content Check           15.         Picture Frame Setting         187         17.         EDIT Switch, Remote Commander Switch Check           16.         IRIS Level Adjustment (VC-122 board)         188         18.         White Balance Mode and Focus Mode <t< td=""><td></td><td></td><td></td><td></td><td></td><td></td><td></td><td>•</td><td>5</td></t<>								•	5
7.         CCD Imager Correction Data Write         182         11.         Mechanism Control A/D Port Input Voltage Check           8.         HALL Adjustment         183         12.         Tape Top/End Sensor Condition Check           9.         Flange Back Adjustment         184         13.         Battery Voltage Check           10.         Flange Back Check         184         14.         Individual Operations of the Drum, Capstan, and Loading Motor           11.         SYNC Level Adjustment (VC-122 board)         185         15.         Mode control micro processor key matrix check           12.         BURST Level Adjustment         186         18.         Wireless Remote Control Unit Reception Content           14.         Carrier Balance Adjustment         186         18.         Wireless Remote Control Unit Reception Content           15.         Picture Frame Setting         187         17.         EDIT Switch, Remote Commander Switch Check           16.         IRIS Level Adjustment (VC-122 board)         188         18.         White Balance Mode and Focus Mode           17.         MAX GAIN Adjustment (VC-122 board)         188         18.         White Balance Adjustment         189         19.         LCD, LED Check, etc.         192         20.         Page D Address List         192         20.         Powe									_
8.         HALL Adjustment         183         12.         Tape Top/End Sensor Condition Check           9.         Flange Back Adjustment         184         13.         Battery Voltage Check           10.         Flange Back Check         184         14.         Individual Operations of the Drum, Capstan, and Loading Motor           11.         SYNC Level Adjustment (VC-122 board)         185         15.         Mode control micro processor key matrix check           12.         BURST Level Adjustment (VC-122 board)         185         15.         Mode control micro processor key matrix check           13.         A/D Offset Adjustment         186         16.         Wireless Remote Control Unit Reception Content Check           14.         Carrier Balance Adjustment         186         16.         Wireless Remote Control Unit Reception Content Check           15.         Picture Frame Setting         187         17.         EDIT Switch, Remote Commander Switch Check           16.         IRIS Level Adjustment (VC-122 board)         188         18.         White Balance Mode and Focus Mode           17.         MAX GAIN Adjustment (VC-122 board)         188         19.         LCD, LED Check, etc.           18.         IRIS IN/OUT Adjustment         189         19.         LCD, LED Check, etc.           19.									
9.         Flange Back Adjustment         184         13.         Battery Voltage Check           10.         Flange Back Check         184         14.         Individual Operations of the Drum, Capstan, and Loading Motor           11.         SYNC Level Adjustment (VC-122 board)         185         15.         Mode control micro processor key matrix check           12.         BURST Level Adjustment (VC-122 board)         186         16.         Wireless Remote Control Unit Reception Content           14.         Carrier Balance Adjustment         186         16.         Wireless Remote Control Unit Reception Content           14.         Carrier Balance Adjustment         186         16.         Wireless Remote Control Unit Reception Content           15.         Picture Frame Setting         187         17.         EDIT Switch, Remote Commander Switch Check           16.         IRIS Level Adjustment (VC-122 board)         188         18.         White Balance Mode and Focus Mode           17.         MAX GAIN Adjustment (VC-122 board)         188         18.         White Balance Adjustment         189         19.         LCD, LED Check, etc.           18.         IRIS IN/OUT Adjustment         189         19.         LCD, LED Check, etc.         19.           20.         Color Reproduction Adjustment         190		The state of the s					_		
10. Flange Back Check							•		
11. SYNC Level Adjustment (VC-122 board) 185 12. BURST Level Adjustment (VC-122 board) 185 13. A/D Offset Adjustment (VC-122 board) 186 14. Carrier Balance Adjustment 186 15. Picture Frame Setting 187 16. IRIS Level Adjustment (VC-122 board) 188 17. EDIT Switch, Remote Commander Switch Check 181 18. IRIS Level Adjustment (VC-122 board) 188 18. White Balance Mode and Focus Mode 17. MAX GAIN Adjustment (VC-122 board) 188 18. IRIS IN/OUT Adjustment (VC-122 board) 189 19. LCD, LED Check, etc. 199 19. Pre-white Balance Adjustment 189 20. Page D Address List 20. Color Reproduction Adjustment 190 21. Auto White Balance Preset Adjustment 191 22. Auto White Balance Adjustment 191 23. White Balance Adjustment 191 24. Linear Matrix Adjustment 192 25. VIDEO OUT Level Check 194 26. VIDEO OUT Level Check 194 27-3-1. Horizontal Slant Adjustment 195 28. VIDEO OUT Level Check 194 29-3. Servo System Adjustment 195 29-3. Focus Adjustment 195 29-4. Focus Adjustment 195 29-4. Focus Adjustment 195 29							•		
12. BURST Level Adjustment (VC-122 board) 185 15. Mode control micro processor key matrix check··· 13. A/D Offset Adjustment···· 186 16. Wireless Remote Control Unit Reception Content 14. Carrier Balance Adjustment 186 Check Che				131					
13. A/D Offset Adjustment 186 16. Wireless Remote Control Unit Reception Content 14. Carrier Balance Adjustment 186 17. Check 18. Picture Frame Setting 187 187 188 18. White Balance Mode and Focus Mode 188 18. White Balance Mode and Focus Mode 188 18. White Balance Mode and Focus Mode 188 18. IRIS IN/OUT Adjustment (VC-122 board) 188 19. LCD, LED Check, etc. 19. Pre-white Balance Adjustment 189 20. Page D Address List 19. Pre-white Balance Adjustment 190 9-2. Power System Adjustments 191 1. Oscillator Frequency Check (DD-48 board) 191 2. Power Voltage Check (DD-48 board) 191 2. Power Voltage Check (DD-48 board) 191 2. Page D Initial Value Input 191 2. Page D Initial Value Input 191 2. Page D Initial Value Input 191 3. Battery Down Check 194 3. Battery Down Check 194 3. Battery Down Check 194 3. Servo System Adjustments 194 3. Servo System Adjustment 195 3. Switching Position Adjustment (VS-95 board) 195 3. Switching Position Adjustment (VS-95 board) 195 3. Horizontal Oscillation Frequency Adjustment 195 4. Aberration Adjustment 195 4. Aberration Adjustment 195 4. Aberration Adjustment 195 5. Horizontal Oscillation Frequency Adjustment 195 7-3-4. Aberration Adjustment 195 7-3-5. Horizontal Oscillation Frequency Adjustment 195 7-3-5. Horizontal Oscillation Frequency Adjustment 195 7-3-5. Horizontal Oscillation Frequency Adjustment 195 7-3-5.		_		15.		,			12.
14. Carrier Balance Adjustment 186 Check 15. Picture Frame Setting 187 17. EDIT Switch, Remote Commander Switch Check 16. IRIS Level Adjustment (VC-122 board) 188 18. White Balance Mode and Focus Mode Display/Switchover 18. IRIS IN/OUT Adjustment 189 19. LCD, LED Check, etc. 19. Pre-white Balance Adjustment 189 20. Page D Address List 20. Color Reproduction Adjustment 190 9-2. Power System Adjustments 21. Auto White Balance Preset Adjustment 191 1. Oscillator Frequency Check (DD-48 board) 22. Auto White Balance Adjustment 191 2. Power Voltage Check (DD-48 board) 23. White Balance Check 192 9-3. System Control System Adjustments 25. VIDEO OUT Level Check 194 2. Battery End Adjustment 25. VIDEO OUT Level Check 194 2. Battery Down Check 27-3-1. Horizontal Slant Adjustment 195 1. Switching Position Adjustment (VS-95 board) 27-3-3. Focus Adjustment 195 1. Switching Position Adjustment (VS-95 board) 27-3-4. Aberration Adjustment 195 7-3-5. Horizontal Oscillation Frequency Adjustment 195 7-3-5. Horizontal Oscillation Frequency Adjustment (VF-42 board) 195									13.
15. Picture Frame Setting 187 17. EDIT Switch, Remote Commander Switch Check- 16. IRIS Level Adjustment (VC-122 board) 188 18. White Balance Mode and Focus Mode 17. MAX GAIN Adjustment (VC-122 board) 188 Display/Switchover 189 Display/Switchover 189 19. LCD, LED Check, etc. 19. Pre-white Balance Adjustment 189 20. Page D Address List 190. Color Reproduction Adjustment 190 9-2. Power System Adjustments 191 1. Oscillator Frequency Check (DD-48 board) 191 2. Power Voltage Check (DD-48 b							•		14.
16. IRIS Level Adjustment (VC-122 board) 188 18. White Balance Mode and Focus Mode 17. MAX GAIN Adjustment (VC-122 board) 188 Display/Switchover 18. IRIS IN/OUT Adjustment 189 19. LCD, LED Check, etc. 19. Pre-white Balance Adjustment 189 20. Page D Address List 20. Color Reproduction Adjustment 190 9-2. Power System Adjustments 21. Auto White Balance Preset Adjustment 191 1. Oscillator Frequency Check (DD-48 board) 22. Auto White Balance Adjustment 191 2. Power Voltage Check (DD-48 board) 23. White Balance Check 192 9-3. System Control System Adjustments 193 1. Page D Initial Value Input 25. VIDEO OUT Level Check 194 2. Battery End Adjustment 194 2. Battery End Adjustment 194 3. Battery Down Check 194 3. Battery Down Check 194 3. Battery Down Check 194 3. Servo System Adjustment 195 1. Switching Position Adjustment (VS-95 board) 195 1. Switching Position Adjust				17.	· 187		icture Frame Setting ·····	F	15.
17. MAX GAIN Adjustment (VC-122 board) 188 18. IRIS IN/OUT Adjustment 189 19. Pre-white Balance Adjustment 189 20. Color Reproduction Adjustment 190 21. Auto White Balance Preset Adjustment 191 22. Auto White Balance Adjustment 191 23. White Balance Check 192 24. Linear Matrix Adjustment 193 25. VIDEO OUT Level Check 194 26. VIDEO OUT Level Check 194 27-3. Electronic Viewfinder System Adjustment 194 28. Horizontal Slant Adjustment 194 29-4. Servo System Adjustment 195 29-3. Focus Adjustment 195 29-4. Servo System Adjustment 195 29-5. Horizontal Oscillation Frequency Adjustment 195 29-6. Horizontal Oscillation Frequency Adjustment 195 29-7-3-5. Horizontal Oscillation Frequency Adjustment 195 29-7-3-6. Horizontal Oscillation Frequency Adjustment 195 29-8. Display/Switchover 199 20. Codor Reproduction Adjustment 199 20. Page D Address List 190 21. Oscillator Frequency Check (DD-48 board) 190 22. Power Voltage Check (DD-48 board) 190 23. System Control System Adjustments 191 24. Linear Matrix Adjustment 193 25. VIDEO OUT Level Check 194 26. Battery End Adjustment 194 27-3-1. Horizontal Slant Adjustment 194 28-3. Servo System Adjustment 195 29-4. Servo System Adjustment (VS-95 board) 195 29-4. Servo System Adjustment (VS-95 board) 195 29-4. Servo System Adjustment 195 29-5. System Control System 195 29-6. Servo System Adjustment 195 29-7-7-7-7-7-7-7-7-7-7-7-7-7-7-7-7-7-7-7				18.	· 188	rd)	RIS Level Adjustment (VC-122 board	11	16.
18. IRIS IN/OUT Adjustment 189 19. LCD, LED Check, etc. 19. Pre-white Balance Adjustment 189 20. Page D Address List 20. Color Reproduction Adjustment 190 9-2. Power System Adjustments 21. Auto White Balance Preset Adjustment 191 1. Oscillator Frequency Check (DD-48 board) 22. Auto White Balance Adjustment 191 2. Power Voltage Check (DD-48 board) 23. White Balance Check 192 9-3. System Control System Adjustments 24. Linear Matrix Adjustment 193 1. Page D Initial Value Input 25. VIDEO OUT Level Check 194 2. Battery End Adjustment 27-3. Electronic Viewfinder System Adjustments 194 3. Battery Down Check 27-3-1. Horizontal Slant Adjustment 194 9-4. Servo System Adjustments 27-3-2. Centering Adjustment 195 1. Switching Position Adjustment (VS-95 board) 27-3-4. Aberration Adjustment 195 7-3-5. Horizontal Oscillation Frequency Adjustment 195 7-3-5. Horizontal Oscillation Frequency Adjustment 195 195					- 188	ard)	IAX GAIN Adjustment (VC-122 board	N	17.
19. Pre-white Balance Adjustment 189 20. Page D Address List 20. Color Reproduction Adjustment 190 9-2. Power System Adjustments 21. Auto White Balance Preset Adjustment 191 1. Oscillator Frequency Check (DD-48 board) 22. Auto White Balance Adjustment 191 2. Power Voltage Check (DD-48 board) 23. White Balance Check 192 9-3. System Control System Adjustments 193 1. Page D Initial Value Input 25. VIDEO OUT Level Check 194 2. Battery End Adjustment 194 2. Battery End Adjustment 194 3. Battery Down Check 194 3. Servo System Adjustment 194 9-4. Servo System Adjustment 195 1. Switching Position Adjustment (VS-95 board) 195 1. Switching Position Adjustment (VS-95 board) 195 1-3-5. Horizontal Oscillation Frequency Adjustment 195 1. Switching Position Adjustment (VS-95 board) 195 1-3-5. Horizontal Oscillation Frequency Adjustment 195 1.				19.	· 189	*****************	RIS IN/OUT Adjustment·····	II	18.
21. Auto White Balance Preset Adjustment 191 1. Oscillator Frequency Check (DD-48 board) 22. Auto White Balance Adjustment 191 2. Power Voltage Check (DD-48 board) 23. White Balance Check 192 9-3. System Control System Adjustments 193 1. Page D Initial Value Input 25. VIDEO OUT Level Check 194 2. Battery End Adjustment 194 3. Battery Down Check 194 3. Servo System Adjustment 194 3. Servo System Adjustment 195 1. Switching Position Adjustment (VS-95 board) 195 1. Switching Position Adjustment (VS-95 board) 195 1. Horizontal Oscillation Frequency Adjustment 195 1. Switching Position Adjustment (VS-95 board) 195 1. Switching Position Adj				20.	· 189	•••••••	re-white Balance Adjustment ·······	F	19.
22. Auto White Balance Adjustment 191 2. Power Voltage Check (DD-48 board) 23. White Balance Check 192 9-3. System Control System Adjustments 193 1. Page D Initial Value Input 25. VIDEO OUT Level Check 194 2. Battery End Adjustment 194 3. Battery Down Check 194 3. Servo System Adjustment 194 9-4. Servo System Adjustment 195 1. Switching Position Adjustment (VS-95 board) 195 7-3-4. Aberration Adjustment 195 195 7-3-5. Horizontal Oscillation Frequency Adjustment 195 195		Power System Adjustments ······	P	9-2.	· 190	*************************	olor Reproduction Adjustment ······	C	20.
23. White Balance Check 192 9-3. System Control System Adjustments 193 1. Page D Initial Value Input 25. VIDEO OUT Level Check 194 2. Battery End Adjustment 27-3. Electronic Viewfinder System Adjustments 194 3. Battery Down Check 27-3-1. Horizontal Slant Adjustment 194 9-4. Servo System Adjustments 195 1. Switching Position Adjustment (VS-95 board) 27-3-3. Focus Adjustment 195 1. Switching Position Adjustment (VS-95 board) 27-3-4. Aberration Adjustment 195 195 195 195 195 195 195 195 195 195	D-48 board) ·····	Oscillator Frequency Check (DD-48 b		1.	· 191	ent·····	uto White Balance Preset Adjustmer	A	21.
24. Linear Matrix Adjustment 193 1. Page D Initial Value Input 25. VIDEO OUT Level Check 194 2. Battery End Adjustment 57-3. Electronic Viewfinder System Adjustments 194 3. Battery Down Check 57-3-1. Horizontal Slant Adjustment 194 9-4. Servo System Adjustments 195 1. Switching Position Adjustment (VS-95 board) 57-3-3. Focus Adjustment 195 7-3-4. Aberration Adjustment 195 7-3-5. Horizontal Oscillation Frequency Adjustment (VF-42 board) 195	board)	Power Voltage Check (DD-48 board)		2.					22.
25. VIDEO OUT Level Check	ents	System Control System Adjustments ····	S	9-3.					
7-3. Electronic Viewfinder System Adjustments 194 3. Battery Down Check 7-3-1. Horizontal Slant Adjustment 194 9-4. Servo System Adjustments 195 7-3-2. Centering Adjustment 195 1. Switching Position Adjustment (VS-95 board) 7-3-3. Focus Adjustment 195 7-3-4. Aberration Adjustment 195 7-3-5. Horizontal Oscillation Frequency Adjustment (VF-42 board) 195				1.			-		
7-3-1. Horizontal Slant Adjustment 194 9-4. Servo System Adjustments 195 1. Switching Position Adjustment (VS-95 board) 195 1. Switching Position Adjustment 195 1. Switching Position Posit	?	Battery End Adjustment·····		2.					
7-3-2. Centering Adjustment		Battery Down Check······		3.					
7-3-3. Focus Adjustment		Servo System Adjustments ······	Se	9-4.					
7-3-4. Aberration Adjustment	(VS-95 board)	Switching Position Adjustment (VS-95		1.					
7-3-5. Horizontal Oscillation Frequency Adjustment (VF-42 board) ···················195							•		
(VF-42 board) ····· 195					195		•		
						-			7-3-5
יס-ס, Fiorizontal Ambiltude Adjustment (VF-42 hoard) 198									701
7-3-7. Vertical Amplitude Adjustment (VF-42 board)									
7-3-8. Brightness, Contrast Adjustments (VF-42 board) ······ 196					196	•	· ·		
7-3-9. Horizontal Amplitude, Vertical Amplitude,  Focus Check					100				1-3-8
7-4. Arrangement Diagram for Adjustment Parts 198									7-4

Secti	on <u>Title</u> <u>Page</u>
9-5.	Video Adjustments 221
1.	Playback Frequency Characteristic Adjustment
	(VS-95 board) 222
2.	Flying Erase Check (VS-95 board) 222
3.	VXO Oscillation Frequency Check (VS-95 board) ····· 222
4.	EE Level Adjustment (VS-95 board) 223
5.	IR Adjustment (VS-95 board) 223
6.	Y/C Separation Adjustment (VS-95 board) ····· 224
7.	Emphasis Input Level Adjustment (VS-95 board) ····· 224
8.	PB Y Level Adjustment (VS-95 board) 225
9.	PB LINE OUT Level Adjustment 225
10.	Y FM Carrier Frequency Adjustment (VS-95 board) ··· 226
11.	Deviation Adjustment (VS-95 board) 226
12.	Chroma Emphasis fo Adjustment (VS-95 board) · · · · 227
13.	REC Y Level Adjustment (VS-95 board) 227
14.	REC C Level Adjustment (VS-95 board) 228
15.	REC ATF Level Check (VS-95 board) 228
16.	REC AFM Level Check (VS-95 board) 229
9-6.	Audio System Adjustment 229
1.	E-E Output Level Check (AU-138 board) 230
2.	IR Adjustment (AU-138 board) 230
3.	Deviation Adjustment 230
4.	Carrier Frequency Check (AU-138 board) 230
5.	Record Level Check (AU-138 board) 230
6.	Overall Level Characteristic, Distortion Check 231
7.	Overall Noise Level Check 231
9-7.	Arrangement Diagram for Adjustment Parts 232

There is the color reproduction standard frame at the back of the book.

## **SERVICE NOTE**

## [SEMICONDUCTOR FOR CORRECTION LIST DISPLAY]

Part code and part name of the semiconductor for correction of the print board is discribed in the space of each print figure. Use this list when ordering parts.


## [PARTS LOCATION DIAGRAM RELATED TO POWER SUPPLY]

The parts location diagram for the power supply which are often checked and replaced when repairing the fuse and IC link and so on. (See pages 95 and 107.)

This diagram is useful for repair.

## [SEMICONDUCTOR LOCATION]

In this service manual, the mounted locations of the semiconductors (IC, transistor, diodes) are indicated in red as shown below. This enables to find the location on the board easily when servicing.



## [HEAD CLEANING]

After an extended period of use the video image may become indistinct or may not appear at all during playback of a tape. The cause of this usually are dirty video heads. For remedy, cleaning of the heads is required.

### **Check for Head Clogs During Recording**

- ① Use a blank tape, record a short section, then press the stop button to stop.
- 2 Set to recording mode again.
- ③ If the [ ♣ ] mark is flashing in the viewfinder at this time, head clogs are occurred.

## **Check During Playback of a Tape**

- ① Play back a pre-recorded tape and display the image on a TV screen.
- ② If there is no sound and the image is unstable, no image appears on the screen, or tape transport is unstable, head clogs are occurred.

### Remedy

### [Cleaning method using a cleaning tape]

 Use the Cleaning Tape. (Please follow the instructions attached to the cleaning tape.)

## GENERAL

For details on the use of each part, refer to the pages indicated in the parentheses.

(B-1)

1 EDITSEARCH button (26)

2 Tape transport buttons (37), (38)

☐ STOP (stop)

← REW (rewind)

▷ PLAY (playback)

▶► FF (fast forward)

II PAUSE (pause)

3 Built-in microphone (monaural)

5 Camera recording/battery lamp (24) 4 Remote sensor (7)

6 LENS COVER switch (23)

8 FOCUS button (27) 7 Focus dial (27)

9 Power zoom button (25), (27)

10 POWER switch

11 Viewfinder (22)

[13] Viewfinder lens adjustment ring (22) [14] Lithium battery compartment (9) 12 Eyecup

审 审

(B-2)

同

9

15 REC MODE (recording mode)/EDIT switch (23), (39) REC MODE Mode Recording Function B 2 R [2]

Playback Editing EDIT switch ā III-Recording mode switch

16 REMOTE COMMANDER IN ON/OFF switch

17 BEEP switch (22)

18 DATE (+) button (19), (24), (31)

19 TIME (NEXT) button (19), (24), (31)

20 SUMMERTIME button (19), (31)

21 AREA button (31)

[22] Battery mounting surface (12)

23 Hooks for shoulder strap

24 COUNTER RESET button (23)

(2)

25 BATT (battery eject) knob (12) 26 FADER button (30)

27 PROGRAM AE diai (28)

This section is extracted from instruction manual of AEP/UK model.

Identifying the Parts

SECTION 1

圓 **回** [2] III 44 CALISE [7] ¥ 4 6

## Identifying the Parts



(B-3)

8

(B-5)

28 EJECT knob (21)

图

29 C\* remote control jack (stereo mini-minijack)

30 START/STOP button (23)

8

8

31 STANDBY switch (19), (23)

32 Cassette compartment (21)

8

33 MIC (microphone) jack (PLUG IN POWER) (monaural minijack) Connect an external microphone (not supplied).

34 Jack cover

35 Video/Audio output jack (phono jacks) (36), (39) 36 RFU DC OUT (DC output) Jack (34), (35)

-(%)

37 Grip strap

38 Tripod receptacle

\* About (LANC)

崗

8


卣

Bus System. The & (LANC) connector is used for controlling the tape transport of video equipment and the peripherals connected to it.


This connector has the same function as the connectors indicated as CONTROL L or REMOTE. CLANC) stands for Local Application Control

Caution (B-4)
Do not pick up the camcorder as shown in the illustration.

(B-4)



(B-6)



## dentifying the Parts

## Wireless Remote Commander

You can remotely record or play back a tape. The buttons on the Remote Commander with the same name or same mark as those on the camcorder have the same function.

Be sure to insert the supplied lithium battery into it (page 10) and to set REMOTE COMMANDER IS ON/OFF on the camcorder to When you use the Remote Commander "ON"

(B-5)

1 Transmitter

2 Power zoom button (25), (27)

3 Tape transport buttons (37), (38)

4 START/STOP button

5 HOLD switch\*

9

Slide in the direction of the arrow to prevent the buttons from being accidentally depressed.

6 DATA SCREEN button\* (38) Press to erase or display the on-screen display.

The \* Indicates the function which is operable only with the Remote Commander.

Remotely controllable area (B-6)
Point the Remote Commander towards the remote sensor [a].

 Keep the remote sensor away from strong light sources such as direct sunlight or Illumination.
 Otherwise the remote control may not be Notes on the Remote Commander

commander mode "VTR 2". A commander mode · Be sure that there is no obstacle between the remote sensor and the Remote Commander.

• This camcorder works through the signals of

we recommend you change the commander mode or cover the remote sensor of the VTR with black paper. is used to distinguish this camcorder from other Sony VTR to avoid misoperation. If you use another Sony VTR at commander mode "VTR 2",




## dentifying the Parts

nserting

# Using the Remote Commander holder

(B-7)

You can clip the Remote Commander holder on your cost pocket or belt, or also slide it onto the shoulder belt before attaching the Remote Commander to it. (B-7)



Your camcorder is supplied with two lithlum batteries. One is for the camcorder, and the other is for the Remote Commander. Note that the lithlum battery has a positive (+) side and a negative (-; no mark) side as illustrated. Be sure to install the lithium battery with the correct polarity. (C-1)

-

· California

(



(C-2)

[b] When detaching the Remote Commander from the Remote Commander holder

[a] When attaching the Remote Commander to the Remote Commander holder

(B-8)

(B-8) Œ


## (C-2)

This camcorder uses a lithium battery to activate the clock. At first install the supplied lithium battery.

- 1 Detach the lid of the lithium battery compariment at the bottom.
- 2 Install the supplied CR2025 lithium battery with the positive (+) side facing out.


## 3 Replace the lid.

When replacing the lithium battery, keep the battery pack or other power source attached. Otherwise, resetting of the date and time will be To change the lithium battery
Detach the lid of the lithium battery
compartment, and replace the lithium battery with a new one. necessary.









2

 $\infty$ 

# nserting the Lithium Batteries

## Inserting the Lithium Battery into the Remote Commander

(S-3)

Pull out the lithium battery holder from the

Commander.

Install the lithium battery with the positive (+) side facing upward. 3 Put the lithium battery holder back into the Commander.

## Connecting Sources

# First, Choose the Power Source.

Place	Power source	Accessory to be used
Outdoors	Battery pack	Battery pack NP-55 (supplied), NP-55H, NP-66H, NP-77, NP-77H, NP-77HD
	Alkaline batteries	Battery case EBP-77
Indoors	House	AC power adaptor AC-V35 (supplied), AC-V55, AC-S10
in the	12V or 24V car battery	DC pack DCP-77, AC power adaptor AC-V55, the car battery cord DCC-18AE and the car battery charger DC-S10

For details, see the operation manual of the accessory you want to use.

## Using the Battery Pack

## Step 1

Charge the battery pack. (D-1)

1 Connect the AC power adaptor to a wall outlet. 2 Align the right side of the battery pack with the line on the AC power adaptor.

3 Slide in the battery pack to the right.

4 Set the selector to "CHARGE" position. When charging is finished, the charge lamp goes out.

	_		_		-
NP-77 NP-66H		110		115	
NP-77		120		120	
NP-77H/	בר/,	140		140	
NP-55 NP-55H		20		2	
NP-55		8		9	
	Required	charging	time*	Battery	1 4 4

life \* \*

Approximate minutes using AC-V35
 \*\* Approximate minutes using fully charged battery pack, continuous recording indoors

(continued)

(D-1)

# Lithium battery life (under normal operation)

The battery for the camcorder lasts for approximately 1 year.

about 5 seconds (when the POWER switch is set to CAMERA). The battery for the Remote Commander lasts for approximately 6 months. When the battery becomes weak or dead, the Commander does When the battery becomes weak, the ⇔ indicator will flash inside the viewfinder for

\*

In either case, replace the battery with a Sony CR2025 battery. Use of any other type of battery may present the risk of fire or explosion. not work.


## CAUTIONS

children. Should the battery be swallowed, immediately consult a doctor. · Keep the lithium battery out of the reach of

tweezers, otherwise a short-circuit may occur.

The battery may explode if mistreated.
Do not recharge, disassemble, or dispose of in fire. · Do not hold the battery with the metallic





10

<del>(</del>4

က

# Connecting the Power Sources

## Step 2

(D-2)

Mount the battery pack on the camcorder. (D-2)

2 Align the right side of the battery pack with the white line on the camcorder. 1 Lift up the viewfinder.

3 Slide the battery pack to the right.

S

Note Make sure that the battery fits completely on the mounting surface of the camcorder.

## You can check the remaining battery capacity with the remaining battery indicator inside the Remaining battery indicator

Connecting the Power Sources

1

1

(

(

viewfinder. The decreasing white bar indicates decreasing battery power. (D-5)

Note
The remaining battery indicator of the camcorder may include a different remaining capacity from that of the NP-77-HD battery pack. The indicator of NP-77-HD is more accurate.

Ō

Other options for charging


• AC-V55 AC power adaptor:
You can charge two battery packs simultaneously.

• AC-S10 AC power adaptor:
This adaptor has a discharging function. When you want charging only, slide the skip switch on the adaptor in the direction of the arrow.

• BC-S5 portable battery charger:
You can charge a battery pack on 100—240 V AC.

• DC-S10 car battery charger:
This charger has a discharging function. When you want charging only, slide the skip switch on the charger in the direction of the arrow.

(D-5)



## To remove the battery pack

(0-3)
While pressing the BATT knob in the direction of the arrow (1), slide the battery pack to the left and pull it out as illustrated (2).

# How to use the switch on the battery pack

(D-4)

remember the charging condition. Set the switch to the "no mark" position when charging is completed. Set the switch to the "red mark" position when the battery is dead. This switch is provided so that you can



12

\$0.00

## the Date and Setting lime

<u>E</u>

E

1 While pressing the green button, set the POWER switch to CAMERA, and turn

STANDBY up.

simultaneously for more than 2 seconds untill
"1 LONDON" flashes inside the viewfinder.
DATE (+) now functions as + (to advance
numbers) and TIME (NEXT) functions as
NEXT (to execute). Press DATE (+) and TIME (NEXT)

If you leave the camcorder in the standby mode for 5 minutes or more, the camcorder will go off automatically. Turn STANDBY down once and

stide it up again.

the date and time

Countries	Area name	Area
The United Kingdom and Portugal (GMT)	LONDON	+-
Other European countries (CET)	PARIS	2
Finland, Greece, etc.	CAIRO	က

4 Choose one of the following options to set the clock:

1

PAGE 1

4

2

1

SHAN T

[a] To set to summer time, press SUMMERTIME. Then press TIME (NEXT). The \* indicator appears inside the

[b] To set to standard time, press TIME viewfinder. (NEXT).

First adjust the flashing digits with DATE (+) 5 Set the year\*, month, day, hour and minute, in this order.

1

PASS

1

PARIS 242 1992

\* To set the year to 1992, no need to press DATE (+) in step 5 - .

and then press TIME (NEXT).

The clock starts operating. 6 Press TIME (NEXT).

ተ

PARIS -17,50:00

1

PARIS 17230000

9

To correct the date and time setting Press TIME (NEXT) repeatedly until the digits of minute stop flashing. Then repeat step 2 to 6.

Make sure that a power source and lithium battery are installed.

To check the preset date and time Press DATE (+) or TIME (NEXT). When you press the same button again, the indicator goes

Setting the Date and Time

To advance the digits faster Keep DATE (+) pressed. To reset to standard time Press SUMMERTIME. The : indicator goes off. If the camcorder goes off abruptly while setting

number appear and then press TIME (NEXT). 3 Press DATE (+) until your area name and

> BUMMERTIME 0

> > S

## nserting a Cassett Preparing your camcorder 4

## Inserting a Cassette

(6.1)

Make sure that a power source is connected.

White pressing the small button on the EJECT knob, slide the knob down. The cassette compartment automatically lifts up and opens toward you.

2 Insert a tape with the window facing out.

Close the cassette holder by pressing the "PUSH" mark on the cassette holder.

2

## Ejecting the Cassette

Make sure that a power source is connected

1 While pressing the small button on the EJECT knob, slide the knob down.

2 Take out the tape.

3

3 Close the cassette holder by pressing the "PUSH" make on the cassette holder.

## when you use the camcorder for the first time, or when you use it after someone else did. Ê

vision varies depending on the person. Adjust it

The position of the viewfinder lens for optimum

Ajusting the Viewfinder

Preparing your camcorder 5

1

(

(

1 Make sure that the power source is connected and that the cassette is inserted.

2 Pull the viewfinder out until it clicks.


3 While pressing the green button, set the POWER switch to CAMERA.

4 Turn STANDBY up.

5 Turn the viewfinder lens adjustment ring so that "STBY" displayed in the viewfinder screen comes into sharp focus.

## Checking Switch

the beep sound is not recorded on the tape. If you do not want to hear the beep sound, set the BEEP switch to OFF. confirming the operation. Several beeps also sound as a warning of any unusual condition of the camcorder. Note that A beep sounds when you start recording and two beeps sound when you stop recording,



Ê

3

€



## Preventing Accidental Erasure

(G:5)

Slide the tab on the cassette to expose the red mark. This will prevent accidental erasure of the recording.

If you try to record with the red mark exposed, the ∞ and ♠ indicators flash inside the covering the red mark. viewfinder

To re-record on this tape, slide the tab back out

Never insert anything in the small holes on the rear of the cassette. These holes are used to sense the type of tape, thickness of tape, or if the tab is out or in, etc. Note on handling tapes

21

22

## Recording a Picture Using Automatic

strongly recommend you make a trial recording and check that everything is working properly. Before recording "once-only" events, we

G-13

(<del>J-</del>2)

If you set the date (page 19), the date is automatically recorded for 10 seconds after you start recording (Auto Date feature). This feature

0

 $\infty$ 

0

2 Make sure that the viewfinder is pulled out.

(7-3)

Set the REC MODE switch to LP (long play) or SP (standard play), according to the length of your planned recording.

Set the white mark of the PROGRAM AE dial

"REC" appears and the red lamp lights up inside the viewfinder. The camcorder is now

TIME(NEXT)

To standby (to stop momentarily)

Turn STANDBY down and set the POWER switch to OFF.  Shoot the subject at the wide-angle position in macro. At the telephoto position, if the subject is To record from the beginning of the tape, run the date for about 15 seconds before recording. This will avoid missing the starting point when the tape is played back. closer than 80 cm, it cannot be brought into

COUNTER RESET

-stille.

ဖ

Ü

## Recording a Picture Using Automatic Adjustments

It can be used in either the pushed-down or The viewfinder can be turned 90 degrees For low-position recording (J-2) upward.

pulled-out position.

To check the remaining time of the tape during In recording mode, the remaining tape length indicator appears inside the viewfinder and changes as illustrated. recording (J-3)

The exp indicator, the red lamp inside the Near the end of the tape

Note on the standby mode if you leave the camcorder in standby mode for lamp on the camcorder flash slowly. When the viewfinder, and the camera recording/battery tape reaches the end, the flashing becomes rapid.

STANDBY down once and slide it up again. To automatically. To resume standby mode, turn 5 minutes or more, the camcorder will go off start recording, press START/STOP directly.

↑ 5min

0min ▲----- 4min

However, the date may automatically appear The auto date feature works once a day. Note on the auto date feature

 you reset the date and time. more than once a day when:

you eject and insert the tape again.
 you stop recording within 10 seconds.

Recording mode

4 7 1992

However, the quality of the playback picture in the LP mode will not be as good as that in the SP mode. You can record and play back a picture on a tape in both SP (standard play) and LP (long play) modes.

## Recording Date or Time

17:30:00

4

The date or time displayed inside the viewfinder During camera recording or when in standby mode, press DATE(+) for date indicator or TIME(NEXT) for time Indicator

is recorded with the picture.

Press DATE(+) or TIME(NEXT) again. The date or time indicator disappears. The picture recording continues. To stop recording date or time

If you set the BEEP switch to ON, beeps sound when you start or stop recording or when you "STBY" appears inside the viewfinder. The "STBY" appears inside the viewfinder If it is not open, you cannot record. 1 Hold the camcorder as illustrated. camcorder is in standby mode again. make a mistake in the operation. 3 Slide LENS COVER to OPEN. Adjustments Press START/STOP again. to the green position. Start Recording works only once a day. Turn STANDBY up. Press START/STOP. 3 9 5 REC 11 \*

STBY

While pressing the green button, set the POWER switch to CAMERA.

7

DATE(+)

PLAYER

POWER OFF

To stop

To reset the counter to 0:00:00 Press COUNTER RESET.

Notes on recording

24

1

(7-7)

subject in the scene. Use "zoom-in (Telephoto)" for dramatic close-ups [a], and "zoom-out (Wide angle)" for panoramic long shots [b]. Also use the zoom to focus manually or to decide the By zooming, you can change the size of the shooting angle.

CONT

(7-2)

For more professional-looking recordings, use zooming sparingly.

Dual-Speed Zooming (J-6)

9-5

The camcorder's power zoom button offers dual speed zooming. Press it firmly for high speed zooming and softly for relatively slow zooming.

[c] W side: for wide-angle (subject appears farther away)

₦

<u>5</u>

[d] T side: for telephoto (subject appears closer)

Autofocusing in macro

and images in photographs, can literally fill the Even small subjects, such as flowers, insects, We recommend you to use a tripod when screen using autofocusing in macro. shooting in macro. 1 Bring the camcorder as close as necessary to obtain the desired subject size.

power zoom button until the zooming stops Keep pressing the W (MACRO) side of the

You can also shoot with manual focus while Manual focusing in macro doing close-up.

For manual focusing, see page 27.

**-Œ** 

Recording a Picture Using Automatic Adjustments

Checking the Recorded Inside the Viewfinder (EDITSEARCH)

DUAL SPEED

recorded picture, you can also re-record over a recorded scene or check the recorded picture Using EDITSEARCH, you can review the last inside the viewfinder. After checking your previously recorded portion.

+ EDITSEARCH - CD

To review the last recorded scene — Rec Review You can check the last portion of a scene you just recorded in CAMERA mode. This is convenient for quick, on-the-spot checks.

1 Set the camcorder in standby mode by turning STANDBY up.

2 Press the - side of EDITSEARCH (@)

The last few seconds of the recorded portion are played back inside the viewfinder. Then, the camcorder goes back to standby mode, ready for the next recording. momentarily.

You can check the recorded picture inside the viewfinder. After checking, you can also rerecord over a previously recorded portion. To check your recorded picture

1 Set the camcorder in standby mode by turning STANDBY up.

+ side: to view the forward playback picture – side: to view the reverse playback picture Press EDITSEARCH softly to transport the tape at normal speed or firmly to transport 2 Keep pressing the + side or - side of EDITSEARCH to play back the picture while looking inside the viewfinder. the tape at high speed.

portion, follow the procedures below:

Press the + side or - side of
EDITSEARCH to locate the point you want To stop playback, release EDITSEARCH. 3 If you want to re-record over a recorded

Re-recording begins from the point you released EDITSEARCH. As long as the tape is not ejected, the transition between to begin re-recording.

Press START/STOP to begin re-recording. the scenes will be smooth.

Press it softly to transport the tape at normal speed (◀ or ₱ appears inside the viewfinder), or firmly to transport the tape at high speed (⊕ or ⊕ appears inside the viewfinder). The camcorder's EDITSEARCH button offers **Dual speed EDITSEARCH button** dual speed transport of the tape.

26

25

— 15 —

(<del>K</del>-1)

[a]

(F-1)

[b] Subjects with little contrast—wall, sky, etc. [a] Too bright behind the subject

[c] Horizontal stripes [d] Subject through frosted glass

Insufficient light

One subject is close; the other is in the center, but at a distance

Subjects beyond nets, etc., or another subject passes in front of the camcorder

豆

2

0000

When shooting a stationary subject using Bright subject or subject reflecting light
 High contrast behind the subject (the background may be in focus)

When you want to save battery power

Focusing Manually (K-2)

FOCUS

(0)

(<del>K</del>-2)

1 Press FOCUS.
The ( (manual focusing) indicator appears inside the viewfinder.

**— 16** —

2 Keep pressing the T side of the power zoom button until the zooming stops (telephoto).

3 Turn the focus dial to achieve sharp focus.

4 Keep pressing the W side of the power zoom button to obtain the desired subject size.

To reactivate autofocusing Press FOCUS again so that the (₺ indicator disappears. Shooting in relatively dark places Shoot at wide angles after focusing in telephoto.

S

Note
The focus dial does not have a stop position.

# Jsing the PROGRAM

When you use the PROGRAM AE (Auto Exposure) function, you can create a "portrait" effect or capture high-speed action using the "sports" mode or "high-speed shutter" mode. When you record fireworks or neon signs, use "twilight" mode.

(5-1)

Set the white mark of the PROGRAM AE dial to the desired PROGRAM AE mode. The indicator of the selected PROGRAM AE mode appears inside the viewfinder.

The PROGRAM AE mode indicator changes as follows:

"Portrait" mode)

No indicator (normal mode)

("Sports" mode)

T ("High-speed shutter" mode)

REC 0:13:15

AE

To restore automatic adjustment Set the white mark of the PROGRAM AE dial to the

green position.

("Twilight" mode)

27

28

## To select the mode

(L-2)

## (F-2)

You may want to use the respective mode when shooting the following subjects or when shooting under the following conditions:

You can fade-in or fade-out to give your recording a professional touch.

When fading-in, the picture will gradually appear

Fade-out

Fade-in and

-

(

(

(M-1)

When fading-out, the picture will gradually fade

to black or mosaic. The sound will also

gradually decrease.

from black or mosaic. The sound will also

gradually increase.

# A still subject such as a person or flower

- [a] B Portrait mode
- · Zooming on a subject in the telephoto mode Subject behind an obstacle such as ■ net

 Recording a landscape while in a moving car
 Outdoor sports scene such as football or [b] K Sports mode

· Subjects moving at high speed, such as a

<u>ত</u>

roller coaster on a cloudy day

ē

lc] \*\* High-speed shutter mode
• Shooting a golf swing or a tennis match with the tennis ball captured clearly on a fine day the tennis ball captured clearly on a fine day or you wish to play back certain scenes having high speed movement and getting a clear, sharp picture

[d] J Twilight mode
• Recording a night view, fireworks, or neon

## Note

(M-2)

as follows:

The shutter speed in each PROGRAM AE mode is

Portrait mode — between 1/80 to 1/2000
 Sports mode — between 1/60 to 1/500
 High-speed shutter mode — 1/4000
 Twilght mode — 1/60

Fading-in or fading-out (M-2)
Each time you press FADER, the indicator inside
the viewfinder changes as follows:

M. FADER (mosaic fade) (black fade) FADER (No indicator) →

# Select the type of fade by pressing FADER

- [a] When fading-in, press FADER after turning STANDBY up to put the camcorder into standby mode. as follows:
  - The fade indicator starts flashing.

    (b) When fading-out, press FADER while The fade indicator starts flashing. recording.

## Press START/STOP. N

When fading-in, the fade indicator stops flashing and the recording starts fading-in. When fading-out, the fade indicator stops flashing and the picture fades out and then the recording stops.

Before pressing START/STOP, press FADER until the fade indicator disappears. To cancel the fade-in/fade-out function before it is performed

FADE IN (M-1)

FADER 2 | FADER

29

30

This camcorder has a world clock. While traveling abroad, you can easily adjust time of the place where you are using the camcorder by Before pressing AREA, set the date and time in your country (see page 19). pressing AREA.

Ŝ

1 While pressing the green button, set the POWER switch to CAMERA.

2 Turn STANDBY up to set the camcorder in standby mode. 3 Press TIME (NEXT).
The time in your country appears inside the viewfinder. Press AREA until the area name and number where you are now using the camcorder

appear.
You can find the area name and number in the "Time Zone Chart" on the pages 32 and 33.

To check the date
Press DATE (+).
To turn off the date indication, press DATE (+)


again.


To reset to your country area time Press AREA until your country area and number

32 31

**— 18** —

(<u>k</u>-1





(N-2)

20 NEW YORK 11:30:00

# 20 NEW YORK 12:30:00

To set summer time (N-2)
Press SUMMERTIME. Time changes to summer time: ★ indicator appears inside the viewfinder. To set to standard time, press SUMMERTIME again.

# \* These are common names. The formal names may be different.

# Playing Back a Tape

Turn on the TV, and select the channel for viewing a playback picture (set the TV/VIDEO selector to VIDEO). Of course, you can monitor the playback picture inside the viewlinder at the same time. (P-1)

(P-1)

1 White pressing the green button, set the POWER switch to PLAYER.

2 Insert a tape.

3 Press ▷. Playback starts.

2

To view a still picture, press II during playback. To resume playback, press II or ⊳ again.

ites

 When still picture mode lasts for 5 minutes or more, the camcorder automatically enters stop mode.
 Streaks appear and sound is muted in still picture mode.

mode. To rewind the tape, press ▲4.

To advance the tape raidly, press

To stop the tape momentarily, press II.

In playback pause mode, you can view the picture in a sequence of stop-motion images by pressing EDITSEARCH. If you keep pressing EDITSEARCH, you can view the picture playback in the forward or reverse direction.

To check the remaining time of the tape during playback (P-2) in playback mode, the remaining tape length indicator appears inside the viewfinder and changes as illustrated.

S[.....]E -----B

(P-2)

S E A----S

33

## Playing Back a Tape

# Monitoring a High-Speed Picture

£

To locate a scene (picture search)
Keep pressing ←← or ▶▶ during playback. You can monitor the picture at high speed as long as To resume a normal playback, release the button. you keep pressing the button.

ė

Ė

You can monitor the picture at high speed as long as you keep pressing the button. To resume a normal fast forwarding or rewinding, release the button.

To resume a normal playback, press ▷. To locate a scene quickly (skip scan)
Keep pressing ◄◀ during rewinding, or ▶▶
while advancing the tape rapidly.

# Displaying the Viewfinder Screen Indicators on the TV

Press DATA SCREEN on the Remote (P-3)

To erase the indicators, press DATA SCREEN Commander.
The indicators inside the viewfinder screen appear on the TV.

- $\epsilon$
- [a] Manual focusing
- [b] Setting of PROGRAM AE mode
- [c] FADER is pressed.

[d] Power zoom indicator

- [e] "Replace battery."
- [f] "Moisture has condensed."

0:00:25

0

FADER 1

<u>5</u>

틸


- [g] "Replace lithlum battery."
- [h] Recording/Playback mode (LP/SP)
- [i] Tape transport and camera recording mode
- [k] Remaining tape length indicator

(i) Tape counter

AUTO


Ė Ξ

- [i] "Exchange tape or no cassette inside."
- [m] The lens cover is closed.
- [n] Remaining battery Indicator
- [o] "Clean video heads (⊗)" or "trouble has occurred (♠)".
- [p] World clock indicator
- [q] Auto date indicator
  - [r] Date or time
- [s] Lights up during recording. When flashing: "Replace battery."




## **SECTION 2** DISASSEMBLY


## 2-1. REMOVAL OF F PANEL ASSEMBLY




## 2-2. REMOVAL OF CASSETTE LID ASSEMBLY

## 2-3. REMOVAL OF CABINET (L) ASSEMBLY







## 2-4. REMOVAL OF CABINET (R) ASSEMBLY




## 2-5. REMOVAL OF CF-32, ED-35 AND VK-27 BOARDS




## 2-6. REMOVAL OF DD-48 AND SW-205 BOARDS




## 2-7. REMOVAL OF LS LID ASSEMBLY




## 2-8. REMOVAL OF JK-91 AND AU-138 BOARDS




## 2-9. REMOVAL OF LENS ASSEMBLY (CD-92 BOARD)




## 2-10. OPENING OF VC-122 BOARD






## 2-12. REMOVAL OF SL-27 BOARD




## 2-13. REMOVAL OF EVF ASSEMBLY (VF-42 BOARD)




## 2-14. INTERNAL VIEWS

## - Left side -




## - Right side -





## CCD-TR303E/TR303EP


## SECTION 3 DIAGRAMS


## 3-1. CIRCUIT BOARDS LOCATION












#### 3-4. CAMERA MICROPROCESSOR PIN FUNCTION (IC709 ON VC-122 BOARD: CXP80624-424R/434R)

Pin No.	Signal	I/O	Function
1	ZOOM M REV	0	Zoom motor control signal. Normally "L". 20 msec period PWM signal when rotating to WIDE. "H" when rotating to TELE.
2	ZOOM M FWD	0	Zoom motor control signal. Normally "L". 20 msec period PWM signal when rotating to TELE. "H" when rotating to WIDE.
3			
4			Not used.
5			
6	FOC END LED	0	Focus end sensor LED control signal. Normally "L".
7	RT05/D5		Not used.
8	CORE RESET	0	Camera core (IC707 on VC-122 board) reset signal. Normally "H". "L" when reset.
9	PDR RESET	0	Focus predriver (IC706 on VC-122 board) reset signal. Normally "H". "L" when reset.
10			Notice
11	TG STBY0		Not used.
12	OPD RESET	0	OPD (IC705 on VC-122 board) reset signal. "H": camera mode. "L": VTR mode.
13			
14			·
15			
16			N.A.
17			Not used.
18			
19			
20			
21	EPROM DO	0	Connected to +5V.
22	EPROM BUSY	I	BUSY signal from EEPROM. Normally "H". "L" pulse when data reading/writing.
23			N
24			Not used.
25			Connected to GND.
26			Connected to +5V.
27	WIDE END		Focus Zone sensor input. Normally "L".
28	FOC END FAR	I	Focus edge sensor input. Normally "L".
29	CAM ON	0	Power supply control signal. Normally "L".
30			
31			
32			
33			Not used.
34			
35			
36			
37	MP		Connected to GND.
38	CAM RESET	I	Reset signal input. Normally "H". "L" when reset.
39	VSS		GND
40	XTAL	0	12 MHz clock ozcillation circuit
41	EXTAL	I	12 MHz clock oscillation circuit.
42	CS CAM	I	Chip select signal from mode control microprocessor. (IC403 on VS-95 board)
43	VTR SI	I	Serial data input from mode control microprocessor.
44	VTR SO	0	Serial data output from mode control microprocessor.
45	VTR SCK	I	Serial data transfer clock.
46			
47			Not used.
48		1	


Pin No.	Signal	I/O	Function	7
49			Not used.	7
50	AVSS		GND	1
51	AVREF		Analog input port reference voltage (5V).	1
52	AVDD		Analog input port voltage (5V).	1
53			Connected to GND.	1
54			Connected to GIVD.	
55	MAN FOCUS (2)	I	Manual focus input. 0 to 5 Vdc.	1
56	MAN FOCUS (1)	I	Manual focus input. 0 to 5 Vdc.	1
57	ZOOM SW	I	Zoom key input. 0.4V: F. TELE, 1.4V: TELE and 3.7V: F. WIDE, 2.5V: WIDE and 5V: no input.	1
58	ZOOM POS X4	I	Zoom position voltage. approx. 0.4V (WIDE end) to approx. 2.8V (TELE end).	1
59	HALL A/D	I	Hall voltage. approx. 1V (iris open) to approx. 3V (iris close).	1
60	ZOOM POS	I	Zoom position voltage. approx. 0.2V (WIDE end) to approx. 2.4V (TELE end).	1
61			Connected to 5V.	1
62	PB V	I	VD signal input from mecha controler (IC402 on VS-95 board).	1
63	PG5/SYNC1			1
64	VTR SYNC			
65	PB CTL		Connected to +5V.	
66	DPG			1
67				
68	AF BUSY	I	AF busy signal.	<u>\$</u>
69				1
70				١
71			Not used.	
72				
73	IRIS PWM	0	Iris control signal. 21 µsec period PWM signal.	$\dashv$
74	ZM PWM	0	Zoom position detection voltage output. 21 µsec period PWM signal.	$\forall$
75			Not used.	+
76			Connected to +5V.	$\dashv$
77	CAM SI	I	Serial data input.	1
78	CAM SO	0	Serial data output.	┨
79	CAM SCK	0	Serial data transfer clock.	$\forall$
80	AJST	I	Adjustment timing pulse input. Normally "H".	┨
81	PI/TO		The state of the s	1
82	PI/PWM		Not used.	
83	PI/PO		110t dised.	
84	PIO			+
85	PKO		Connected to +5V.	
86	GND		GND	+
87	VDD		GND	+
	VPP		+5V power supply.	ı
88	YFF		Not year	+
	CS PDR	1	Not used.  Chin select signal to feeue and fives (IC206 on VC 122 heart)	$\dashv$
90	CS PDR  CS CAM D/A	0	Chip select signal to focus predriver (IC706 on VC-122 board).	4
91		0	Chip select signal to camera EVR (IC702 on VC-122 board).	+
92	CS ROM	0	Chip select signal to EEPROM (IC712 on VC-122 board).	4
93	CS OPD	0	Chip select signal to OPD (IC705 on VC-122 board).	-
94	NTSC	0	NTSC: "L", PAL: "H".	4
95	CS CORE	0	Chip select signal to camera core (IC707 on VC-122 board).	4
96	CS TG	0	Chip select signal to timing generator (IC801 on VC-122 board).	4
97	00.40		Not used.	-
98	CS A/D	0	Chip select signal to Zoom position A/D converter. Not used.	4
99			Not used.	
100				


#### 3-5. CAMERA (2) BLOCK DIAGRAM


nd 5V: no input.




#### 3-6. VIDEO (1) BLOCK DIAGRAM













#### 3-8. SERVO BLOCK DIAGRAM









## 3-10. MECHANISM CONTROL MICROPROCESSOR PIN FUNCTION (IC402 ON VS-95 BOARD: CXP80624)

Pin No.	Port Name	Signal	1/0	Connection	Function
1	PB3/PP011	RP PB MODE	О	VS	REC/PB select signal of REC/PB amplifier (IC001 on VS-95 board) and ATF servo IC (IC404 on VS-95 board). "H": PB.
2	PB2/PP010	FE ON	0	VS	Flying erase oscillation ON/OFF control signal. "L": oscillation.
3	PB1/PP09	JOG VD	0	VS	False VD signal to be inserted into playback video signal during variable speed playback.
4	PB0/PP08	JOG	0	vs	Variable speed/normal speed playback select signal of video circuit. "H" when variable speed playback.
5	PC7/RT07	JACK ĪN/OUT	I	VS	Not used. Connected to +5V.
6	PC6/RT06	1.7M DET	I	VS	
7	PC5/RT05	JACK MONO/STE DET	I	vs	Not used.
8	PC4/RT04	INT VD	I		
9	PC3/RT03	PB V (SYSTEM SYNC)	0	MODE CON	V sync for mode controller.
10	PC2/RT018	SYNC DET OUT	0	VS	Sync detect output. "L" when Sync is detected.
11	PC1/RT017	E/L DET	I	VS	
12	PC0/RT016	MIC MONO/ST DET	ı	AU	Not used.
13	PJ7	M SW 0	ī	MD	BL END EJECT USE LOAD READY TURN REC/PB FF
14	PJ6	M SW 1	I	MD	Mode switch M SW 0 L L L H L H H L L
15	PJ5	M SW 2	ī	MD	input.   M SW 1 L H L L L L H H L   L   L L L L L L L L
16	PJ4	CC DOWN	I	MD	Cassette compartment down switch input. "L": down.
	PJ3	REC PROOF	I	MD	Erasure protection switch input. "L" when REC prohibit.
17	<del> </del>	ME/MP	I	MD	ME/MP switch input. "L": MP, "H": ME.
18	PJ2	HG/NOR	1	MD	Connected to GND.
19	PJ1		<del> </del>		Video output mute signal. "H": mute.
20	PJ0	VIDEO MUTE	0	VS	Video output mute signal. 11 . mute.
21	PD7	LINE MIX	I	VS	
22	PD6	MAT SEL 1	l	VS	No. and
23	PD5	MAT SEL 2	I	VS	Not used.
24	PD4	MAT ON/OFF	0	VS	
25	PD3	E MODE	0	VS	
26	PD2	CAM/LINE	0	VS	Camera input/line input select signal. "H" when camera input.
27	PD1	DS ON	0	VS	Data screen ON/OFF signal. "H": ON.
28	PD0	EDIT	0	VS	Video circuit EDIT/NORMAL switch signal. "L": EDIT.
29	PH7	UNLOAD	0	VS	Loading motor control signal. "H" or "H" pulse when unloading.
30	PH6	LOAD	0	VS	Loading motor control signal. "H" or "H" pulse when loading.
31	PH5	LM LIM COM	0	VS	Loading motor limiter control signal. Temporary "H" when loading.
32	PH4	COMP REC	0	VS	Not used.
33	PH3	DRUM REV	0	VS	Drum rotating control signal . Normally "L".
34	PH2		0		N.C.
35	PH1		0		19.0.
36	PH0	REEL HALL CONT	0	VS	Reel FG sensor (HALL element) power supply control signal.
37	MP	MP			Connected to GND.
38	RST	RESET	I	MODE CON	Reset signal from mode control microprocessor. "L" when reset.
39	VSS	VSS			GND
40	XTAL	XTAL	I	VS	
41	EXTAL	EXTAL	0	VS	11.89 MHz clock oscillation circuit.
42	CSO	VTR COSMO CS	I	MODE CON	Chip select signal from mode control microprocessor (VS-95 board IC403)
43	S10	DATA TO SLVE	I	MODE CON	Serial data input from mode control microprocessor.
44	S00	DATA TO MSTR	0	MODE CON	
	1 000		<u> </u>		

PF7/AN11 PF6/AN10	AUDIO MUTE			
DE6/AN10	AUDIO MUTE	0	VS	Audio output mute signal. "H": mute.
110/2010	1.7M OFF	0	VS	Not used.
PF5/AN9	GND	I		
PF4/AN8	GND	I		GND
AVSS	AVSS			Analog port GND.
AVREF	AVREF			Analog port reference voltage. Connected to +5V.
AVDD	VDD			Analog port power supply (5V).
PF3/AN7	N.C.	1		Connected to GND.
PF2/AN6	END SENS	I	VS	Tape end detection signal. Normally "L", "H" pulse: tape end.
PF1/AN5	TOP SENS	I	VS	Tape top detection signal. Normally "L", "H" pulse: tape top.
PF0/AN4	DEW	I	VS	Dew condensation detection signal. "L" when dew condensation.
AN3	BATT SENSE	I	VS	Battery voltage input for battery end detection. 1/2 divided by RB401.
AN2	ATF ERROR	ı	VS	ATF error, ATF lock error input.
AN1	S REEL FG	I	VS	S reel FG signal input.
AN0	T REEL FG	I	VS	T reel FG signal input.
PG7/EXII	PG7 (N.C.)			Connected to GND.
PG6/EXI0	CAM VD	I	CAM SG	VD signal from camera circuit sync generator. V period pulse.
PG5/SYNC1	FLD	I	CAM SG	FIELD signal from camera circuit sync generator. 2V period pulse.
PG4/SYNC0	VTR SYNC	I	VS	Composite sync signal separated from REC/PB Y signal.
				Discriminates PB tape REC mode when CUE/REVIEW/FF and REW.
PG3/PBCTL	PB SP/LP DET	I	VS	"L": LP.
PG2/DPG	DRUM PG	I	VS	Drum PG signal input. For drum phase servo 40 msec period "H" pulse.
PG1/DFG	DRUM FG	I	VS	Drum FG signal input. For drum speed servo 3.3 msec period pulse.
PG0/CFG	CAP FG	I	MD	Capstan FG signal input. For capstan speed servo. Approx. 1388 Hz when REC/PB (SP).
PE7/DAB0	N.C.	0		N.C.
			VS	Tape LED ON/OFF signal. 100 msec period "H" pulse when REC/PB.
	N.C.	0		
PE4/DAA0	N.C.	0		N.C.
	CAP PWM	_	VS	Capstan error signal output 20.15 µsec PWM signal.
PE2/PWM0	DRUM PWM	0	VS	Drum error signal output 20.15 μsec PWM signal.
PE1/EC/INT2	C FG	I	MD	Capstan FG signal input. For tape counter.
	S JACK IN			Not used, connected to +5V.
P17/ST1		1	VS	Control L serial data input.
	· · · · · · · · · · · · · · · · · · ·	0	VS	Control L serial data output.
P15/SCK1	LM LIMIT DET	I	VS	Loading motor limiter ON detection signal. Normally "H", "L" when limiter ON.
P14/INT1	AGC SLOW			Not used.
		0	VS	Drum driver ON/OFF control signal. "H" when drum ON.
			<b>+</b>	Head clog detection signal. "L" when no trouble.
P11/PO	REF PILOT	0	vs	ATF servo reference pilot signal. Synchronized when drum rotation to output by selecting four frequencies. f1=101.0 kHz, f2=117.2 kHz, f3=162.8 kHz and f4=146.5 kHz.
P10/PCK				Connected to +5V.
PKO	13/10 SW	I	MD	Not used.
				GND
	<del>"</del>	-		VDD
<u> </u>				Connected to +5V.
	, ,		VS	Drum motor acceleration signal. Not used.
	AVDD PF3/AN7 PF2/AN6 PF1/AN5 PF0/AN4 AN3 AN2 AN1 AN0 PG7/EXI1 PG6/EXI0 PG5/SYNC1 PG4/SYNC0 PG3/PBCTL PG2/DPG PG1/DFG PG1/DFG PE7/DAB0 PE6/DAB0 PE5/DAA1 PE4/DAA0 PE3/PWM1 PE2/PWM0 PE1/EC/INT2 PE0/INT0 P17/ST1 P16/SO1 P15/SCK1 P14/INT1 P13/TO P12/PWM	AVDD         VDD           PF3/AN7         N.C.           PF2/AN6         END SENS           PF1/AN5         TOP SENS           PF0/AN4         DEW           AN3         BATT SENSE           AN2         ATF ERROR           AN1         S REEL FG           PG7/EXI1         PG7 (N.C.)           PG6/EXI0         CAM VD           PG5/SYNC1         FLD           PG4/SYNC0         VTR SYNC           PG3/PBCTL         PB SP/LP DET           PG2/DPG         DRUM PG           PG1/DFG         DRUM FG           PG1/DFG         DRUM FG           PE7/DAB0         N.C.           PE6/DAB0         T/E LED ON           PE5/DAA1         N.C.           PE4/DAA0         N.C.           PE3/PWM1         CAP PWM           PE1/EC/INT2         C FG           PE0/INT0         S JACK IN           P17/ST1         LANC OUT           P15/SCK1         LM LIMIT DET           P14/INT1         AGC SLOW           P13/TO         DRUM ON           P12/PWM         CLOG           P11/PO         REF PILOT           P10/PCK	AVDD         VDD           PF3/AN7         N.C.           PF2/AN6         END SENS         I           PF1/AN5         TOP SENS         I           PF0/AN4         DEW         I           AN3         BATT SENSE         I           AN2         ATF ERROR         I           AN0         T REEL FG         I           PG7/EXI1         PG7 (N.C.)         PG6/EXI0           PG6/EXI0         CAM VD         I           PG5/SYNC1         FLD         I           PG4/SYNC0         VTR SYNC         I           PG3/PBCTL         PB SP/LP DET         I           PG3/PBCTL         PB SP/LP DET         I           PG2/DPG         DRUM PG         I           PG1/DFG         DRUM FG         I           PE7/DAB0         N.C.         O           PE6/DAB0         T/E LED ON         O           PE5/DAA1         N.C.         O           PE4/DAA0         N.C.         O           PE3/PWM1         CAP PWM         O           PE2/PWM0         DRUM PWM         O           PE1/EC/INT2         C FG         I           PE0/INT0	AVDD VDD

 Pin No.
 Po

 90
 PAG

 91
 PAG

 92
 PAG

 93
 PAG

 94
 PAG

 95
 PAG

 96
 PAG

 97
 PBG

 98
 0

 99
 11

 100
 PB

Pin No.	Port Name	Signal	1/0	Connection	Function
90	PA6/PP06	DRUM BRK	0	VS	Drum motor brake signal. Normally "L".
91	PA5/PP05	SP/LP	0	VS	SP/LP select signal. "L": LP.
92	PA4/PP04	AU IN/OUT	0		Not used.
93	PA3/PP03	VIDEO O SW	0	VS	VIDEO OUT inhibit signal. "H": inhibit.
94	PA2/PP02	VIDEO I SW	10	VS	VIDEO IN/OUT select signal. Not used.
95	PA1/PP01	VA PB MODE	0	ALL	Video/audio circuit REC/PB select signal. "H": PB.
96	PA0/PP00	VI SWP	0	VS	
97	PB7/PP015	RF SWP	0	ALL	RF switching pulse signal for video circuit. 25 Hz, 50% duty pulse.  RF switching pulse signal for REC/PB amp and Audio circuit. 25 Hz, 50% duty pulse.
98	0	H CHG	0	VS	Not used.
99	11	CAP ON	0	MD	Capstan driver ON/OFF control signal. "H" when capstan ON.
100	PB4/PP012	CAP FWD/RVS	0	MD	Capstan rotating direction control signal. "H": FWD, "L": RVS.

tion. v RB401.

pulse.

nd REW.

'H" pulse. pulse. 88 Hz

REC/PB.

when

tion to

## 3-11. MODE CONTROL MICROPROCESSOR PIN FUNCTION (IC403 ON VS-95 BOARD: μPD75316)

Pin No.	Port Name	Signal	I/O	Connection	NCTION (IC403 ON VS-95 BOARD: µPD75316)
1	S12	S12	0		T directory
2	S13	S13	0		
3	S14	S14	0		
4	S15	S15	0		
5	S16	S16	0		7
6	S17	S17	0		Segment terminal drive signal to LCD.
7	S18	S18	0		(Four value output of 0, 1.7, 3.3, 5V) Not used.
8	S19	S19	0		1100 doed,
9	S20	S20	0		
10	S21	S21	0		-
11	S22	S22	0		· ·
12	S23	S23	0		1
13	S24/BP0	EEPROM CS	0		Chip select signal to EEPROM (IC406 on VS-95 board). 1/2V period "L" pulse.
14	S25/BP1	N.C	0		Not used.
15	S26/BP2	TG STBY 1	0	CAM	Power save control signal to timing generator (IC801 on VC-122 board Normally "L".
16	S27/BP3		0		N.C.
17	S28/BP4	CS TITLE	0	CAM	Not used.
18	S29/BP5	REMO CS	0	Crim	Chip select signal to sircs remote controller (IC907 on VS-95 board). IN period "L" pulse.
19	S30/BP6	S RAM CS	0		Not used.
20	S31/BP7	CAM COSM CS	0	CAM	Chip select signal to camera controller (IC709 on VC-122 board). 1V period "L" pulse.
21	СОМО	COM 0	0		period L puise.
22	COM1	COM 1	0		Common terminal drive signal to LCD.
23	COM2	COM 2	0		(Four value output of 0, 1.7, 3.3, 5V)
24	СОМЗ	COM 3	0		Not used.
25	BIAS	BIAS	0		Discovelters and of
26	VLC0	VCC 0	1		Bias voltage output for voltage deviding resistor. Not used.
27	VLC1	VCC 1	I		Power source 1 input  Power source 1 input  Power source for LCD dirve.
28	VLC2	VCC 2	I		Not used.
29	P40	K OUT 4		all	Power source 2 input
30	P41	K OUT 5	-+-+	all	KEY matrix output. 1V period "L" pulse output when corresponding key is pressed. "L" when other cases.
31	P42	SYS RESET	<del></del>	all	
32	P43	TALLY		EVF	Output signal to reset each IC when power is turned on. Normally "H".  Tally LED ON/OFF signal. "L": ON.
33	VSS	VSS	-		GND
34	P50	K OUT 0	0 8	all	OND
35	P51	K OUT 1			KEY matrix output.
36	P52	K OUT 2	+	11	1V period "L" pulse output when corresponding key is pressed. "L"
37	P53	K OUT 3		11	when other cases.
38	P00/INT4	BATTIN	I		Clock select to 32 kHz when "L" and to 4.19 MHz with "H" when Battery is turned on. "L" is select.
39	P01/SCK	SCK	O a		
	P02/SO/SB0	DATA TO SLVE	O a		Serial clock output terminal, Serial clock (2 µS) communication.
	P03/SI/SB1	DATA TO MSTR	I a		Serial bus output terminal, Serial clock (2 \( \mu S \)) communication.
			, a	I .	Serial bus input terminal, Serial clock (2 $\mu$ S) communication.
42 I	P10/INT0	SYSTEM SYNC	I a		(Edge detection vector interruption), System synchronization input port from CXP80624 (IC402 on VS-95 board).

Pin No.	Port Name	Signal	1/0	Connection	Function
43	P11/INT1	LI PRE END	I		(Edge detection vector interruption), Lithium PRE END is selected with "L".
44	P12/INT2	LANC PWR ON	I		Power on signal input from wired remote control. "L" when power switch pressed.
45	P13/TIO	TITLE BUSY	I	CAM	Not used.
46	P20/PT00	VTR DD ON	0	PS	VTR power source (VIDEO 5V, RP 5V, AUDIO 5V, EVF 5V, D5V, (SS5V), D4V, CORE 4V) control signal. "H" when power switch is in "PLAYER" or "CAMERA" position.
47	P21	CAM DD ON	0	PS	CAMERA power source (CAM 5V, +15V, -9V) control signal. "H" when power switch is in "CAMERA" position.
48	P22/PCL	VIDEO D/A CS	0	VA	Serial data load signal to video circuit EVR (IC156, 158 on VS-95 board). IV period "H" pulse.
49	P23/BUZ	BEEP	0		Buzzer output. Normally "L". 2 kHz pulse: alarm.
50	P30/LCDCL	VIDEO CS	0	VA	Chip select signal to Y process IC (IC151 on VS-95 board). IV period "L" pulse.
51	P31/SYNC	VTR COSM CS	0		Chip select signal to mechanism controller (IC402 on VS-95 board). 1V period "L" pulse.
52	P32	SG CS	0	CAM	Chip select signal to sync generator (IC704 on VC-122 board). IV period "L" pulse.
53	P33	CRTC CS	0	CAM	Strobe signal for character generator (IC406 on VS-95 board). 1V period "H" pulse.
54	VDD	VDD			VDD
55	XT1	XT1	I		SUB system clock.
56	XT2	XT2			32 kHz oscillation terminal.
57	N.C.	N.C.			N.C.
58	X1	X1	I		Main system clock.
59	X2	X2	I		4.19 MHz oscillation terminal.
60	P60/KK0	K IN 0	I	all	
61	P61/KR1	K IN 1	1	all	
62	P62/KR2	KIN 2	I	all	KEY matrix input.
63	P63/KR3	K IN 3	I	all	1V period "L" pulse input when corresponding key is pressed. "H" when
64	P70/KR4	K IN 4	1	all	other case.
65	P71/KP5	K IN 5	I	all	
66	P72/KP6	K IN 6	1	all	
67	P73/KP7	CC DOWN	I	MD	Cassette compartment lock switch input. "L": Lock.
68	RESET	RESET	I		System reset input. "L": Reset, Normally: "H".
69	S0	CLK CHK	0		N.C.
70 71	S1 S2	S1	0		
72	S2 S3	S2 S3	0		
73	S3 S4	\$3 \$4	0		
74	S5	S5	0		
75	\$6	\$6	0		Segment terminal drive signal to LCD.
76	S7	S7	0		(Four value output of 0, 1.7, 3.3, 5V) Not used.
77	S8	S8	0		
78	S9	S9	0		
79	S10	S10	0		
80	S11	S11	0		

#### 3-12. INTERFACE

#### 3-12-1. System Control – Video/Audio Block Interface (VS-95 BOARD)

				,	J					VTR	MODE		
NAME	I/O	No.	STOP	FF	REW	FR SE	ARCH	PB	PICTURI	SEARCH	PB•	FRAME	SLOW
				, ,		CUE	REVIEW		CUE	REVIEW	PAUSE	FRAME	SLUVV
SP/LP	0	IC402 ⑨	*1	н	Н	*2	*2	*2	*2	*2	*1	*1	*1
VA PB MODE	0	IC402 ®	L	L	L	Н	н	н	Н	н	Н	Н	Н
AUDIO MUTE *13	0	IC402 46	L	L	L	Н	Н	L	Н	н	Н	Н	н
VIDEO MUTE	0	IC402 20	*14	*14	*14	*15	*15	* 15	*15	*15	*15	*15	*15
CAM/LINE	0	IC402 🚳	L	L	L	L	L	L	L	L	L	L	L
JOG VD	0	IC402③	L	L	L	*5	*5	L	*5	*5	*5	*5	*5
RP PB MODE	0	IC402①	н	н	Н	н	н	н	Н	Н	н	Н	н
FE ON	0	IC402②	Н	Н	н	н	н	Н	н	Н	Н	Н	Н
RF SWP	0	IC402 🕅	L	*7	*7	*7	*7	*7	*7	*7	*7	*7	*7
log	0	IC402 4	L	L	L	Н	Н	L	Н	н	Н	Н	н
VIDEO CS	0	IC403 50											V period '
VIDEO D/A CS	0	IC403 🚳						•					V period '
DATA TO MSTR	I	IC403 🚯											V period '
DATA TO SLVE	0	IC403 @					, , , , , , , , , , , , , , , , , , , ,					,	√ period p
SCK	ł	IC403 😘										, , , , , , , , , , , , , , , , , , ,	V period "
PB SP/LP DET	ı	IC402 🚳	L	*10	*10	*10	*10	L	*10	*10	* 10		
CLOG	ı	IC402 🕸	н	*11	*11	*11	*11	*11	*11	*11	*11	*11	*11
VTR SYNC	1	IC402 🚱	*12	*12	*12	*12	*12	* 12	*12	*12	*12	* 12	*12

<sup>\*1.</sup> Outputs discrimination result of the mode just before. "H": SP mode, "L": LP mode.

Outputs discrimination result of the playback tape. "H": SP mode, "L": LP mode.

<sup>\*3.</sup> Edit search button pressed when playback pause mode.

<sup>\*4.</sup> Mode for adjustment.

<sup>\*5.</sup> False VD signal

By REC MODE switch, "H": SP mode, "L": LP mode.

<sup>\*7. 25</sup> Hz duty 50% pulse (synchronized with drum rotation)

<sup>\*10. &</sup>quot;H": SP recording

<sup>\*11. &</sup>quot;H": no recording \*12. Composite sync s

video signal. (pola \*13. "H" during camer

<sup>\*14. &</sup>quot;L" when externa

<sup>\*15. &</sup>quot;H" when tape no

#### 3-12. INTERFACE

elected with

V, D5V, witch is in

nal. "H"

VS-95

1V period

board). 1V

d). IV period

l). 1V period

d. "H" when

#### 3-12-1. System Control – Video/Audio Block Interface (VS-95 BOARD)

										VTRI	MODE										CAMER	A MODE		
NAME	I/O	No.	STOP	55	DEW	FR SI	EARCH	22	PICTUR	E SEARCH	PB•				SHUTTL	E EDIT * 3	*	REC*4	STAND		EDIT S	EARCH	REC R	REVIEW
			3102	FF	REW	CUE	REVIEW	PB	CUE	REVIEW		FRAME	SLOW	X2	FWD	REV	REC*4	PAUSE	BY	REC	FWD	RVS	FWD	RVS
SP/LP	0	IC402 🕦	*1	н	н	*2	*2	*2	*2	*2	*1	*1	*1	*1	*2	*2	*6	H/L	H/L	*6	*2	*2	*2	*2
VA PB MODE	0	IC402 🗞	L	L	L	н	н	н	н	н	н	Н	н	Н	Н	Н	L	L	L	L	н	н	н	Н
AUDIO MUTE *13	0	IC402 46	L	L	L	Н	н	L	н	Н	н	Н	Н	L	Н	н	L.	L	L	L	Н	н	Н	н
VIDEO MUTE	0	IC402 20	*14	*14	*14	* 15	*15	* 15	* 15	*15	* 15	* 15	* 15	* 15	*15	*15	*14	*14	L	L	*15	*15	*15	*15
CAM/LINE	0	IC402 26	L	L	L	L	L	L	L	L	L	L	L	L	L	L	L	L	Н	Н	L	L	L	L
JOG VD	0	IC402③	L	L	L	*5	*5	L	*5	*5	*5	*5	*5	*5	*5	*5	L	L	L	L	*5	*5	*5	*5
RP PB MODE	0	IC402 ①	н	н	н	Н	Н	н	н	Н	Н	н	Н	н	н	н	L	н	Н	L	Н	н	Н	Н
FE ON	0	IC402②	н	Н	Н	Н	Н	н	н	Н	н	Н	Н	Н	н	Н	L	Н	н	L	н	Н	н	н
RF SWP	0	IC402 🕅	L	*7	*7	*7	*7	*7	*7	*7	*7	*7	*7	*7	*7	*7	*7	*7	*7	*7	*7	*7	*7	*7
JOG	0	IC402 ④	L	L	L	Н	Н	L	Н	н	Н	Н	Н	Н	Н	Н	L	L	L	L	н	н	н	н
VIDEO CS	0	IC403 🗐											V period	"L" pulse	•	1			· · · · · · · · · · · · · · · · · · ·	· · · · · · · · · · · · · · · · · · ·			<b>1</b>	
VIDEO D/A CS	0	IC403 48		-									V period	'H" pulse										
DATA TO MSTR	ı	IC403 41)											V period	"L" pulse										40
DATA TO SLVE	0	IC403 40			· · · · · · ·					,,,		\	/ period p	ulse train	1									
SCK		IC403 39		1770-1							· · · · · · · · · · · · · · · · · · ·	,	V period '	"H" pulse		•								
PB SP/LP DET	l	IC402 🚳	L	*10	*10	* 10	*10	L	*10	*10	* 10			*10	L	*10	Н	н	н	н	L	*10	L	*10
CLOG	ı	IC402®	н	*11	*11	*11	*11	*11	*11	*11	*11	*11	*11	*11	*11	*11	н	*11	*11	н	*11	*11	*11	*11
VTR SYNC	ı	IC402 🚱	*12	*12	* 12	*12	*12	*12	*12	*12	*12	*12	*12	* 12	*12	*12	* 12	*12	*12	*12	*12	*12	*12	*12

<sup>\*1.</sup> Outputs discrimination result of the mode just before. "H": SP mode, "L": LP mode.

<sup>\*2.</sup> Outputs discrimination result of the playback tape. "H": SP mode, "L": LP mode.

<sup>\*3.</sup> Edit search button pressed when playback pause mode.

<sup>\*4.</sup> Mode for adjustment.

<sup>\*5.</sup> False VD signal

<sup>\*6.</sup> By REC MODE switch, "H": SP mode, "L": LP mode.

<sup>7. 25</sup> Hz duty 50% pulse (synchronized with drum rotation)

<sup>\*10. &</sup>quot;H": SP recording area on tape. "L": LP recording area.

<sup>\*11. &</sup>quot;H": no recording area or drop out area on tape. Head clog detection input.

<sup>\*12.</sup> Composite sync signal input separated from line input video signal, camera video signal or playback video signal. (polarity +)

<sup>\*13. &</sup>quot;H" during camera mode load/unload.

<sup>\*14. &</sup>quot;L" when external input (video) present. "H" when other cases.

<sup>\*15. &</sup>quot;H" when tape no signal. "L" when other cases.

3-12-2. System Control - Servo Block Interface


							-			VTR	MODE										CAMER	A MODE		<del></del>
NAME	I/O	No.	STOP	FF	REW	FR SE	EARCH	PB	PICTUR	E SEARCH	РВ∙	50445			SHUTTLE	EDIT * 13	***	REC*14	STAND		EDIT S	EARCH	REC F	REVIEW
	ļ				11277	CUE	REVIEW		CUE	REVIEW	PAUSE	FRAME	SLOW	X2	FWD	REV	REC 14	PAUSE	BY	REC	FWD	RVS	FWD	RVS
T.REEL FG	ı	IC402 🚳	-	*1	*1	*1	*1	*1	*1	*1	*1	*1	*1	*1	*1	*1	*1	_	-	*1	*1	*1	*1	*1
S.REEL FG	1	IC402 🗐	_	*1	*1	*1	*1	*1	*1	*1	*1	*1	*1	*1	*1	*1	*1	_	_	*1	*1	*1	*1	*1
ATF ERROR	ı	IC402 58	-	*2	*2	*2	*2	*2	*2	*2	*2	*2	*2	*2	*2	*2	*2	*2	*2	*2	*2	*2	*2	*2
DRUM PG	1	IC402 🚳	_	*3	*3	*3	*3	*3	*3	*3	*3	*3	*3	*3	*3	*3	*3	*3	*3	*3	*3	*3	*3	*3
DRUM FG	ı	IC402 🗑	-	*4	*4	*4	*4	*4	*4	*4	*4	*4	*4	*4	*4	*4	*4	*4	*4	*4	*4	*4	*4	*4
CAP FG/ CFG HMS	ı	IC402 🚳 , 🔞	_	*5	*5	*5	*5	*5	*5	*5	*5	*5	*5	*5	*5	*5	*5	*5	*5	*5	*5	*5	*5	*5
CAP ON	0	IC402 ®	L	н	Н	Н	н	Н	Н	Н	L	*8	*8	н	н	Н	н	L	L	н	Н	Н	Н	н
REF PILOT	0	IC402 🚳	*7	*6	*6	*6	*6	*6	*6	*6	*6	*6	*6	*6	*6	*6	*6	*6	*6	*6	*6	*6	*6	*6
RP PB MODE	0	IC402①	Н	н	н	н	н	н	Н	Н	н	Н	н	н	Н	н	L	н	н	L	Н	н	Н	Н
DRUM REV * 10	0	IC402 🕸	Н	н	н	Н	н	Н	н	Н	Н	н	Н	Н	Н	н	н	н	н	н	н	Н	н	н
CAP FWD/ RVS	0	IC402 (0)	L	н	L	Н	L	н	н	L	L	*8	*8	н	н	L	н	L	L	н	н	L	Н	L
DRUM PWM	0	IC402 1/9	*9	*9	*9	*9	*9	*9	*9	*9	*9	*9	*9	*9	*9	*9	*9	*9	*9	*9	*9	*9	*9	*9
CAP PWM	0	IC402 ®	L	*9	*9	*9	*9	*9	*9	*9	L	*9	*9	*9	*9	*9	*9	L	L	*9	*9	*9	*9	*9
LM LIM CONT *11	0	IC402 (1)	L	L	L	L	L	L	L	L	L	L	L	L	L	L	L	L	L	L	L	L	L	L
DRUM ON *12	О	IC402 🗐	L	н	н	н	н	н	н	н	н	н	н	н	н	н	н	н	н	н	н	н	н	н

- \*1. Inputting waveform which is similar to sine wave according to reel rotation.
- \*2. ATF error voltage input
- \*3. One PG pulse input per one drum rotation, approx. 25 Hz.
- \*4. 12 FG pulses input per one drum rotation, approx. 300 Hz.
- \*5. 520 FG pulses input per one capstan rotation. Approx. 1388 Hz when REC/PB (SP). 694 Hz when PB (LP).
- \*6. Four frequencies output synchronized with drum rotation. f1=101.0 kHz, f2=117.2 kHz, f3=162.8 kHz and f4=146.5 kHz.


- \*7. f2 (117.2 kHz) output
- \*8. "H" pulse when tape run.
- \*9. 21.5 μsec period PWM signal
- \*10. Normally "H". Temporary "L" when load (drum reverse rotation).
- \*11. Temporary "H" when cassette loading (finger catch protection).
- \*12. "H": approx. 1.3 Vdc
- \*13. Edit search button pressed when playback pause mode.
- \*14. Mode for adjustment.


TR I	MODE					CAMERA MODE								
асн	PB.	FRAME	SLOW	X2	SHUTTLE	EDIT * 13	PEC*14	REC * 14	STAND	DEC	EDIT S	EARCH	RECP	EVIEW
IEW	PAUSE	FRAME	GLOW	A2	FWD	REV	HEC	PAUSE	BY	REC	FWD	RVS	FWD	RVS
1	*1	*1	*1	*1	*1	*1	*1	_	_	*1	*1	*1	*1	*1
1	*1	*1	* 1	*1	*1	*1	*1	_	_	*1	*1	*1	*1	*1
2	*2	*2	*2	*2	*2	*2	*2	*2	*2	*2	*2	*2	*2	*2
3	*3	*3	*3	*3	*3	*3	*3	*3	*3	*3	*3	*3	*3	*3
	*4	*4	*4	*4	*4	*4	*4	*4	*4	*4	*4	*4	*4	*4
•	*5	*5	*5	*5	*5	*5	*5	*5	*5	*5	*5	*5	*5	*5
	L	*8	*8	н	Н	н	н	L	L	Н	Н	н	Н	Н
	*6	*6	*6	*6	*6	*6	*6	*6	*6	*6	*6	*6	*6	*6
	н	н	н	н	Н	Н	L	н	н	L	Н	н	н	Н
	н	Н	Н	Н	н	н	н	н	н	н	н	н	н	н
	L	*8	*8	н	н	L	Н	L	L	Н	н	L	н	L
	*9	*9	*9	*9	*9	*9	*9	*9	*9	*9	*9	*9	*9	*9
	L	*9	*9	*9	*9	*9	*9	L	L	*9	*9	*9	*9	*9
	L	L	L	L	L	L	L	L	L	L	L	L	L	L
	н	Н	н	н	н	Н	н	н	н	н	н	н	н	н

- \*7. f2 (117.2 kHz) output
- \*8. "H" pulse when tape run.
- \*9. 21.5 μsec period PWM signal
- \*10. Normally "H". Temporary "L" when load (drum reverse rotation).
- \*11. Temporary "H" when cassette loading (finger catch protection).
- \*12. "H": approx. 1.3 Vdc
- \*13. Edit search button pressed when playback pause mode.
- \*14. Mode for adjustment.





#### 3-14. EVF BLOCK DIAGRAM













SECTION 4
PRINTED WIRING BOARDS AND SCHEMATIC DIAGRAMS





#### 4-2. PRINTED WIRING BOARDS AND SCHEMATIC DIAGRAMS

## THIS NOTE IS COMMON FOR PRINTED WIRING BOARDS AND SCHEMATIC DIAGRAMS. (In addition to this, the necessary note is printed in each block.)

- For printed wiring boards.
- O— : indicated a lead wire mounted on the component side.
- \_\_\_\_ : indicated a lead wire mounted on the conductor side.
- Parts mounted on the conductor side.
- Pattern from the side which enables seeing.

(The other layers'patterns are not indicated.)

- · Circled numbers refer to waveforms.
- (B) or (F), etc. of capacitors indicate the temperature characteristics.
- Through hole.

#### \* Caution:

Pattern face side:

Parts on the pattern face side seen from

(Conductor Side)

Parts face side:

the pattern face are indicated.

Parts on the parts face side seen from the

(Component side) parts face are indicated.

#### For schematic diagrams.

• Caution when replacing chip parts.

New parts must be attached after removal of chip.

Be careful not to heat the minuts side of tantalum capacitor, because it is damaged by the heat.

- All resistors are in ohms, 1/4W unless otherwise noted. Chip resistor are 1/10W unless otherwise noted.  $k\Omega:1000\Omega$ ,  $M\Omega:1000k\Omega$ .
- All capacitors are in  $\mu$ F unless otherwise noted. pF:  $\mu$   $\mu$ F. 50V or less are not indicated except for electrolytics and
- All variable and adjustable resistors have characteristic curve B, unless otherwise noted.
- w : nonflammable resistor.
- tusible resistor.
- : panel designation.
- 🛆 : internal component.
- : adjustment for repeair.\* : B+ Line.\*
- === : B- Line.\*
- ZZ : IN/OUT direction of (+, ) B LINE.\*
- Circled numbers refer to waveforms.\*

#### Note:

The components identi- fied by mark  $\triangle$  or dotted line with mark  $\triangle$  are critical for safty.


Replace only with part number specified.

When indicating parts by reference number, please include the board name.

\*: indicated by the color red.

## Measuring conditions voltage value and waveform. (CAMERA, DIGITAL TITLE block)

- The object is color bar chart of pattern box.
- Voltages are dc between ground and measurement points.\* Readings are taken with a digital multimeter (DC  $10M\Omega$ ).\*
- Voltage variations may be noted due to normal production tolerances.\*
- 1. Connection



2. Adjust the distance so that the output waveform of Fig. a and the Fig. b can be obtain.




Fig. a (Video output terminal output waveform)




Fig. b (Picture on monitor TV)

## (VIDEO, SERVO/SYSTEM CONTROL, LCD CONTROL, VIEW FINDER block)

- Voltages are dc between ground and measurement points.\*
- Readings are taken with a color-bar signal input.\*
- Readings are taken with a digital multimeter (DC10M $\Omega$ ).\*
- Voltage variations may be noted due to normal production tolerances.\*

#### CD-92 (CCD IMAGER) PRINTED WIRING BOAR

— Ref. No. CD-92 BOARD: 1000 series —

#### · For printed wiring boards.

- CD-92 board is the printed wiring board which has structure but inner two layers' patterns are omitted.
- Through hole is omitted.

#### Caution:

D878

Pattern face side: (Conductor Side)

Parts on the pattern face side s

Parts face side: (Component side) the pattern face are indicated.

Parts on the parts face side seen

parts face are indicated.

( DIODE )


D875 8-719-800-76 D10DE 1SS123 D876 8-719-404-46 D10DE MA110 D877 8-719-820-05 D10DE 1SS181

⟨ TRANSISTOR ⟩

0875 8-729-425-64 TRANSISTOR 2SD22160 0876 8-729-427-72 TRANSISTOR XP4501 0877 8-729-232-86 TRANSISTOR 2SK1875

8-719-404-46 DIODE MA110


OARD



- **77** —

CAMERA

CAMERA



CL890

LNB878 R886 \$ Q877 BUFFER (B-6)

25K1875-BLV

14.8

8.9

LNB879

9.5

6

7-8

8.9

LNB879

14.8

R887

3900

R887

CL894

R881

(A-4) (A-4) Q875, 876 V SUB REG 3 Q876 15 XP4501

13

14

15

16

12

#### Note on the CCD imager replacement

**17** 

• Some of this units require the correction data by the CCD imager (IC901 on CD-92 board), some do not.

18

19

20

21

22

The correction data is input in F page and addresses 1D to 2C of the camera micro processor (IC709 on VC-122 board), and also written on the CCD data label put on the shield case (upper) of the DD-48 board.

The correction data is not required for the CCD imager supplied for repair. Therefore, when replacing the CCD imager to which the CCD data label is put, remove the CCD data label and input 00 to F page and addresses 1D to 2C of the camera micro processor. Refer to the camera adjustment for input method.

 The CCD imager is not mounted for the already mounted CD-92 board supplied as the repair parts.

When replacing the CD-92 board, remove the CCD imager from the old board and install on the new board.

- Perform all adjustments of the camera block when the CCD imager has been replaced.
- Handle the CCD imager with attention such as MOS IC as it may be broken by static electricity in the structure.

  Also prevent the receiving light section from dust extended.


Also, prevent the receiving light section from dust attached and strong light.

# 

#### • SIGNAL PATH

		VIDEO S	IGNAL	AUDIO
	CHROMA	Υ	Y/CHROMA	SIGNAL
REC			→>>>	
PB				

- Ref. No. VC-122 BOARD: 3000 series -




IC801 8-752-350-16 IC CXD1257AR IC802 8-752-056-39 IC CXA1507BR IC803 8-752-053-26 IC CXA13990 IC804 8-752-327-48 IC CXD1250N IC805 8-752-054-61 IC CXA1390AR IC851 8-759-701-24 IC NJM3414M IC852 8-759-998-96 IC LM324D 1C853 8-759-058-47 IC MPC1724VMEL IC854 8-759-823-51 IC LB1830M IC856 8-759-998-98 IC LM358D

( TRANSISTOR )

8-729-928-87 TRANSISTOR DTC124EE 8-729-427-74 TRANSISTOR XP4601 Q703 8-729-427-74 TRANSISTOR XP4601 Q704 8-729-425-50 TRANSISTOR 2SB14620 0706 8-729-425-64 TRANSISTOR 2SD22160


8-729-428-84 TRANSISTOR UN9111 8-729-425-64 TRANSISTOR 2SD22160 0709 8-729-427-72 TRANSISTOR XP4501 0801 8-729-425-64 TRANSISTOR 2SD22160 Q802 8-729-427-70 TRANSISTOR XP4401 0851 8-729-425-64 TRANSISTOR 2SD22160 8-729-013-88 TRANSISTOR RN1302

Q853 8-729-427-70 TRANSISTOR XP4401



0707

**Q**852




-83 -

**CAMERA** 


CAMERA

**— 84** —



### • SIGNAL PATH

	VIDEO SIGNAL			AUDIO
	CHROMA	Υ	Y/CHROMA	SIGNAL
REC			→>>>	
PB				



19

18

(See Page 89) TO VC-122 BOARĐ (2/3) CONT CAM SO CAM SCK CS TG AGC C AGC C ABCK 吊克 \$ \$ 4 1 1 1 1 1 1 1 S F6 E7 E8 A7 L801 10#H :3225 MURATA CT801 ± 28.375MHz STBY EVA CLK MINV LINV 9 VCC 9 OND 9 OND 0 C10 0 0.4 C9 0 0.4 C8 0 0.6 C7 C803 4.7 6.3V : TA. A C804 0 01 0.566 Đ5 IC802 CXA1507BR-T4 C805 0.01 F 0.8 C5 0.8 C4 0.8 C4 0.8 C4 0.8 C4 0.8 C4 0.8 C4 0.1 C3 0.1 C3 0.1 C1 CK XCK TEST HTSG C807 0.01 F C809 4.7 6.3V VĐ 60 2.8 ΗĐ VIN L VIN H CASCOBE A VCC A VEE D VCC2 UNBER OVER P5 CL 56 4.8 - C817 0.01 VĐĐ I GM (55) 4.8 +PCFPFEEEEE WEN R810 2200 IÐ (53)4 C816 0.01 PBLK (52) 4.1 CLP4 (51) R809 2200 TGSTBY1 50 R808 (C-8) | IC802 A/Ð CONVERTER XSH2 XSH1 XSP2 XSP1 R819 47 CHASSIES GNÐ LNDS02 R825 8200 C818 ] : | 6V A R816 10k IC803 (N-9) R813幸 R813 2200 A/Đ BIAS AMP (5) CSSL OUT AGCMAX GND3 AGCCONT VCLP 4.8 © NÐ1 4.8 © XSHP 4.8 XSHÐ CLP1 IC803 CXA1399Q-T4 CAV1 (K-9) SIBY 4.8 × VCC1 VTRIN ~ 2.7 Q801 L804 104H & : 3225 TĐK BUFFER EMPHIN (-) C832 PGIN BATAIN ABJ AGCOUT VCC2 ABCK GNB2 CAMIN Q801 2502216QR-TX 1.9 83533333 8533333 R803 1500 19 P9-IN 19 P9-IN 19 P9-IN 19 XSP3 10 XSP3 10 XSP3 11 XSP1 12 XSP1 13 GNB 14 FSHI 15 F3-CLP 16 F2-CLP 17 XSH2 18 XSH2 ≢ R806 1800 DET-OUT (14) VCC2 (13) 4.8 R807 470 4.8 IRIS-GC IRIS-LEVEL (21) 4.8 BET-CLP GNÐ (19) IC805 CXA1390AR-T3 IS-CLP IRIS-OUT (17)
VG-OUT (18)
WN0 (15) C835 PBLK 14 4.1 CLP1 13 0.2 No BORK:CAMERA REC BOOK. VC-122 BOARD (1/3)

8

9

10

11

12

13


14


15


16


**— 87** —


17












**- 91 -**



#### CCD-TR303E/TR303EP Caution: · For printed wiring boards. Pattern face side: Parts on the pattern face side seen from VS-95 (REC/PB HEAD AMP, VIDEO, SERVO/SYSTEM CONTROL) PRINTED WIRING BOARD • VS-95 board is the printed wiring board which has four layers (Conductor Side) the pattern face are indicated. structure but inner two layers' patterns are omitted. Parts on the parts face side seen from the Parts face side: - Ref. No. VS-95 BOARD: 4000 series -• • : Through hole is omitted. (Component side) parts face are indicated. VS-95 BOARD(COMPONENT SIDE) 0282 ⊕ C289 R362 R366 0 C291 C283 (P358 C284) **₽357** ⊕ €256 В IC154 **R**329 ⊕ c220 **(237** R226 R 228 6 240 8 C182 C132 (C129) (C129) (C127) (R133) (C126) (C127) (C12 R139 R337 R146 R2 22 C181 10121 C125 T-y 0189 R220 C180 R125 ZZW QERW C124 RZW ZZ R14 I P218 0121 C151 R 155 C178 R164 D R154 Q182 R169 R177 C C159 R170 R132 R175 B E C C6 R153 L 160 G A Q 162 R216 C177 X403 C451 C439 L406 R217 **⊕** ¢ 307 R457 ¢452 ⊕ 0152 c305 ⊕ R456 C434 C433 R416 Ε R460 R449 C425 R430 R432 8448 C 466 \$6 E459 R431 10402 C461 RB423 10407 ¢465 W **E 3** 10408 32 0 R049 C057 2 893 C467 C066 R475 R472 1C003 ¢064 10403 C067 R474 ⊕ ∞ 5 6 6417 R401 R403 L 403 C018 C021 3~ 040i 1-644-986 H 9001

**VIDEO** 

**VIDEO** 


**— 95 —** 

13


10

**— 96 —** 


9




### ( DIODE ) 8-719-800-76 DIODE 1SS123 D001 Q160 8-729-403-35 TRANSISTOR UN5113 D121 8-719-027-50 DIODE MA142WK 0161 8-729-402-32 TRANSISTOR 2SD1819A-R 8-719-027-48 DIODE MA142WA D152 0162 8-729-403-35 TRANSISTOR UN5113 8-719-027-50 DIODE MA142WK D159 8-729-402-55 TRANSISTOR 2SB1218A-R D160 8-719-027-50 DIODE MA142WK 8-729-403-35 TRANSISTOR UN5113 8-719-404-46 DIODE MA110 D161 8-729-420-20 TRANSISTOR XN4312 D162 8-719-027-50 DIODE MA142WK 0171 8-729-117-73 TRANSISTOR 2SC4178-F14 8-719-027-50 DIODE MA142WK D163 0175 8-729-402-32 TRANSISTOR 2SD1819A-R D401 8-719-421-27 DIODE MA728 8-729-402-32 TRANSISTOR 2SD1819A-R D402 8-719-027-50 DIODE MA142WK 8-729-402-55 TRANSISTOR 2SB1218A-R 0177 D403 8-719-404-46 DIODE MA110 8-729-402-55 TRANSISTOR 2SB1218A-R Q180 8-729-422-54 TRANSISTOR XN4215 0182 8-729-402-32 TRANSISTOR 2SD1819A-R < 1C > 8-729-420-53 TRANSISTOR UN5115 8-729-402-32 TRANSISTOR 2SD1819A-R IC001 8-752-033-38 IC CXA1202R IC003 8-752-053-21 IC CXA1211M 0189 8-729-402-32 TRANSISTOR 2SD1819A-R IC121 8-759-605-61 IC CXA1203N 8-729-402-32 TRANSISTOR 2SD1819A-R IC151 8-752-065-54 IC CXA1207AR 8-729-402-32 TRANSISTOR 2SD1819A-R 0192 IC152 8-752-065-56 IC CXA1208R 0194 8-729-402-32 TRANSISTOR 2SD1819A-R IC154 8-752-333-24 IC CXL1506M 0195 8-729-402-55 TRANSISTOR 2SB1218A-R IC155 8-752-053-21 IC CXA1211M 8-729-403-35 TRANSISTOR UN5113 IC156 8-759-055-82 IC M62353GP 0196 IC158 8-759-055-82 IC M62353GP 0199 8-729-807-87 TRANSISTOR 2SB1295-UL6 0200 8-729-013-88 TRANSISTOR RN1302 IC159 8-759-636-33 IC CXA1452N 0203 8-729-402-55 TRANSISTOR 2SB1218A-R IC401 8-759-056-84 IC S-8420AF 0204 8-729-402-32 TRANSISTOR 2SD1819A-R IC402 8-752-838-20 IC CXP80624-428R 0205 8-729-402-42 TRANSISTOR UN5213 IC403 8-759-096-79 IC uPD75316GF-318-389 IC404 8-759-059-42 IC CXA1481AR 0207 8-729-403-35 TRANSISTOR UN5113 0208 8-729-013-88 TRANSISTOR RN1302 IC405 8-759-044-78 IC BR9011BF-RE2 0210 8-729-402-42 TRANSISTOR UN5213 1C406 8-759-081-96 1C uPD6456GS-620 8-729-402-55 TRANSISTOR 2SB1218A-R IC407 8-759-145-63 IC uPD7564G-540 8-729-420-12 TRANSISTOR XN4213 0214 IC408 8-759-057-60 IC MCD004BM IC409 8-759-999-02 IC TL1596CDB 0217 8-729-402-42 TRANSISTOR UN5213 8-729-403-35 TRANSISTOR UN5113 IC410 8-759-062-02 IC MPC1720VM 0219 8-729-402-42 TRANSISTOR UN5213 0220 8-729-420-12 TRANSISTOR XN4213 ( TRANSISTOR ) 8-729-402-32 TRANSISTOR 2SD1819A-R 0222 0001 8-729-216-22 TRANSISTOR 2SA1162 0223 8-729-402-42 TRANSISTOR UN5213 0003 8-729-402-55 TRANSISTOR 2SB1218A-R 8-729-402-55 TRANSISTOR 2SR1218 8000 8-729-402-32 TRANSISTOR 2SD1819A-R 8-729-402-32 TRANSISTOR 2SD1819A-R 0230 8-729-403-35 TRANSISTOR UN5113 0010 8-729-402-55 TRANSISTOR 2SB1218A-R 0231 0019 8-729-120-28 TRANSISTOR 2SC1623-L5L6 0232 8-729-402-32 TRANSISTOR 2SD1819A-R 8-729-120-28 TRANSISTOR 2SC1623-L5L6 0020 0233 8-729-402-32 TRANSISTOR 2SD1819A-R 0021 8-729-905-23 TRANSISTOR 2SA1576-R Q234 8-729-402-55 TRANSISTOR 2SB1218A-R 8-729-402-55 TRANSISTOR 2SB1218A-R 0022 8-729-420-56 TRANSISTOR UN511E 0236 8-729-102-07 TRANSISTOR 2SC2223-F13 0024 0237 8-729-425-50 TRANSISTOR 2SB14620 8-729-014-16 TRANSISTOR RN2302 0025 8-729-402-48 TRANSISTOR UN521E 0401 0026 8-729-402-32 TRANSISTOR 2SD1819A-R 8-729-403-35 TRANSISTOR UN5113 0403 8-729-403-35 TRANSISTOR UN5113 0121 8-729-907-00 TRANSISTOR DTC114EU 0405 Q123 8-729-402-42 TRANSISTOR UN5213 8-729-017-67 TRANSISTOR 2SB1574 8-729-403-35 TRANSISTOR UN5113 0124 8-729-117-73 TRANSISTOR 2SC4178-F14 0125 8-729-402-32 TRANSISTOR 2SD1819A-R 0126 8-729-101-07 TRANSISTOR 2SB798-DL 0151 8-729-402-32 TRANSISTOR 2SD1819A-R 0152 Q154 8-729-402-32 TRANSISTOR 2SD1819A-R Q158 8-729-402-32 TRANSISTOR 2SD1819A-R



**— 100 –** 





## SIGNAL PATH

AUDIO		REC	REC/PB	РВ
IGNAL	Drum speed servo			
-	Drum phase servo			
⇒	Drum servo (speed and phase)			
	Capstan speed servo			
	Capstan phase servo			
	Capstan servo (speed and phase)			
	Ref. signal	-		D

### CCD-TR303E/TR303EP • Refer to page 95 for Printed Wiring Board. VS-95 (VIDEO) SCHEMATIC DIAGRAM 2 3 5 6 7 8 9 10 - Ref. No. VS-95 BOARD: 4000 series -(See Page 109) (See Page 117) TO VS-95 BOARE (3/3) TO JK-91 BOARD W517 98 55 Ð152 MA142WA (Ð-4) Q168 Q162. 237 SHARPNESS SW 0168 UNS113 CURRENT LIMITER Œ 9237 25814629R ⊥C156 T 39₽ 9152 820 2501819A 0166 25B1218A (D-6) Q154 BUFFER R158 4.7k R178 820 R190 22k R152 5600 R191 K1K002 Ε R204 1k VS-95 BOAR Q175, 176 CHARACTER MIX (See Page 109) 2591819A (9-16) (9-16) Q170, 196 25010194 C218 R293 0.01 68 1 C219 W 91.2 9178 (B-23) 2SB1218A Q178 F ₽0 R192 10k C2 (9-16) Q171 R198 470 Q171 25C4178 EVF BUFFER PB/EE C SEL. R203= (See Page 131) R201 (B-25)(B-25 Q180,183 DS SWITCH G R211 ₹ R213 2.2k ₹ 15k 0.2 R224 2.24

25818194

R243

9 L169 R397

C187 0 0

Q236 (A-22)

SP/LP SWITCH

-103-

B161 MA110 (E-6)

0236 UN511E

R248 R250 R251 2.2k 120 56

C182

BUFFER

(See Page 102)

**VIDEO** 

(C-16) REC C BUFFER

R223 15k 820eH 8:4532

(4.9) (3.9) [193 (3.9)

250 819A 560 0

VS-95 BOARÐ (3/3)

VS-95 BOARO (3/3)

(See Page 100, 109)

M

Ν

0

JOG V21)

PB RF V47

5P/ LP V27> SYNC DET V13>

(See Page 109)

11

R285 R286 10k 10k

R291 820

7294 100k

Q2U5 -II- 0.01 F DOC DET SWI

10 16V 3AL

8163 MA142WK

0210 UN5213

C260 22p R333 1.2k

R295 470k

(D-4) Q189 BUFFER

R270 04.9

PB C AMP

L175 100AH C207 T

0160 UNS113

Q160, Q219, Q220

Q200 (0-7) INVERTER

R279

Q199 (Ð-8) PB 5V SWITCH

0203 2581218A

VIDEO BND R16

**VIDEO** 

TO VS-95 BOARĐ

J06-ANB-BDC

¥ 127,1

R280 = R281 3.3k = 1.5k

R282 4.7k

0.0033 B


0221 XN4213


(A-23) Q221 DOC E SWITCH


28)


R339 2.2k HHK C

(C-18) Q222, 223 (C-18) BUFFER, INVERTER










27



### • SIGNAL PATH

23

24


25

26

		AUDIO		
	CHROMA	Υ	Y/CHROMA	SIGNAL
REC	<b>→</b>	→>		-
РВ				⇒

	REC	REC/PB	РВ
Drum speed servo		<b>&gt;</b>	
Drum phase servo		<b>▶</b>	
Drum servo (speed and phase)		<b>&gt;&gt;</b>	
Capstan speed servo			
Capstan phase servo			Σ>>
Capstan servo (speed and phase)		<del></del>	
Ref. signal	-	<b>&gt;</b>	$\Sigma$

## **VS-95** BOARD(3/3)



## CF-32 (CAMERA FUNCTION SWITCH), CN-65 (BOARD LINK), ED-35 (CAMERA FUNCTION SWITCH), MF-191 (MANUAL FOCUS SWITCH), VK-27 (VTR FUNCTION SWITCH),

— Ref. No. JK-91 BOARD: 3000 series, LI-44 BOARD: 4000 series, MF-191 BOARD: 5000 series, CN-65 BOARD: 6000 series, CF-32 BOARD: 7000 series, ED-35 BOARD: 8000 series, VK-27 BOARD: 9000 series —

### • For printed wiring boards.

- CF-32, ED-35, MF-191, VK-27 boards is the printed wiring board which has four layers structure but inner two layers' patterns are omitted.
- • : Through hole is omitted.

Caution: Pattern face side:

Parts on the pattern face side seen from


(Conductor Side) the pattern face are indicated.


Parts face side: parts face are indicated. (Component side)

Parts on the parts face side seen from the


CF-32BOARD (COMPONENT SIDE) S996 MA OFF 599


- For printed wiring boards.
- CN-65 board is the printed wiring board which has four layers structure but inner two layers' patterns and component side pattern are omitted.
- Through hole is omitted.






D992 8-719-404-






⟨ DIODE ⟩


D992 8-719-404-46 DIODE MA110








⟨ DIODE ⟩


D986 8-719-404-46 DIODE MA110 D987 8-719-404-40 DIODE MA121













( DIODE ) D971 8-719-404-46 DIODE MA110





TCH), MF-191 (MANUAL FOCUS SWITCH), VK-27 (VTR FUNCTION SWITCH), JK-91 (VIDEO/AUDIO JACK), LI-44 (LITHIUM BATTERY HOLDER) SCHEMATIC DIAGRAMS


7 8 9 10 11 12 13 14 15 16 17 18 19 20 21 22 1

F-32 BOARD: 7000 series, ED-35 BOARD: 8000 series, VK-27 BOARD: 9000 series ---









## CCD-TR303E/TR303EP

## AU-138 (AFM AUDIO), MA-149 (MIC JACK, MIC AMP) PRINTED WIRING BOARDS

- Ref. No. AU-138, MA-149 BOARDS: 2000 series -

### • For printed wiring boards.

 AU-138, MA-149 boards are the printed wiring board which has four layers structure but inner two layers' patterns are omitted.

• : Through hole is omitted.


Caution:


Pattern face side: Parts on the pattern face side seen from the pattern face are indicated.


Parts face side: Parts on the parts face side seen from the parts face are indicated.

( IC )


IC601 8-759-823-19 IC CXA1488R IC602 8-749-923-29 IC RS-20E-T







## VF-42 BOARD



## ( DIODE )

D501 8-719-820-65 DIODE TLS221 D502 8-719-984-02 LED BR4371F D503 8-719-400-20 DIODE MA152WA

( IC )

1C501 8-759-420-01 IC AN2512S

⟨ TRANSISTOR ⟩


0501 8-729-100-66 TRANSISTOR 2SC1623 0502 8-729-216-31 TRANSISTOR 2SA1163-G 0504 8-729-106-68 TRANSISTOR 2SD1615A-GP


## • For printed wiring boards.


Caution:	
Pattern face side: (Conductor Side)	Parts on the pattern face side seen from the pattern face are indicated.
Parts face side: (Component side)	Parts on the parts face side seen from the parts face are indicated.

## VF-42 (VIEW FINDER) PRINTED WIRING BOARD

- Ref. No. VF-42 BOARD: 1000 series -








VF-42 (VIEW FINDER) SCHEMATIC DIAGRAM

15

7	l •	۵	1 10	44	1 40	10	1 44 1	15
<i>I</i>	8	9	וו	11	12	13	14	15



S	IGN	Δľ	РΔ	TH	

		AUDIO		
	CHROMA	Υ	Y/CHROMA	SIGNAL
REC				
РВ		⇔		


## DD-48 (POWER), SW-205 (CAMERA FUNCTION SWITCH) PRINTED WIRING BOARDS


- Ref. No. DD-48 BOARD: 1000 series, SW-205 BOARD: 7000 series -• For printed wiring boards. • DD-48 board is the printed wiring board which has four layers structure but inner two layers' patterns are omitted. • 


3 Through hole is omitted. Caution: Pattern face side: Parts on the pattern face side seen from the pattern face are indicated. (Conductor Side) Parts on the parts face side seen from the Parts face side: (Component side) parts face are indicated. ( DIODE ) D901 : 8-719-981-59 DIODE FC805 8-719-404-46 DIODE MA110 D906 :8-719-404-46 DIODE MA110 ( IC ) 1C901 8-759-060-94 IC MB3785APFV-G-BND-ER < TRANSISTOR >

8-729-403-27 TRANSISTOR XN4401 8-729-402-42 TRANSISTOR UN5213 0902 8-729-823-84 TRANSISTOR FP102 8-729-804-41 TRANSISTOR 2SB1122-S 8-729-823-82 TRANSISTOR FP101 8-729-823-82 TRANSISTOR FP101 8-729-402-81 TRANSISTOR XN4501 8-729-805-25 TRANSISTOR 2SB1121 0908 8-729-805-25 TRANSISTOR 2SB1121 0909 8-729-014-20 TRANSISTOR RN2304 0910

**— 134 —** 







## 4-3. SEMICONDUCTORS


## AN2512S



**BR9021AF** LM358DR



CXA1202R CXA1208R CXA1481AR **CXA1488R** 




**CXA1211M** NJM2234M NJM3414M



CXA1452N CXL1506M




### CXD2100Q $\mu$ PD75316GF









CXP80624-428R/434R



LB1830M




LB8111V



LM324DR





TC7SU04F



TL1596CDB



FP101

FP102

XN4213 UMZ1

XN4312

-140 -








## XN4401



RS-20E-T



UMT1

**TLS221** 

**BR4371F** 

1. anode 2 cathode



XP4401

XP4601







FC805



MA110




## **SECTION 5 EXPLODED VIEWS**

- -XX, -X mean standardized parts, so they may have some difference from the original one.
- Items marked " \* " are not stocked since they are seldom required for routine service. Some delay should be anticipated when ordering these items.
- The mechanical parts with no reference number in the exploded views are not supplied.
- Hardware (# mark) list is given in the last of this parts list.

The components identified by mark ⚠ or dotted line with mark ⚠ are critical for safety. Replace only with part number specified.

## 5-1. CABINET (L) AND F PANEL ASSEMBLIES



Ref. No.	Part No.	Description	Remark	Ref. No.	Part No.	Description	Remark
1	X-3942-282-1	CABINET (L) ASSY		* 12		STICKER, SONY SYMBOL (10)	
2	3-736-807-01	BELT, GRIP		13	3-713-790-21	SCREW (M2X6), TAPPING, P3	
3	3-578-221-00	SPRING, COMPRESSION		14	1-696-487-11	CABLE, FLAT (FFC-90)	
Ž		KNOB, STAND-BY				, , , , , , , , , , , , , , , , , , ,	
5 /	3-736-364-01			15	A-7063-322-A	MA-149P BOARD, COMPLETE	
<b>.</b>	0 100 004 01	OF ITTING		16		SCREW (B2X5), TAPPING	
c	4 602 400 00	SPRING. TENSION		* 17		RETAINER, MICROPHONE	
<u>6</u>							
7	3-942-895-01	STOPPER, BELT		18	A-7091-800-A	MICROPHONE UNIT	
8	3-943-154-11	HOLDER (B), REMOTE CONTROL		19	X-3941-891-2	PANEL ASSY, F	
* 9		LABEL, MODEL NUMBER (AEP)					
* 9		LABEL, MODEL NUMBER (UK. E. Australia	n)	20	3-947-357-01	SPRING, TORSION	
. 5	0 000 004 01	more nonell (on, e, notice) is	,	21	3-945-269-01		
10	3_710_381_01	SCREW (M2X4)		22		REMOTE COMMANDER (CAM CORDER) (	'RMT-507)
							(IMII JUI)
11	X-3942-139-1	LID ASSY, CASSETTE		23	3-708-412-01	LID, REMOTE COMMANDER	

5-2. CAE

No.	Part
	A-70 A-70 A-70 A-70 A-70 3-71
	3-74 X-39 3-94 3-94 3-42
	3-94 3-30 3-94 3-94 3-94

# SECTION 5 EXPLODED VIEWS


### NOTE:

- -XX, -X mean standardized parts, so they may have some difference from the original one.
- Items marked "\* " are not stocked since they are seldom required for routine service. Some delay should be anticipated when ordering these items.
- The mechanical parts with no reference number in the exploded views are not supplied.
- Hardware (# mark) list is given in the last of this parts list.

The components identified by mark ⚠ or dotted line with mark ⚠ are critical for safety.


Replace only with part number specified.

## 5-1. CABINET (L) AND F PANEL ASSEMBLIES




Ref. No.	Part No.	Description	Remark	Ref. No.	Part No.	Description	Remark
1 2 3 4	3-736-807-01 3-578-221-00 3-942-985-01	SPRING, COMPRESSION KNOB, STAND-BY		* 12 13 14	3-713-790-21	STICKER, SONY SYMBOL (10) SCREW (M2X6), TAPPING, P3 CABLE, FLAT (FFC-90)	
5 6 7 8 * 9	3-942-895-01 3-943-154-11	SPRING  SPRING, TENSION STOPPER, BELT HOLDER (B), REMOTE CONTROL LABEL, MODEL NUMBER (AEP)		15 16 * 17 18 19	3-719-601-01 3-949-000-01 A-7091-800-A	MA-149P BOARD, COMPLETE SCREW (B2X5), TAPPING RETAINER, MICROPHONE MICROPHONE UNIT PANEL ASSY, F	
* 9 10 11	3-950-354-01 3-719-381-01	LABEL, MODEL NUMBER (UK, E, Australia	n)	20 21 22 23	3-945-269-01 1-465-927-81	SPRING, TORSION KNOB, S REMOTE COMMANDER (CAM CORDER) (RMT- LID, REMOTE COMMANDER	-507)

## 5-2. CABINET (R) AND EVF ASSEMBLIES




Ref. No.	Part No.	Description	Remark	Ref. No.	Part No.	Description	Remark
51 52	A-7071-655-A	CN-65P BOARD, COMPLETE CF-32 BOARD, COMPLETE		75	3-949-008-01	SHEET, FOOT	
53	A-7071-653-A	VK-27 BOARD, COMPLETE		76	3-948-989-01	KNOB, BATTERY	
54 55	A-10/1-654-A	ED-35 BOARD, COMPLETE SCREW (M2X6), TAPPING, P3		77	3-948-843-01	LID. BATTERY CASE. LITHIUM	
00	3 113 130 21	JOHLW (MZXU), TAFFING, F3		78 79	3-/13-/86-51 A-7071-656 A	SCREW (M2X3)	
56	3-740-546-41	SCREW (M2X10)		80	1-692-257-11	MF-191 BOARD, COMPLETE SWITCH, PUSH (ZOOM)	
57	X-3942-156-3	CABINET (R) ASSY		00	1 032 231 11	3#1101, 10311 (200m)	
58 59	3-942-911-01	SCREW, TRIPOD		81		LID ASSY, LS	
60	3-948-990-01	LOCK, BATTERY SPRING, COMPRESSION		82		HOLDER ASSY, FINDER	
00	3 420 300 00	SINTING, COMPRESSION		83 84	3-946-426-01	EYE CUP	
61 62	3-948-839-01	BLIND, POWER		85	3-747-116-01	SCREW (M2X8), TAPPING, P3	
62	3-303-973-00	SPRING, COMPRESSION			0 110 100 01	OONER (MEXO), TAITING, 13	
63 64	3-946-186-01	PUSH BUTTON, POWER POWER (BASE) BUTTON, POWER		86	X-3940-706-1	CABINET (L) ASSY, EVF	
65	3-946-975-01	RITTON DOWED		87	3-943-077-01	CABINET (R), EVF	
00	0 040 240 01	BOTTON, TOWER		88 89	A-7003-220-A	VF-42P BOARD, COMPLETE	
66	3-948-988-01	SPRING, LEAF, VK		* 90	3-942-888-01	LABEL, CAUTION (UK)	
67	3-747-111-01	PLATE, LOCK, TILT			0 104 200 01	ENDEE, UNOTTON (UK)	
68	3-/4/-110-01	SPRING, LEAF, TILT		V901	1-452-565-11		
69 70	3-747-176-01	REINFORCEMENT, TILT LOCK SCREW (B2X5), TAPPING		<b>∆₩501</b>		SOCKET ASSY, CRT	
10	0 113 001 01	SCHEW (BEAS), TAFFING		W971 W986	1-696-484-11	CABLE, FLAT (FFC-87)	
71	3-948-976-01	DOOR, CONTROL			1-696-622-11	FP-590 FLEXIBLE BOARD FP-591 FLEXIBLE BOARD	
<b>*</b> 72	3-948-987-01	FRAME, MF					
73 7 <b>4</b>	3-747-112-01	KING, IILT		W991	1-696-483-11	CABLE, FLAT (FFC-86)	
14	3-747-109-01	SLEEVE, EVF					


## 5-3. MAIN BOARDS ASSEMBLY




Ref. No.	Part No.	Description	Remark	Ref. No.	Part No.	Description	Remark
<b>1</b> 01	3-713-786-51	DD-48P BOARD, COMPLETE SCREW (M2X3) SCREW (B TIGHT) (2), TAPPING		119 120		JK-91 BOARD, COMPLETE SCREW (M2X4)	
104 105	A-7063-318-A	CD-92P BOARD, COMPLETE RUBBER (S), SEAL		* 121 122 123	A-7063-321-A	FRAME (M), JACK AU-138P BOARD, COMPLETE SHIELD, DRUM	
106 107 108	3-946-856-01	FILTER BLOCK, OPTICAL ADAPTOR (H), CCD FITTING LENS, ZOOM (VCL-6210WC)		H516 J517	1-550-104-32	HOLDER, BATTERY TERMINAL BOARD	
	3-949-001-01			J901 IC875		TERMINAL BOARD CCD BLOCK ASSY (AUTO) (1CX0554K-2)	(CCD IMAGER)
111 112 113 114	3-948-842-01 A-7063-317-A	LI-44 BOARD, COMPLETE HOLDER, LI VC-122P BOARD, COMPLETE SCREW (B2X5), TAPPING			1-532-841-21	LINK, IC 1.6A/90V LINK, IC 1.6A/90V FP-588 FLEXIBLE BOARD	(000 141/1221)
115		VS-95P BOARD, COMPLETE		W405 W517		FP-572 FLEXIBLE BOARD CABLE, FLAT (FFC-85)	
* 116 117 118	A-7071-651-A	FRAME (UPPER LOWER) ASSY SW-205 BOARD, COMPLETE SL-27P BOARD, COMPLETE			1-696-488-11 1-642-186-11	CABLE, FLAT (FFC-92) FP-437 FLEXIBLE BOARD FP-589 FLEXIBLE BOARD	




Ref. No.	Part No.	Description	Remark	Ref. No.	Part No.	Description	Remark
151 152 153 154 155	3-945-773-01 3-945-771-01 X-3941-287-2	CASSETTE COMPARTMENT BLOCK ASSY BAR, TORSION SPRING, TORSION DAMPER ASSY WASHER, STOPPER		157 158 159 160	3-945-760-01 3-321-393-01	PROTECT (BASE) BLOCK ASSY SPRING, TENSION WASHER, STOPPER ROLLER ASSY, HC	And the second
156	3-947-503-01	SCREW (M1. 4X2. 5)		161 162		RETAINER ASSY, GOOSENECK COVER, CAPSTAN	



Ref. No.	Part No.	Description	Remark	Ref. No.	Part No.	Description	Remark
201 202 203 204	3-331-007-21 X-3941-271-1	TABLE ASSY, REEL, T WASHER ARM ASSY, PINCH SPRING, TORSION		218 219 220	X-3941-277-1	SCREW (M1. 4X3) STRING BLOCK ASSY BRAKE, S SOFT	
205		SPRING, TENSION		221 222	3-948-810-01 X-3941-276-1	SPRING, TENSION	
206 207 208 209	X-3941-424-1 3-947-504-01	GUIDE (BASE) (T) BLOCK ASSY ROLLER ASSY, TG6 SCREW (M1.2X2) ARM (T) ASSY, GUIDE	:	223 224 225	3-945-752-01 3-945-799-01	SPRING, TORSION BRAKE, S HARD SCREW (M1. 4X2. 5)	
210		WASHER (1.5), STOPPER		226 227		CHASSIS ASSY, LS	
211 212 213 214	3-945-753-01 3-726-829-01	SOFT ASSY, T ARM, T SOFT WASHER, STOPPER GEAR ASSY, GOOSENECK		228 229 230	A-7040-306-A X-3941-269-1	PLATE, CAM, LS GUIDE (BASE) (S) BLOCK ASSY ROLLER ASSY, TG3 ARM (S) ASSY, GUIDE	
215	3-947-644-01	RETAINER, TG5 (BASE)		231 232	3-945-837-01		
216 217		CLAW BLOCK ASSY, T HARD TABLE ASSY, REEL, S		S002	3-949-881-01 1-572-987-11	SWITCH, PUSH (3 KEY) (REC PROOF, ME/MP, MP/MP-HG	)




Ref. No.	Part No.	Description	Remark	Ref. No.	Part No.	Description	Remark
251 252		DRUM ASSY, UPPER (DGR-90-R) SPRING, LEAF, TG7 ARM		260	3-945-702-01	ROLLER, LS	
252 253 254 255	A-7040-305-A 3-947-503-01	ARM BLOCK ASSY, TG7 SCREW (M1. 4X2. 5) PLATE (T) ASSY, SIDE		261 262 263	3-945-774-01	ROLLER ASSY, TG2 SPRING, COMPRESSION SCREW (M2X5), P1	4
256	3-945-735-01	ARM, HC CONVERSION		M901 M902	A-7048-585-A	DRUM ASSY (DGH-90A-R) MOTOR, DC SCE-0101A (CAPSTAN)	#ACC
257 258 259		SCREW (M2X5) PLATE (S), SIDE ARM, LS		M903	A-7040-304-A	MOTOR BLOCK ASSY, LM (LOADING)	



Ref. No.	Part No.	Description	Remark	Ref. No.	Part No.	Description	Remark
301 302 303	3-728-103-11	ARM, HC DRIVING SCREW (M1.4X1.6), SPECIAL HEAD ARM ASSY, PINCH PRESS		314 315		SCREW (M2X5) CHASSIS ASSY, MECHANICAL	
304 305	3-726-829-01	WASHER, STOPPER SLEEVE, EJECT		316 317	3-945-722-01	SCREW (M1. 4X2. 5) RETAINER, GEAR	
306 307 308	3-945-729-01	LEVER, EJECT SPRING, COMPRESSION		318 319 320	3-945-697-01 3-945-700-01		
308 309 310	3-944-539-01	GEAR ASSY, CHANGE BELT, RELAY PULLEY, RELAY		321 322		SCREW, TG6 ADJUSTMENT	
311 312 313	3-945-696-01	SLIDER ASSY, M CAM ARM ASSY, GL		323 \$001 \$005	1-572-986-11	SCREW (M1.4X3) SWITCH, ROTARY (ENCODER) SWITCH (C DOWN)	

#### 5-8. ZOOM LENS ASSEMBLY (VCL-6210WC)



Ref. No.	Part No.	Description	Remark	Ref. No.	Part No.	Description	Remark
401 402 403 404 405	3-708-446-01 3-708-053-01 3-708-493-01	LENS, ZOOM (VCL-6210WC) METER, POTENTIAL SCREW, FB FITTING FLEXIBLE PHOTO INTERRUPTER			3-708-491-01		

# SECTION 6 ELECTRICAL PARTS LIST

AU-138 CD-92

#### NOTE:

The components identified by mark

\( \frac{\Lambda}{\Lambda} \) or dotted line with mark \( \frac{\Lambda}{\Lambda} \) are critical for safety.

Replace only with part number

Replace only with part number specified.

When indicating parts by reference number, please include the board name.

- Due to standardization, replacements in the parts list may be different from the parts specified in the diagrams or the components used on the set.
- -XX, -X mean standardized parts, so they may have some difference from the original one.
- RESISTORS
   All resistors are in ohms
   METAL: Metal-film resistor
   METAL OXIDE: Metal Oxide-film resistor
   F: nonflammable
- Hardware (# mark) list is given in the last of this parts list.
- Items marked "\*" are not stocked since they are seldom required for routine service. Some delay should be anticipated when ordering these items.
- SEMICONDUCTORS
  In each case, u: μ, for example:
  uA...: μ A..., uPA...: μ PA...,
  uPB...: μ PB..., uPC...: μ PC...,
  uPD...: μ PD...
- CAPACITORS uF : μF
- COILS uH : μH

Ref. No.	Part No.	Description			Remark	Ref. No.	Part No.	Description			Remark
			00101555					/ 0011 \			
*	A-7063-321-A	AU-138 BOARD,						( COIL )			
		***************************************		No 2,	000 Series)	L601	1-410-384-31	INDUCTOR CHIP	18uH		
		<pre>&lt; CAPACITOR &gt;</pre>						⟨ RESISTOR ⟩			
C601	1-126-607-11	ELECT CHIP	47uF .	20%	4V	R603	1-216-851-11	METAL CHIP	330K	5%	1/16W
C605	1-124-778-00		22uF	20%	6. 3V	R604	1-216-837-11	METAL CHIP	22K	5%	1/16W
C607		CERAMIC CHIP	0. 22uF		25V	R605	1-216-849-11	METAL CHIP	220K	5%	1/16W
C614	1-164-156-11	CERAMIC CHIP	0. 1uF		25V	R607	1-216-859-11	METAL CHIP	1.5M	5%	1/16W
C615		CERAMIC CHIP	0. 033uF		25V	R614	1-216-817-11	METAL CHIP	470	5%	1/16W
C617	1-162-974-11	CERAMIC CHIP	0. 01uF		50V	R615	1-216-839-11	METAL CHIP	33K	5%	1/16W
C618	1-162-957-11	CERAMIC CHIP	220PF	5%	50V	R616	1-216-864-11	METAL CHIP	0	5%	1/16W
C627	1-162-974-11	CERAMIC CHIP	0. 01uF		50V	R617	1-216-831-11	METAL CHIP	6. 8K	5%	1/16W
C628		CERAMIC CHIP	0. 047uF	10%	25V	R618	1-216-839-11	METAL CHIP	33K	5%	1/16W
C629	1-126-607-11	ELECT CHIP	47uF	20%	4V	R619	1-216-864-11	METAL CHIP	0	5%	1/16W
C630	1-124-778-00	FLECT CHIP	22uF	20%	6. 3V	R620	1-216-840-11	METAL CHIP	39K	5%	1/16W
C631	1-128-006-11		4. 7uF	20%	25V	R622	1-216-839-11		33K	5%	1/16W
C632		CERAMIC CHIP	68PF	5%	50V	R625	1-216-833-11		10K	5%	1/16W
C636		CERAMIC CHIP	0. 0033uF	10%	50V	R630	1-216-821-11	METAL CHIP	1K	5%	1/16W
C637		CERAMIC CHIP	0. 01uF		50V	R632	1-216-827-11	METAL CHIP	3. 3K	5%	1/16W
C639	1-162-974-11	CERAMIC CHIP	0. 01uF		50V	R633	1-216-831-11	METAL CHIP	6. 8K	5%	1/16W
C640		CERAMIC CHIP	0. 47uF		25V	R634	1-216-837-11	METAL CHIP	22K	5%	1/16W
C641		CERAMIC CHIP	47PF	5%	50V	R637	1-216-864-11	METAL CHIP	0	5%	1/16W
C643		CERAMIC CHIP	220PF	5%	50V	R677	1-216-832-11	METAL CHIP	8. 2K	5%	1/16W
C645	1-128-006-11		4. 7uF	20%	25V	R679	1-216-821-11	METAL CHIP	1K	5%	1/16W
C647	1-128-013-11	ELECT CHIP	1uF	20%	50V	R681	1-216-851-11	METAL CHIP	330K	5%	1/16W
C649	1-128-004-11		10uF	20%	16V	R682	1-216-849-11	METAL CHIP	220K	5%	1/16W
C651		CERAMIC CHIP	0.0068uF	10%	25V						
C654		CERAMIC CHIP	0.0018uF	10%	50V	******	*******	*******	******	*****	k*********
C655	1-126-205-11	ELECT CHIP	47uF	20%	6. 3V						
						*	A-7063-318-A	CD-92 BOARD,			
C657	1-164-005-11	CERAMIC CHIP	0. 47uF		25V			*********			
C660	1~162-966-11	CERAMIC CHIP	0. 0022uF	10%	50V				(Re	f. No 1	1,000 Series)
C691	ୀ-128-006-11	ELECT CHIP	4. 7uF	20%	25V						
C695	1-128-006-11	ELECT CHIP	4. 7uF	20%	25V			( CAPACITOR )			
C699	1-124-778-00	ELECT CHIP	22uF	20%	6. 3V						
						C875	1-135-214-21			20%	
		( CONNECTOR )				C876	1-128-013-11	ELECT CHIP	1uF	20%	
						C877	1-128-008-11		3. 3uF	20%	
CN601		CONNECTOR, FF				C879		CERAMIC CHIP			16V
		CONNECTOR, BO			•	C880	1-135-091-00	TANTALUM CHIP	1uF	20%	16V
CNOUS	1-200-231-1	ONNECTOR, F	U (NUN ∠II	/ 35		C881	1-128-004-11	ELECT CHIP	10uF	20%	16V
		( IC )				C882	1-126-607-11	ELECT CHIP	47uF	20%	
						C884	1-164-156-11	CERAMIC CHIP	0. 1uF		25V
IC601	8-759-823-19	IC CXA1488R				C888	1-135-210-11	TANTALUM CHIP	4. 7uF	20%	10V
	8-749-923-29	O IC RS-20E-T									

## CD-92 CF-32 CN-65 DD-48

Ref. No.	Part No.	Description			Remark	Ref. No.	Part No.	Description			Remark	k
		< CONNECTOR	>			S997	1-692-024-21	SWITCH, ROTA	RY (PROGRA	M AE)		
CN875	1-573-308-11	CONNECTOR	DUNDU TU B	OADD 16D					•			
GNO75	1-3/3-306-11	CONNECTOR, 1	ם טו עמאטפ	UNNU IOP				〈 BUZZER 〉				
		( DIODE )				SP991	1-529-107-11	BUZZER, PIEZ	OELECTRIC			
D875	8-719-800-76					******	******	*******	*******	*****	*******	*
D876	8-719-404-46											
	8-719-820-05		1			*	A-7071-694-A	CN-65 BOARD,				
D878	8-719-404-46	DIODE MATTO						********				
		( COIL )							(Ket	. No 6,	000 Series	)
		( OOIL /						( CONNECTOR	>			
L875	1-412-064-11	INDUCTOR CH	IP 100uH					( 00/11/2010/11				
						CN518	1-573-310-11	CONNECTOR, B	DARD TO BO	ARD 20F	>	
		< TRANSISTOR	R >									
0875	0.720.425.64	TRANSISTOR (	20022100					CABLE, FLA	Γ >			
Q875 Q876	8-729-425-64 8-729-427-72					W991	1_606_402.11	CADIC CLAT	/EEC 06\			á
0877	8-729-232-86					W991	1-090-403-11	CABLE, FLAT	(FFG-86)			
3011	0 120 202 00	THE RESTOR	LONTOTO			******	*********	********	*********	*****	******	*
		( RESISTOR )	<b>)</b>									
						* <u>^</u>	A-7063-320-A	DD-48 BOARD,	COMPLETE			
	1-216-845-11		100K		16W			********	******			
	1-216-857-11		1M		16W				(Ref.	No 1,	000 Series	)
	1-216-839-11		33K	· .	16W							
	1-216-843-11		68K		16W			( CAPACITOR )				
R881	1-216-819-11	METAL CHIP	680	5% 1/	16W							
R882	1-216-849-11	METAL CHID	2204	EN 1/	1 CW	C901		CERAMIC CHIP		0. 25PF		
			220K		16W			CERAMIC CHIP		10%	25V	
	1-216-835-11		15K		16W	C903		CERAMIC CHIP			50V	
	1-216-850-11		270K		16W	C904		CERAMIC CHIP		10%	25V	
	1-216-833-11		10K 3. 9K		16W	C906	1-163-037-11	CERAMIC CHIP	0. 022uF	10%	25V	
11001	1-210-020-11	METAL CHIP	3. 3N	3/h 1/	16W	C907	1_162_027_11	CERAMIC CHIP	0.0225	109	2EV	
******	******	********	*******	*******	******	C909		CERAMIC CHIP		10% 10%	25V 25V	
								CERAMIC CHIP		10%	25V 25V	
*	A-7071-655-A	CF-32 BOARD	COMPLETE			C911		CERAMIC CHIP		10%	25V 25V	
		*********						CERAMIC CHIP		5%	50V	
			(Re	f. No 7.00	00 Series)	0012	. 100 017 00	OLINGING OITH	0. 0047ui	5/6	301	
						C914	1-162-962-11	CERAMIC CHIP	470PF	10%	50V	Ž
		< CONNECTOR	>			C915		CERAMIC CHIP		10%	50V	,
						C916	1-162-962-11	CERAMIC CHIP	470PF	10%	50V	
CN993	1-566-540-11	CONNECTOR, F	PC (NON Z	IF) 8P		C917	1-162-962-11	CERAMIC CHIP	470PF	10%	50V	
						C918	1-162-964-11	CERAMIC CHIP	0.001uF	10%	50V	
		( DIODE )										
0000	0 710 404 40	DIODE 141410				C919	1-128-530-11		33uF	20%	10V	
D992	8-719-404-46	DIODE MAILU					11-162-928-11		120PF	5%	50V	
		/ DECICEOD \				C921	1-162-928-11		120PF	5%	50V	
		( RESISTOR )						CERAMIC CHIP		10%	50V	
R991	1-216-295-00	METAL CHID	0	E% 1 /1	I AW	C923	1-135-215-21	TANTAL. CHIP	6. 8uF	20%	16V	
	1-216-295-00		0	5% 1/1 5% 1/1	IOW	0024	/1.120 004 11	CLECT CHIE	10 5	0.01/	104	
.1332	1 210 233 00	METAL VIIII	U	J/0 I/	IVπ		1-128-004-11 1-164-836-11		10uF 6. 8uF	20%	16V	
		(SWITCH)								201	16V	
		, our roll /				C927	1-135-215-21 1-128-530-11		6. 8uF	20%	16V	
S991	1-692-111-11	SWITCH KEY	ROARD (FAI	OFR)		C928		CERAMIC CHIP	. 33uF	20%	10V	
	1-692-111-11					V320 ,	104 030-11	OLIMATO UNIF	u. our		16V	
	1-692-111-11				-T)	C929	1-165-178-11	CERAMIC CHIP	6 8uF		16V	
S996	1-692-111-11				/			CERAMIC CHIP			16V	á
			\11II		'	JJJ 1	. 100 170 11	VENEWITO UTIL	J. Jul		, 01	direct.
								The c	omnonents i	dentifie	d by mark	l

The components identified by mark  $\triangle$  or dotted line with mark  $\triangle$  are critical for safety.

Replace only with part number specified.

Ref. No.	Part No.	Description			<u>!</u>	Remark	Ref. No.	Part No.	Descrip	otion			Rem	ark
C932	1-165-178-11	CERAMIC CHIP	6. 8uF		16V				⟨ TRAN	SISTOR >				
	1-128-530-11	-	33uF	20%	10V									
C934	1-128-530-11	ELECT CHIP	33uF	20%	107		0901	8-729-403-27						
							0902	8-729-402-42						
C935		TANTALUM CHIP		20%	20V		0903	8-729-823-84						
C936		TANTALUM CHIP		20%	20V		0904	8-729-804-41						
C938		CERAMIC CHIP	2. 2uF		16V		0905	8-729-823-82	IKAN51	STUR FP10	1			
C939 C940	1-164-505-11	CERAMIC CHIP	2. 2ur 10uF	20%	16V 16V		0906	8-729-823-82	TRANCI	STOR EDIO	1			
6940	1-120-004-11	ELECT CHIP	Tour	ZUA	104		Q907	8-729-402-81						
C942	1-135-177-21	TANTALUM CHIP	1oF	20%	20V		0908	8-729-805-25						
C943		TANTALUM CHIP		20%	207		0909	8-729-805-25						
	1-128-004-11		10uF	20%	167		0910	8-729-014-20						
C947	1-128-004-11		10uF	20%	167									
C948	1-128-004-11	ELECT CHIP	10uF	20%	16V				⟨ RESI	STOR >				
C949	1-128-004-11	ELECT CHIP	10uF	20%	16V		R901	1-216-837-11	METAL.	CHIP	22K	5%	1/16W	
C950		CERAMIC CHIP	0. 01uF	10%	25V		R902	1-218-716-11			10K	0. 50%		
*							R903	1-216-837-11	METAL	CHIP	22K	5%	1/16W	
		< CONNECTOR >					R904	1-218-698-11			1.8K	0.50%	1/16W	
							R905	1-218-724-11	METAL	CHIP	22K	0. 50%	1/16W	
		CONNECTOR, BO												
CN902	1-573-506-41	CONNECTOR, FP	C (NON ZIF	) 4P			R906	1-218-708-11				0. 50%		
							R907	1-216-818-11			560	5%	1/16W	
		< DIODE >					R908	1-216-847-11			150K		1/16W	
0004	0 740 004 50	DIODE FOODE					R909	1-216-827-11		_	3. 3K		1/16W	
D901	8-719-981-59						R910	1-216-829-11	METAL	CHIP	4. 7K	5%	1/16W	
	8-719-404-46 8-719-404-46						R911	1-216-838-11	METAI	CHID	27K	5%	1/16W	
D300	-0-119-404-40	DIODE MATTO					R912	1-216-840-11			39K	5%	1/16W	
		( 10 )					R913	1-216-296-00			0	5%	1/8W	
		( 10 /					R914	1-216-831-11			6. 8K	5%	1/16W	
IC901	8-759-060-94	IC MB3785APFV	-G-BND-ER				R915	1-216-823-11			1. 5K	5%	1/16W	
		/ IACK \					D016	1 216 022 11	METAL	CHID	101	EN	1 /1 CW	
		( JACK )					R916 R917	1-216-833-11 1-218-716-11			10K 10K	5% 0. 50%	1/16W	
J901	1_527_281_41	TERMINAL BOAR	n /RATTERV	TERMII	MAL \		R918	1-216-811-11			150	5%	1/16W	
J902		JACK, ULTRA SI			INC.		R919	1-218-716-11			10K	0. 50%		
0002	1 000 270 21	Onon, OLIVER OF	**************************************	LMO I L/			R920	1-216-829-11			4. 7K		1/16W	
		( COIL )					D021	1 210 041 11	METAL	ALL D	ATV	rw.	1 /1 CW	
L903	1 404 500 01	COIL, CHOKE	100				R921 R922	1-216-841-11 1-216-833-11			47K 10K	5% 5%	1/16W 1/16W	
L903	1-424-522-21		10uH 10uH				R923	1-216-829-11			4. 7K		1/16W	
L905	1-424-522-21		10uH				R924	1-216-823-11			1. 5K		1/16₩	
L906	1-424-523-21		22uH				R925	1-216-829-11			4. 7K		1/16W	
L909		INDUCTOR CHIP							****	••••	** ***	570	.,	
							R926	1-216-833-11	METAL	CHIP	10K	5%	1/16W	
L910	1-412-028-11	INDUCTOR CHIP	4. 7uH				R927	1-216-829-11		-	4. 7K		1/16W	
L911	1-412-028-11	INDUCTOR CHIP	4. 7uH				R928	1-216-843-11	METAL	CHIP	68K	5%	1/16W	
L912		COIL, CHOKE	47uH				R929	1-216-841-11	METAL	CHIP	47K		1/16W	
L913		COIL, CHOKE	47uH				R930	1-216-182-00	METAL	CHIP	220	5%	1/8W	
L914	1-412-034-11	INDUCTOR CHIP	330uH				R931	1-216-182-00	METAL	CHID	220	59	1/8W	
L915	1-412-034-11	INDUCTOR CHIP	33004				R932	1-216-182-00			220 220		1/8W	
L915		INDUCTOR CHIP					R933	1-216-162-00			680		1/8W	
	1 312 020 11		1. I WII				R935	1-216-864-11			0		1/16W	
		(LINK, IC)					R936	1-216-845-11			100K		1/16W	
∕∱ PSQn1	1_527_941_71	LINK, IC (PRF	1600 1 64\				R937	1-216-864-11	METAI	CHID	0	5%	1/16₩	
		LINK, IC (PRF					R938	1-216-822-11			1. 2K		1/16W	
<u>دیا</u> ، ۲۵۰۰	1 302 041 21	- IIII, 10 (IIII	. 000 I. UN)				1 11000	1 210 022 11	mc i /\L	VIIII	1. 41	J/8	1/1011	

The components identified by mark  $\triangle$  or dotted line with mark  $\triangle$  are critical for safety.

Replace only with part number specified.

# DD-48 ED-35 JK-91 LI-44 MA-149

Ref. No.	Part No.	Description				Remark	Ref. No.	Part No.	Description			Remark
R939	1-218-883-11	METAL CHIP	33K	0. 50%	1/16W				〈 JACK 〉			
R940	1-216-836-11		18K	5%	1/16W				( 0)101( )			
R941	1-216-825-11	METAL CHIP	2. 2K	5%	1/16W		J517	1-537-142-21	TERMINAL BOAR	D		
										(VIDEO, A	UD 10,	RFU DC OUT)
R942	1-216-833-11		10K	5%	1/16W							
R943	1-216-296-00		0	5%	1/8W				CABLE, FLAT	>		
R944	1-216-841-11		47K	5%	1/16W		WC17	1 000 400 44	DADLE FLAT	FF0 0F)		
-	1-216-828-11		3. 9K 56K	5% 5%	1/16W 1/16W		WOII	1-090-482-11	CABLE, FLAT (	FFC-85)		
11340	1-210-042-11	METAL CHIP	JUN	3/6	1/10#		******	******	******	******	*****	****
R947	1-216-295-00	METAL CHIP	0	5%	1/10W				****	*****	****	4. 4. 4. 4. 4. 4. 4. 4. 4. 4. 4. 4.
	1-216-296-00		0	5%	1/8W		*	A-7071-652-A	LI-44 BOARD,	COMPLETE		
R950	1-216-864-11	METAL CHIP	0	5%	1/16W				*******			
R951	1-216-296-00	METAL CHIP	0		1/8W					(Ref.	No 4,	000 Series)
R952	1-216-864-11	METAL CHIP	0	5%	1/16W							
2050	4 040 004 44	METAL OLLID		EN	4 /4 NW				< CONNECTOR >			
R953	1-216-864-11	METAL CHIP	0	5%	1/16W		+ CNE16	1 500 055 21	PIN. CONNECTOR	20		
		( SWITCH )					* UNDIO	1-560-055-21	PIN, CONNECTO	K ZP		
		\ SHITGH /							( HOLDER, BAT	TERY \		
S901	1-572-467-11	SWITCH, PUSH (1	KEY)	(EJECT)	)				( HOLDEN, DAT	ILIII /		
			,	(====;	,		H516	1-550-104-32	HOLDER, BATTE	RY		
		<pre>&lt; TRANSFORMER &gt;</pre>										
							******	*********	*********	******	*****	*******
T901	1-450-874-21	TRANSFORMER, DC-	-DC CO	NVERTE	R			. =====				
****		********					*	A-7063-322-A	MA-149 BOARD,			
*****	*****	*****		*****	*****	*****			*********		No 2	000 Series)
*	A-7071-654-A	ED-35 BOARD, COM	<b>IPLETE</b>							(1101)	110 4.,	000 0011037
		******	*****						( CAPACITOR )			
			(Re	f. No l	B, 000 S	Series)		,				
							C551		CERAMIC CHIP		10%	50V
		⟨ DIODE ⟩							CERAMIC CHIP		10%	50V
D986	8-719-404-46	DIODE MATTO							CERAMIC CHIP		10% 10%	50V 50V
D987	8-719-404-40						C555		CERAMIC CHIP		10%	25V
	0 110 101 10						0000	1 102 001 11	OLIDANIO OTTO	0. 000ai	1 0/0	201
		( SWITCH )					C556	1-164-004-11	CERAMIC CHIP	0. 1uF	10%	25V
							C557	1-162-953-11	CERAMIC CHIP	100PF	5%	50V
		SWITCH, SLIDE (							CERAMIC CHIP			16V
S987		SWITCH, KEY BOAR	-		-				CERAMIC CHIP			16V
\$988		SWITCH, SLIDE (I			NDER)		C563	1-126-205-11	ELECT CHIP	47uF	20%	6. 3V
S989 S990		SWITCH, KEY BOAR SWITCH, SLIDE (		EA)			CECC	1_162_620_11	CERAMIC CHIP	15		167
3990	1-5/1-2/5-3/	SWITCH, SLIDE (	(ווטב				C569		CERAMIC CHIP		10%	16V 16V
		( CABLE, FLAT )					6303	1-104-432-11	CENAMIC CHIP	u. 15ur	10/6	104
		, ,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,							( CONNECTOR )			
W986	1-696-621-11	FP-590 FLEXIBLE	BOARD									
									CONNECTOR, FPO		5P	
*****	********	**********	*****	*****	*****	******	CN552	1-580-056-21	PIN, CONNECTOR	R 3P		
*	A_7063_266_A	JK-91 BOARD. COI	ADI ETE						( DIODE )			
77	W-1009-500-W	***********							\ DIODE /			
				f. No S	3. 000 9	Series)	D552	8-719-404-46	DIODE MA110			
			,		.,		- 301	40				
	3-719-381-01	SCREW (M2X4)							( IC )			
*	3-948-974-01	FRAME (M), JACK										
							IC551	8-759-822-37	IC LA7293M			

## MA-149 MF-191 SL-27 SW-205

Ref. No.	Part No.	Description			Remark	Ref. No.	Part No.	Description			Re	<u>emark</u>
		〈 JACK 〉				C525 C526		CERAMIC CHIP		10%	50V 25V	
J551	1-568-027-11	JACK, SMALL TY	PE 1P (N	AIC)		C527		CERAMIC CHIP				
		⟨ TRANSISTOR ⟩				3321		( CONNECTOR )				
0551	8-729-402-55	TRANSISTOR 2SB	1218A-R			CNE21	1_601_482_21	CONNECTOR, FF		)		
		〈 RESISTOR 〉			!	CN522	1-691-472-21	CONNECTOR, FF	C/FPC 6P			
R551	1-216-822-11	METAL CHIP	1. 2K	5%	1/16W	GN323	1-031-415-21	COMMECTOR, 11	0/110 11			
R552	1-216-830-11	METAL CHIP	5. 6K		1/16W			( IC )				
R553	1-216-838-11	METAL CHIP	27K		1/16W							
R554	1-216-838-11	METAL CHIP	27K		1/16W	IC521	8-759-059-09	IC LB8111V				
R555	1-216-864-11	METAL CHIP	0	5%	1/16W							
								< TRANSISTOR	>			
R556	1-216-864-11		0		1/16₩							
R558	1-216-831-11		6. 8K		1/16W	Q521	8-729-402-81	TRANSISTOR X	14501			
R564	1-216-295-00		0		1/10W							
R565	1-216-821-11		1K		1/16W			⟨ RESISTOR ⟩				
R566	1-216-864-11	METAL CHIP	0	5%	1/16W				4001/		4 /4 0111	
						R522			100K		1/16W	
R571	1-216-296-00		0		1/8W	R523	1-216-845-11		100K		1/16W	
R572	1-216-296-00	METAL CHIP	0	5%	1/8W		1-216-825-11		2. 2K		1/16W	
							1-216-825-11		2. 2K		1/16W	
******	******	**********	*****	******	*****	R528	1-216-845-11	METAL CHIP	100K	5%	1/16W	
		. WE 404 BOARS	AALIDI ETI	-		pron	1 010 040 11	MCTAL CILID	201	EW.	1 /1 CW	
*	A-7071-656-7	MF-191 BOARD,					1-216-840-11		39K	5% 5%	1/16W 1/8W	
		*********			000 0:\		1-216-174-00		100 0	5%	1/0# 1/16W	
			(Ke	т. мо э	,000 Series)	Ross	1-216-864-11	METAL CHIP	U	J/n	1/10#	
		( DIODE )						< NETWORK, RE	ES >			
D971	8-719-404-40	6 DIODE MA110						NETWORK, RES				
		⟨ RESISTOR ⟩						〈 FLEXIBLE BO	DARD >			
R971	1-216-295-00	O METAL CHIP	0	5%	1/10W	W521	1-642-186-11	FP-437 FLEXIE	BLE BOARD			
		< SWITCH >				W522	1-696-490-12	PP-589 FLEXIE	BLE BOARD			
S971		1 SWITHC, TACTIL				******	**********	*******	*******	****	*****	****
S972		1 RES, VAR, CARE										
S973	1-572-467-1	1 SWITCH, PUSH (	(1 KEY)	(LENS 0	PEN/CLOSE)	*	A-7071-651-A	SW-205 BOARD,				
		( CABLE, FLAT	>					********			7, 000 Se	ries)
₩971	1-696-484-1	1 CABLE, FLAT (F	FC-87)					( SWITCH )				
******	********	*********	*****	*****	******	S519 S520		SWITCH, SLIDE SWITCH, KEY E		ART/STI	)P)	
*	A-7063-319-	A SL-27 BOARD, (	OMPLETE							, • 1		
		**********			i,000 Series)			( CABLE, FLAT	Γ >			
			(IIC	110 0	, , , , , , , , , , , , , , , , , , , ,	W519	1-696-488-11	CABLE, FLAT	(FFC-92)			
		<pre>〈 CAPACITOR 〉</pre>										****
0504	1 100 001 1	1 FLEAT OULD	10	201	16V	******	***********	**********	********	*****	*****	****
C521		1 ELECT CHIP	10uF	20%	16V							
C522		1 ELECT CHIP	10uF	20%	16V							
C524	1-128-013-1	1 ELECT CHIP	1uF	20%	50V	I						

## VC-122

Ref. No.	Part No.	Description			Remark	Ref. No.	Part No.	Description			Remark
*	A-7063-317-A	VC-122 BOARD,	*****	No 3,	000 Series)	C804 C805 C806 C807	1-162-974-11 1-162-971-11 1-162-974-11	CERAMIC CHIP CERAMIC CHIP CERAMIC CHIP CERAMIC CHIP	0. 01uF 0. 001uF 0. 01uF		50V 50V 50V
		〈 CAPACITOR 〉				C808	1-135-091-00	TANTALUM CHIP	1uF	20%	16V
C701 C702 C703 C705 C706	1-164-633-11 1-164-361-11 1-164-360-11	TANTALUM CHIP CERAMIC CHIP CERAMIC CHIP CERAMIC CHIP CERAMIC CHIP	0. 1uF 0. 047uF 0. 1uF	20% 10%	10V 25V 16V 16V 25V	C809 C810 C811 C813 C814	1-164-360-11 1-164-360-11 21-164-360-11	TANTALUM CHIP CERAMIC CHIP CERAMIC CHIP CERAMIC CHIP CERAMIC CHIP	0. 1uF 0. 1uF 0. 1uF	20%	6. 3V 16V 16V 16V 50V
C707 C708 C709 C710 C711	1-162-974-11 1-135-259-11 1-162-974-11	CERAMIC CHIP CERAMIC CHIP TANTAL. CHIP CERAMIC CHIP TANTALUM CHIP	0. 01uF 10uF 0. 01uF	20% 20%	50V 50V 6. 3V 50V 6. 3V	C815 C816 C817 C818 C819	1-162-974-11 1-162-974-11 1-135-091-00	TANTALUM CHIP CERAMIC CHIP CERAMIC CHIP TANTALUM CHIP CERAMIC CHIP	0. 01uF 0. 01uF 1uF	20%	6. 3V 50V 50V 16V
C712 C713 C714 C716 C717	1-162-947-11 1-164-360-11 1-164-360-11		0. 1uF 33PF 0. 1uF 0. 1uF 10uF	5% 20%	16V 50V 16V 16V 6. 3V	C820 C821 C823 C824 C826	1-162-947-11 1-135-091-00 1-164-360-11	TANTALUM CHIP CERAMIC CHIP TANTALUM CHIP CERAMIC CHIP CERAMIC CHIP	33PF 1uF 0. 1uF	20% 5% 20%	16V 50V 16V 16V
C718 C719 C721 C722 C723	1-162-974-11 1-162-974-11 1-162-974-11	CERAMIC CHIP CERAMIC CHIP CERAMIC CHIP CERAMIC CHIP TANTALUM CHIP	0. 01uF	20%	16V 50V 50V 50V 6. 3V	C827 C830 C832 C833 C834	1-164-156-11 1-162-971-11 1-162-974-11	CERAMIC CHIP CERAMIC CHIP CERAMIC CHIP CERAMIC CHIP CERAMIC CHIP	0. 1uF 0. 1uF 0. 001uF 0. 01uF 0. 1uF		16V 25V 50V 50V 16V
C724 C725 C726 C727 C728	1-135-259-11 1-164-360-11 1-135-181-21	CERAMIC CHIP TANTAL. CHIP CERAMIC CHIP TANTALUM CHIP CERAMIC CHIP	10uF 0. 1uF 4. 7uF	20% 20%	16V 6. 3V 16V 6. 3V 50V	C835 C836 C837 C838 C839	1-126-205-11 1-162-974-11 1-135-145-11	CERAMIC CHIP ELECT CHIP CERAMIC CHIP TANTALUM CHIP CERAMIC CHIP		20% 10%	50V 6. 3V 50V 35V 50V
C729 C730 C731 C733 C734	1-162-971-11 1-164-360-11 1-162-974-11	CERAMIC CHIP	0. 1uF 0. 001uF 0. 1uF 0. 01uF 0. 1uF		16V 50V 16V 50V 25V	C841 C851 C852 C853 C854	1-164-633-11 1-162-971-11 1-164-634-11	CERAMIC CHIP CERAMIC CHIP CERAMIC CHIP CERAMIC CHIP CERAMIC CHIP	0. 1uF 0. 1uF 0. 001uF 1uF 0. 01uF	10%	16V 25V 50V 16V 50V
C735 C736 C737 C738 C739	1-164-360-11 1-135-181-21 1-164-360-11	CERAMIC CHIP CERAMIC CHIP TANTALUM CHIP CERAMIC CHIP CERAMIC CHIP	0. 1uF 4. 7uF 0. 1uF	20%	50V 16V 6. 3V 16V 50V	C855 C856 C857 C858 C859	1-162-974-11 1-164-360-11 1-162-974-11	CERAMIC CHIP CERAMIC CHIP CERAMIC CHIP CERAMIC CHIP TANTALUM CHIP	0. 01uF 0. 1uF 0. 01uF	20%	16V 50V 16V 50V 6. 3V
C741 C742 C745 C749 C750	1-135-181-21 1-162-974-11 1-135-259-11	CERAMIC CHIP TANTALUM CHIP CERAMIC CHIP TANTAL. CHIP CERAMIC CHIP	4. 7uF 0. 01uF 10uF	20% 20%	50V 6. 3V 50V 6. 3V 16V	C860 C861 C862 C863 C864	1-162-974-11			20%	6. 3V 50V 50V 50V 16V
C751 C752 C801 C802 C803	1-162-943-11 1-135-259-11 1-162-920-11	CERAMIC CHIP CERAMIC CHIP TANTAL. CHIP CERAMIC CHIP TANTALUM CHIP	15PF 10uF 27PF	5% 20% 5% 20%	50V 50V 6. 3V 50V 6. 3V	C866 C868 C869 C870 C871	1-164-173-11 1-164-005-11	CERAMIC CHIP CERAMIC CHIP CERAMIC CHIP CERAMIC CHIP CERAMIC CHIP	0. 0039uF 0. 47uF	10%	50V 16V 50V 25V 16V

CONNECTOR BOARD TO BOARD 18P L893 1-412-086-31 INDUCTOR CHIP 10-H L893 1-412-085-11 INDUCTOR CHIP 10-H L993 1-412-085-11 INDUCTOR CHIP 10-H L893 1-412-085-11 INDUCTOR CHIP 10-H L993 1-412-085-11 INDUCTOR CHIP 10-H L993 1-412-085-11 I	Ref. No.	Part No.	Description	Remark	Ref. No.	Part No.	Description			Remark
LB03			〈 CONNECTOR 〉		L802	1-412-006-31	INDUCTOR CHIP	10uH		
CR851   1-573-386-11 CONNECTOR, BOARD 16P   L851   1-412-0586-11 INDUCTOR CHIP PT-MH										
CR851   1-573-361-11 CONNECTOR, FFC/FPC 21P										
(TRIMER) (TR										
CT801   1-141-356-11 CAP, ADJ 6P	CN851	1-573-361-11	CONNECTOR, FFC/FPC 21P		L853	1-412-031-11	INDUCTOR CHIP	47uH		
(FILTER)  (FILTE			⟨ TRIMMER ⟩				<pre>&lt; TRANSISTOR &gt;</pre>			
(FILTER)  (FILTE	CT801	1-141-356-11	CAP AD.1 6P		0701	8-729-928-87	TRANSISTOR DTO	124EE		
FL701   1-288-834-21 FILTER LOW PASS   1768   8-729-425-81 TRANSISTOR ZSB214620   1-415-751-21 DELAY LINE, LC (YH)   (IC )   0708   8-729-425-81 TRANSISTOR ZSB22160   1707   8-729-425-81 TRANSISTOR TRANSISTOR ZSB22160   1707   8-729-425-81 TRANSISTOR ZSB22160   1707   8-729-425-81 TRANSISTOR ZSB22160   1707	01001	1 141 000 11	0/11, 7/00 GI							
FLT01 1-238-834-21 FILTER, LOW PASS FLT02 1-415-751-21 DELAY LINE, LC (YH)  ( IC )  (			⟨ FILTER ⟩		0703	8-729-427-74	TRANSISTOR XP4	601		
Color										
( IC )			•		0706	8-729-425-64	TRANSISTOR 2SD	22160		
C701   8-759-243-19   C TC75004F   0709   8-729-425-64 TRANSISTOR ZSD22160   0709   8-729-427-72 TRANSISTOR ZSD22160   0709   8-729-425-64 TRANSISTOR ZSD22160   0709   8-729-425-64 TRANSISTOR ZSD22160   0709   8-729-425-64 TRANSISTOR ZSD22160   0709	FL702	1-415-751-21	DELAY LINE, LC (YH)		0707	0 720 420 04	TRANSICTOR HAIC	1111		
1C701   8-759-243-19   1C TC7SU04F   0801   8-729-427-72 TRANSISTOR XP4501			/ IC \							
C701   8-759-243-19   C TC7SUGF   0802   8-759-243-19   C TC7SUGF   0802   8-759-064-36   C MB88346BPF-EF   0802   8-729-427-70 TRANSISTOR XP4401			(10)							
1C702 8-759-710-7   C N.M2234M	10701	8-759-243-19	LC TC7SU04F							
ICTO3										
1C705										
1.00										
C706	1C705	8-759-063-18	IC CXD2103AR							
COTO7 8-752-347-93   C CXD2100A0   CRESISTOR	10700	A 350 A55 50			Q853	8-729-427-70	TRANSISTOR XP4	401		
1C709 8-752-840-64   1C CXP80624-434R							/ PECISTOR \			
1C712							/ NESISION /			
12801 8-752-350-16   C CXD1257AR   R702 1-216-821-11 METAL CHIP   2K   5K   1/16W					R701	1-216-857-11	METAL CHIP	1M	5%	1/16W
R703   1-216-837-11   METAL CHIP   22K   5%   1/16W										
12803 8-752-053-26   C CXA13990   R705 1-216-833-11 METAL CHIP   10K   5%   1/16W   1/2604 8-752-327-48   C CXD1250N   R706 1-216-825-11 METAL CHIP   2. 2K   5%   1/16W   1/2651 8-759-701-24   C NJM3414M   R707 1-216-825-11 METAL CHIP   2. 2K   5%   1/16W   1/2652 8-759-998-96   C LM324D   R708 1-216-845-11 METAL CHIP   10K   5%   1/16W   1/2653 8-759-058-47   C MPC1724VMEL   R710 1-216-857-11 METAL CHIP   33K   5%   1/16W   1/2653 8-759-998-98   C LM358D   R711 1-216-864-11 METAL CHIP   1M   5%   1/16W   1/2658 8-759-998-98   C LM358D   R711 1-216-821-11 METAL CHIP   1K   5%   1/16W   1/2658 8-759-998-98   C LM358D   R711 1-216-821-11 METAL CHIP   1K   5%   1/16W   1/266-821-11 METAL CHIP					R703			22K	5%	
10804   8-752-327-48   10 CXD1250N   1 C805   8-752-054-61   10 CXA1390AR   R706   1-216-825-11   METAL CHIP   2. 2K   5%   1/16W   R707   1-216-825-11   METAL CHIP   2. 2K   5%   1/16W   R708   1-216-825-11   METAL CHIP   2. 2K   5%   1/16W   R708   1-216-825-11   METAL CHIP   100K   1/16W   R709   1-216-825-11   METAL CHIP   100K   1/16W   R709   1-216-825-11   METAL CHIP   100K   1/16W   R709   1-216-821-11   METAL CHIP   100K   1/16W   R709   1-216-825-11   METAL CHIP   100K   1/16W   R709   1-216-82										•
10805   8-752-054-61   10 CXA1390AR   R706   1-216-825-11   METAL CHIP   2. 2K   5%   1/16W   R707   1-216-825-11   METAL CHIP   2. 2K   5%   1/16W   R708   1-216-835-11   METAL CHIP   2. 2K   5%   1/16W   R708   1-216-835-11   METAL CHIP   33K   5%   1/16W   R709   1-216-839-11   METAL CHIP   1M   5%   1/16W   R709   1-216-839-11   METAL CHIP   1M   5%   1/16W   R709   1-216-825-11   METAL CHIP   1M   5%   1/16W   R709   1-216-825-11   METAL CHIP   1M   5%   1/16W   R709   1-216-821-11   METAL CHIP   1K   5%   1/16W   R709   1-216-825-11   METAL CHIP					R705	1-216-833-11	METAL CHIP	10K	5%	1/16W
1.0851 8-759-701-24   1.0 N_M3414M   R707					P70C	1 010 005 11	MCTAL CHID	2 24	E0/	4 /4 CW
R708   1-216-845-11   METAL CHIP   33K   5%   1/16W   R709   1-216-839-11   METAL CHIP   33K   5%   1/16W   R709   1-216-839-11   METAL CHIP   33K   5%   1/16W   R709   1-216-839-11   METAL CHIP   33K   5%   1/16W   R709   1-216-825-11   METAL CHIP   1M   5%   1/16W   R709   1-216-821-11   METAL CHIP   1M   1/16W   R709   1-216-821-11   METAL CHIP   1/16W   1/16										
1	10001	0-109-101-24	16 NOMO414M		1					•
R710   1-216-857-11   METAL CHIP   1M   5%   1/16W	IC852	8-759-998-96	IC LM324D							
R711   1-216-864-11   METAL CHIP   0   5%   1/16W   R712   1-216-821-11   METAL CHIP   1K   5%   1/16W   R713   1-216-821-11   METAL CHIP   1K   5%   1/16W   R713   1-216-821-11   METAL CHIP   1K   5%   1/16W   R714   1-216-821-11   METAL CHIP   1K   5%   1/16W   R715   1-216-821-11   METAL CHIP   1K   5%   1/16W   R715   1-216-821-11   METAL CHIP   1K   5%   1/16W   R715   1-216-821-11   METAL CHIP   1K   5%   1/16W   R716   1-216-821-11   METAL CHIP   1K   5%   1/16W   R716   1-216-821-11   METAL CHIP   1K   5%   1/16W   R718   1-216-821-11   METAL CHIP   1K   5%   1/16W   R719   1-216-825-11   METAL CHIP   1K   5%   1/16W   R721   1-216-825-11   METAL CHIP   2. 2K   5%   1/16W   R721   1-216-825-11   METAL CHIP   2. 2K   5%   1/16W   R721   1-216-825-11   METAL CHIP   2. 2K   5%   1/16W   R722   1-216-825-11   METAL CHIP   2. 2K   5%   1/16W   R721   1-216-825-11   METAL CHIP   2. 2K   5%   1/16W   R722   1-216-825-11   METAL CHIP   2. 2K   5%   1/16W   R723   1-216-825-11   METAL CHIP   3. 3K   5%   1/16W   R725   1-216-825-11   METAL CHIP   3. 3K   5%   1/16W   R727   1-216-825-11   METAL CHIP   2. 2K   5%   1/16W   R727   1-216-825-11   METAL CHIP   2. 2K   5%   1/16W   R727   1-216-825-11   METAL CHIP   2. 2K   5%   1/16W   R728   1-216-825-11   METAL CHIP   2. 2K   5%   1/16W   R728   1-216-825-11   METAL CHIP   2. 2K   5%   1/16W   R728   1-216-825-11   METAL CHIP   2. 2K   5%   1/16W   R729   1-216-825-1	IC853	8-759-058-47	' IC MPC1724VMEL		R710	1-216-857-11	METAL CHIP			
R712   1-216-821-11   METAL CHIP   1K   5%   1/16W										
R713   1-216-821-11   METAL CHIP   1K   5%   1/16W   R714   1-216-821-11   METAL CHIP   1K   5%   1/16W   R715   1-216-821-11   METAL CHIP   1K   5%   1/16W   R716   1-216-821-11   METAL CHIP   1K   5%   1/16W   R716   1-216-821-11   METAL CHIP   1K   5%   1/16W   R716   1-216-821-11   METAL CHIP   1K   5%   1/16W   R718   1-216-821-11   METAL CHIP   1K   5%   1/16W   R718   1-216-821-11   METAL CHIP   1K   5%   1/16W   R719   1-216-840-11   METAL CHIP   39K   5%   1/16W   R721   1-216-825-11   METAL CHIP   2. 2K   5%   1/16W   R721   1-216-829-11   METAL CHIP   3. 3K   5%   1/16W   R721   1-216-829-11   METAL CHIP   3. 3K   5%   1/16W   R721   1-216-829-11   METAL CHIP   3. 3K   5%   1/16W   R721   1-216-827-11   METAL CHIP   3. 3K   5%   1/16W   R722   1-216-827-11   METAL CHIP   3. 3K   5%   1/16W   R723   1-216-827-11   METAL CHIP   3. 3K   5%   1/16W   R723   1-216-825-11   METAL CHIP   2. 2K   5%   1/16W   R723   1-216-825-11   METAL CHIP   3. 3K   5%   1/16W   R723	1C856	8-759-998-98	B IC LM358D		1					
R714   1-216-821-11 METAL CHIP   1K   5%   1/16W			/ <b>0</b> 011 \		1					
L701 1-412-006-31 INDUCTOR CHIP 10uH L703 1-412-052-21 INDUCTOR CHIP 1uH L704 1-412-066-31 INDUCTOR CHIP 10uH L705 1-412-979-21 INDUCTOR CHIP 4ruH L706 1-412-062-11 INDUCTOR CHIP 4ruH L708 1-412-062-11 INDUCTOR CHIP 4ruH L709 1-412-052-21 INDUCTOR 1uH L709 1-412-052-21 INDUCTOR 1uH L709 1-412-052-21 INDUCTOR CHIP 1uH L710 1-412-052-21 INDUCTOR CHIP 1uH L711 1-412-052-21 INDUCTOR CHIP 1uH L712 1-412-052-21 INDUCTOR CHIP 1uH L714 1-412-052-31 INDUCTOR CHIP 1uH L715 1-412-052-31 INDUCTOR CHIP 1uH L716 R721 1-216-825-11 METAL CHIP L717 1-412-058-11 INDUCTOR CHIP 1uH L718 R721 1-216-829-11 METAL CHIP L719 R721 1-216-829-11 METAL CHIP L710 R721 1-216-829-11 METAL CHIP L711 1-412-058-11 INDUCTOR CHIP 1uH L712 1-412-058-11 INDUCTOR CHIP 1uH L713 1-412-058-11 INDUCTOR CHIP 1uH L714 1-412-058-11 INDUCTOR CHIP 1uH L715 1-412-058-11 INDUCTOR CHIP 1uH L717 1-412-058-11 INDUCTOR CHIP 1uH L717 1-412-058-11 INDUCTOR CHIP 1uH L719 1-412-058-11 INDUCTOR CHIP 1uH L710 1-412-058-11 INDUCTOR CHIP 1uH L711 1-			( COIL )							
L703 1-412-052-21 INDUCTOR CHIP 1uH L704 1-412-06-31 INDUCTOR CHIP 10uH R716 1-216-821-11 METAL CHIP 1K 5% 1/16W L705 1-412-979-21 INDUCTOR 1uH R718 1-216-821-11 METAL CHIP 1K 5% 1/16W R719 1-216-840-11 METAL CHIP 39K 5% 1/16W R721 1-216-825-11 METAL CHIP 2. 2K 5% 1/16W R722 1-216-825-11 METAL CHIP 2. 2K 5% 1/16W R723 1-216-825-11 METAL CHIP 2. 2K 5% 1/16W R724 1-216-825-11 METAL CHIP 10K 5% 1/16W R725 1-216-825-11 METAL CHIP 1	I 701	1-412-006-31	INDUCTOR CHIP 10uH							
Total								•••	574	1, 10
R719   1-216-840-11   METAL CHIP   39K   5%   1/16W   R721   1-216-825-11   METAL CHIP   2. 2K   5%   1/16W   R721   1-216-825-11   METAL CHIP   2. 2K   5%   1/16W   R722   1-216-825-11   METAL CHIP   2. 2K   5%   1/16W   R722   1-216-825-11   METAL CHIP   2. 2K   5%   1/16W   R722   1-216-825-11   METAL CHIP   2. 2K   5%   1/16W   R723   1-216-825-11   METAL CHIP   10K   5%   1/16W   R724   1-216-829-11   METAL CHIP   4. 7K   5%   1/16W   R724   1-216-829-11   METAL CHIP   4. 7K   5%   1/16W   R725   1-216-821-11   METAL CHIP   1K   5%   1/16W   R727   1-216-827-11   METAL CHIP   3. 3K   5%   1/16W   R727   1-216-827-11   METAL CHIP   3. 3K   5%   1/16W   R728   1-216-813-11   METAL CHIP   220   5%   1/16W   R728   1-216-813-11   METAL CHIP   2. 2K   5%   1/16W   R729   1-216-825-11   METAL CHIP   2. 2K   5%   1/16W   R730   1-216-825-11   METAL CHIP   2. 2K   5%   1/16W   R730   1-216-825-11   METAL CHIP   2. 2K   5%   1/16W   R731   1-216-295-00   METAL CHIP   0   5%   1/10W   R731   1-216-295-00   METAL CHIP   0   0   0   0   0   0   0   0   0		1-412-006-31	INDUCTOR CHIP 10uH		R716	1-216-821-11	METAL CHIP	1K	5%	1/16W
R721   1-216-825-11   METAL CHIP   2. 2K   5%   1/16W	L705	1-412-979-21	NDUCTOR 1uH		R718	1-216-821-11	METAL CHIP	1K	5%	1/16W
L708 1-412-979-21 INDUCTOR 1uH L710 1-412-052-21 INDUCTOR CHIP 1uH L711 1-412-058-11 INDUCTOR CHIP 10uH L712 1-412-052-21 INDUCTOR CHIP 10uH L714 1-412-006-31 INDUCTOR CHIP 10uH L715 1-412-058-11 INDUCTOR CHIP 10uH L716 1-412-058-11 INDUCTOR CHIP 10uH L717 1-412-058-11 INDUCTOR CHIP 10uH L718 1-412-066-31 INDUCTOR CHIP 10uH L719 1-412-066-31 INDUCTOR CHIP 10uH L719 1-412-058-11 INDUCTOR CHIP 10uH L719 1-412-068-11 INDUCTOR CHIP 10uH L720 1-412-068-31 INDUCTOR CHIP 10uH L720 1-412-068-31 INDUCTOR CHIP 10uH L721 1-410-391-11 INDUCTOR CHIP 10uH L731 1-216-825-11 METAL CHIP 2. 2K 5% 1/16W L731 1-216-825-11 METAL CHIP 0 5% 1/10W	L706	1-412-062-11	INDUCTOR CHIP 47uH		1					
L710 1-412-052-21 INDUCTOR CHIP 1uH  L711 1-412-058-11 INDUCTOR CHIP 10uH  L712 1-412-052-21 INDUCTOR CHIP 1uH  L714 1-412-006-31 INDUCTOR CHIP 10uH  L715 1-412-058-11 INDUCTOR CHIP 10uH  L717 1-412-058-11 INDUCTOR CHIP 10uH  L718 1-412-066-31 INDUCTOR CHIP 10uH  L719 1-412-066-31 INDUCTOR CHIP 10uH  L710 1-412-066-31 INDUCTOR CHIP 10uH  L720 1-412-066-31 INDUCTOR CHIP 10uH  L720 1-412-066-31 INDUCTOR CHIP 10uH  L721 1-410-391-11 INDUCTOR CHIP 68uH  L721 1-410-391-11 INDUCTOR CHIP 10uH  L721 1-412-029-11 INDUCTOR CHIP 10uH  R730 1-216-825-11 METAL CHIP 2. 2K 5% 1/16W  R731 1-216-295-00 METAL CHIP 0 5% 1/10W	1.700	4 440 070 04	4.11		1					
L711 1-412-058-11 INDUCTOR CHIP 10uH R723 1-216-833-11 METAL CHIP 10K 5% 1/16W R724 1-216-829-11 METAL CHIP 4. 7K 5% 1/16W R724 1-216-829-11 METAL CHIP 1 K 5% 1/16W R725 1-216-821-11 METAL CHIP 1 K 5% 1/16W R727 1-216-827-11 METAL CHIP 3. 3K 5% 1/16W R727 1-216-827-11 METAL CHIP 220 5% 1/16W R728 1-216-813-11 METAL CHIP 220 5% 1/16W R729 1-216-825-11 METAL CHIP 2. 2K 5% 1/16W R729 1-216-825-11 METAL CHIP 2. 2K 5% 1/16W R729 1-216-825-11 METAL CHIP 2. 2K 5% 1/16W R730 1-216-825-11 METAL CHIP 2. 2K 5% 1/16W R730 1-216-825-11 METAL CHIP 2. 2K 5% 1/16W R730 1-216-825-11 METAL CHIP 3. 3K 5% 1/16W R730 1-216-825-10 METAL CHIP 3. 3K 5% 1					K/22	1-216-825-11	METAL CHIP	2. 2K	5%	1/16W
L712 1-412-052-21 INDUCTOR CHIP 1uH L714 1-412-006-31 INDUCTOR CHIP 10uH R725 1-216-829-11 METAL CHIP 1K 5% 1/16W R727 1-216-827-11 METAL CHIP 3. 3K 5% 1/16W R727 1-216-827-11 METAL CHIP 220 5% 1/16W R728 1-216-813-11 METAL CHIP 220 5% 1/16W L717 1-412-058-11 INDUCTOR CHIP 10uH L720 1-412-006-31 INDUCTOR CHIP 10uH R729 1-216-825-11 METAL CHIP 2. 2K 5% 1/16W L721 1-410-391-11 INDUCTOR CHIP 68uH R730 1-216-825-11 METAL CHIP 2. 2K 5% 1/16W R731 1-216-295-00 METAL CHIP 0 5% 1/10W					R723	1-216-833-11	METAL CHIP	10K	54	1/16W
L714 1-412-006-31 INDUCTOR CHIP 10uH  R725 1-216-821-11 METAL CHIP 1K 5% 1/16W  R727 1-216-827-11 METAL CHIP 3. 3K 5% 1/16W  R728 1-216-813-11 METAL CHIP 220 5% 1/16W  R728 1-216-813-11 METAL CHIP 220 5% 1/16W  R729 1-216-825-11 METAL CHIP 2. 2K 5% 1/16W  R729 1-216-825-11 METAL CHIP 2. 2K 5% 1/16W  R720 1-412-006-31 INDUCTOR CHIP 10uH  R729 1-216-825-11 METAL CHIP 2. 2K 5% 1/16W  R730 1-216-825-11 METAL CHIP 2. 2K 5% 1/16W  R731 1-216-295-00 METAL CHIP 0 5% 1/10W					1					•
R727 1-216-827-11 METAL CHIP 3. 3K 5% 1/16W L715 1-412-058-11 INDUCTOR CHIP 10uH L717 1-412-058-11 INDUCTOR CHIP 10uH L720 1-412-006-31 INDUCTOR CHIP 10uH L721 1-410-391-11 INDUCTOR CHIP 68uH L801 1-412-029-11 INDUCTOR CHIP 10uH R730 1-216-825-11 METAL CHIP 2. 2K 5% 1/16W R731 1-216-295-00 METAL CHIP 0 5% 1/10W										
L717 1-412-058-11 INDUCTOR CHIP 10uH  L720 1-412-006-31 INDUCTOR CHIP 10uH  R729 1-216-825-11 METAL CHIP 2. 2K 5% 1/16W  L721 1-410-391-11 INDUCTOR CHIP 68uH  R730 1-216-825-11 METAL CHIP 2. 2K 5% 1/16W  R731 1-216-295-00 METAL CHIP 0 5% 1/10W					R727			3. 3K		1/16W
L720 1-412-006-31 INDUCTOR CHIP 10uH R729 1-216-825-11 METAL CHIP 2. 2K 5% 1/16W R730 1-216-825-11 METAL CHIP 2. 2K 5% 1/16W R730 1-216-825-11 METAL CHIP 2. 2K 5% 1/16W R731 1-216-295-00 METAL CHIP 0 5% 1/10W					R728	1-216-813-11	METAL CHIP	220	5%	1/16W
L721 1-410-391-11 INDUCTOR CHIP 68uH R730 (1-216-825-11 METAL CHIP 2. 2K 5% 1/16W R731 1-216-295-00 METAL CHIP 0 5% 1/10W					page	4 040 005 11	METAL CILIP	0.01	WW-	4 /4 0111
L801 1-412-029-11 INDUCTOR CHIP 10uH R731 1-216-295-00 METAL CHIP 0 5% 1/10W										
	_001	, TIE VES 11								

## VC-122

Pof No	Dave No	Donarintian				Remark	l Dof No	Dort No	Dooring	et am				Pama ela
Ref. No.	Part No.	Description				Nemark	Ref. No.	Part No.	Descript	CION				Remark
R733	1-216-827-11	METAL CHIP	3. 3K	5%	1/16W		R803	1-216-823-11	METAL C	HIP	1. 5K	5%	1/16W	
R734	1-216-817-11	METAL CHIP	470	5%	1/16W		R804	1-216-833-11	METAL C	HIP	10K	5%	1/16W	
R735	1-216-834-11	METAL CHIP	12K	5%	1/16W		R805	1-216-845-11	METAL C	HIP	100K	5%	1/16W	
R736	1-216-864-11	METAL CHIP	0	5%	1/16W		R806	1-216-824-11	METAL C	HIP	1. 8K	5%	1/16W	
R738	1-216-821-11	METAL CHIP	1K	5%	1/16W		R807	1-216-817-11	METAL C	HIP	470	5%	1/16W	
R739	1-216-833-11	METAL CHIP	10K	5%	1/16W		R808	1-216-801-11			22	5%	1/16W	
R742	1-216-821-11	METAL CHIP	1K	5%	1/16W		R809	1-216-825-11			2. 2K	5%	1/16W	
R744	1-216-833-11	METAL CHIP	10K	5%	1/16W		R810	1-216-825-11	METAL C	HIP	2. 2K	5%	1/16W	
R745	1-216-827-11	METAL CHIP	3. 3K		1/16W		R812	1-216-825-11	METAL C	HIP	2. 2K	5%	1/16W	
R748	1-216-864-11		0	5%	1/16W		R813	1-216-825-11	METAL C	HIP	2. 2K	5%	1/16W	
R749	1-216-841-11	METAL CHIP	47K	5%	1/16W		R816	1-216-833-11	METAL C	HIP	10K	5%	1/16W	
D750	1 010 040 11	METAL CHID	ECV	EW	1 /1 CW		D010	1 210 005 11	METAL O		47	FW	4 /4 CW	
R750	1-216-842-11		56K	5%	1/16W		R819	1-216-805-11			47	5%	1/16W	
R751	1-216-821-11		1K	5%	1/16W		R821	1-216-863-11			3. 3M	5%	1/16W	
R752	1-216-817-11		470	5%	1/16W		R823	1-218-721-11			16K	0. 50%		1
R753	1-216-834-11		12K	5%	1/16W		R825	1-216-832-11			8. 2K	5%	1/16W	1
R754	1-216-821-11	METAL CHIP	1K	5%	1/16W		R826	1-216-833-11	MEIAL C	HIP	10K	5%	1/16₩	
R755	1-216-821-11	METAL CHIP	1K	5%	1/16W		R827	1-216-833-11	METAL C	HIP	10K	5%	1/16W	
R756	1-216-857-11		1M	5%	1/16W		R828	1-218-716-11			10K	0. 50%		
R757	1-216-857-11		1M	5%	1/16W		R829	1-218-744-11			150K	0. 50%		
R758	1-216-841-11		47K	5%	1/16W		R830	1-216-821-11			1K	5X	1/16W	
R759	1-216-821-11		1K	5%	1/16W		R851	1-216-837-11			22K	5%	1/16W	
R760	1-216-857-11		1M	5%	1/16W		R852	1-216-821-11			1K	5%	1/16W	
R761	1-216-841-11		47K	5%	1/16W		R853	1-216-827-11			3. 3K	5%	1/16W	
R762	1-216-821-11		1K	5%	1/16W		R854	1-216-833-11	METAL C	HIP	10K	5%	1/16W	į
R769	1-216-821-11	METAL CHIP	1K	5%	1/16W		R855	1-216-826-11	METAL C	HIP	2. 7K	5%	1/16W	
R770	1-216-821-11	METAL CHIP	1K	5%	1/16W		R856	1-216-837-11	METAL C	HIP	22K	5%	1/16W	
R771	1-216-821-11	METAL CHIP	1K	5%	1/16W		R857	1-216-848-11	METAL C	нір	180K	5%	1/16W	
R775	1-216-833-11		10K	5%	1/16W		R858	1-216-837-11			22K	5%	1/16W	
R776	1-216-841-11		47K	5%	1/16W		R859	1-216-845-11			100K	5%	1/16W	
R777	1-216-825-11		2. 2K	5%	1/16W		R860	1-216-827-11			3. 3K	5%	1/16W	
R778	1-216-839-11		33K	5%	1/16W		R861	1-218-724-11			22K	0. 50%		
******	1 210 000 11	me 1716 01111	0011	V/*	17 1011		11001	1 210 124 11	METAL O	***	LLIN	0. 00%	17 1011	
R779	1-216-833-11		10K	5%	1/16W		R862	1-216-848-11	METAL C	HIP	180K	5%	1/16W	
R780	1-216-821-11	METAL CHIP	1K	5%	1/16W		R863	1-216-855-11	METAL C	HIP	680K	5%	1/16W	
R781	1-216-833-11	METAL CHIP	10K	5%	1/16W		R864	1-216-134-00	METAL C	HIP	2. 2	5%	1/8₩	•
R782	1-216-813-11	METAL CHIP	220	5%	1/16W		R865	1-216-829-11	METAL C	HIP	4. 7K	5%	1/16W	
R783	1-216-863-11	METAL CHIP	3. 3M	5%	1/16W		R866	1-216-820-11	METAL C	HIP	820	5%	1/16W	
R784	1-216-823-11	METAL CHIP	1. 5K	5%	1/16W		R867	1-216-837-11	METAL A	нір	22K	5%	1/16W	
R785	1-216-841-11		47K	5%	1/16W		R868	1-216-833-11			10K		1/16W	
R787	1-216-821-11		1K	5%	1/16W		R869	1-216-838-11			27K		1/16W	
R788	1-216-821-11		1K	5%	1/16W		R870	1-216-841-11						
R791	1-216-825-11		2. 2K		1/16W		R871	1-216-833-11			47K		1/16W 1/16W	
10/51	1-210-025-11	MEIAL CHIP	Z. ZN	3/6	1/10#		nori	1-210-033-11	MEIAL C	піг	10K	D/A	1/10#	
R792	1-216-833-11		10K	5%	1/16W		R872	1-216-851-11	METAL C	HIP	330K	5%	1/16W	
R793	1-216-821-11		1K	5%	1/16W		R873	1-216-814-11			270	5%	1/16W	
R794	1-216-827-11	METAL CHIP	3. 3K	5%	1/16W		R874	1-216-842-11	METAL C		56K		1/16W	
R795	1-216-815-11	METAL CHIP	330	5%	1/16W									
R796	1-216-817-11	METAL CHIP	470	5%	1/16W				< NETWO	RK, RES >				
R797	1-216-818-11	METAL CHID	560	5%	1/16W		PP701	1-236-420-11	NETWODY	DEC 4 7	w			
R800	1-216-309-00		5. 6	5%	1/10W			1-236-420-11						
R801	1-216-309-00		o. o	5%	1/16W									
R802	1-216-835-11		15K	5%	1/16W			1-236-412-11 1-236-416-11						4
nouz	1-410-030-11	MEINE UTIP	/CI	IJ/ii	1/10#		1 ND / U4	1-230-410-11	HE I WUNK,	, NES 2. 2	Λ.			

Ref. No.	Part No.	Description			Rema	k Ref. No.	Part No.	Description			Remark
		NETWORK, RES 2.				L502 <b></b> ∆L503		INDUCTOR CHIP COIL, FERRITE			
RB707	1-236-412-11	NETWORK, RES 1. NETWORK, RES 1. NETWORK, RES 1.	0K					〈 TRANSISTOR 〉			
UD100	1-230-412-11		UK			Q501 Q502		TRANSISTOR 2SC TRANSISTOR 2SA			
V701	1 570 552 11	( CRYSTAL )	-)			Q504		TRANSISTOR 2SD		SP .	
X701 X801		VIBRATOR (12MHz VIBRATOR, CRYST		363MHz	)			〈 RESISTOR 〉			
*****	******	*********	*******	*****	******	* R501 R502	1-216-033-00 1-216-041-00		220	5% 5%	1/10W
*	A-7063-220-A	VF-42 BOARD, CO				R503	1-216-041-00	METAL CHIP	470 470	5%	1/10W 1/10W
		*********		No 1,	000 Serie	R506 R507	1-216-069-00 1-216-047-00		6. 8K 820	5% 5%	1/10W 1/10W
	3-942-888-01	HOLDER, LED				R508	1-216-689-11		39K		1/10W
		( CAPACITOR )				R509 R510	1-216-689-11 1-216-005-00		39K 15	0. 5% 5%	1/10W 1/10W
						R511	1-216-121-00		1M	5%	1/10W
C501 C502	1-126-176-11		220uF ). 1uF	20% 10%	10V 25V	R512	1-216-131-11	METAL CHIP	2. 7M	5%	1/10W
			1. Tur 17PF	5%	50V	R513	1-216-101-00	METAL CHIP	150K	5%	1/10W
<b><u></u><b>∆C</b>504</b>			). 001uF	10%	50V	R514	1-216-121-00		1M	5%	1/10W
<b> ∆</b> C505	1-164-758-11	CERAMIC CHIP	). 0039uF	5%	50V	R515	1-216-131-11		2. 7M	5%	1/10W
<b>∱</b> C506	1 104 715 11	CERAMIC CHIP (	). 0068uF	5%	50V	R516 R517	1-216-055-00		1. 8K	5%	1/10W
_			1. 0000ur 17uF	20%	6. 3V	norr	1-216-025-00	METAL CHIP	100	5%	1/10W
C508			). 001uF	10%	500V	R518	1-216-308-00	METAL CHIP	4. 7	5%	1/10W
C509	1-124-257-00		2. 2uF	20%	50V	R519	1-216-336-11		47K	1%	1/10W
C510	1-163-037-11	CERAMIC CHIP	). 022uF	10%	25V	R520 R521	1-216-107-00 1-216-121-00		270K	5%	1/10W
C511	1-126-090-11	ELECT 8	32uF	20%	10V	R522	1-216-121-00		1M 27	5% 5%	1/10W 1/8W
C512	1-137-306-11		). 1uF	5%	16V	11000	. 2.0 .00 00	m=1710 01111		0/1	17011
		TANTALUM CHIP		20%	10V		1-216-053-00		1. 5K	5%	1/10W
C514 C515	1-131-381-00 1-163-037-11	CERAMIC CHIP	17uF ). 022uF	10% 10%	10V 25V	R524 R525	1-216-113-00 1-216-097-00		470K 100K		1/10W 1/10W
C516	1-135-149-21	TANTALUM CHIP 2	2. 2uF	20%	10V			( VARIABLE RES	STOR >		
		( CONNECTOR )				RV501	1-241-596-11	RES, ADJ, METAL	GRAZE	47K	
+ 011504	4 500 750 44		(00 00100			RV502	1-241-590-11	RES, ADJ, METAL	GRAZE	470	
		PIN, CONNECTOR PIN, CONNECTOR						RES, ADJ, METAL RES, ADJ, METAL			
* CN503	1-566-195-11	PIN, CONNECTOR	(PC BOARD	) 2P				( TRANSFORMER )			
		⟨ DIODE ⟩					1-439-486-11	TRANSFORMER ASS		RACK	
		DIODE TLS221				23.00	. 100 100 11		, , , , , ,	Drioit	
D502 D503	8-719-984-02 8-719-400-20	DIODE MA152WA	BR4371F					( THERMISTOR )			
		( 1C )				TH501	1-809-350-21	THERMISTOR, NTO	(2125	) 500	
IC501	8-759-420-01	IC AN2512S						( CABLE, FLAT )			
		( COIL )				<u></u> <b>₩501</b>	1-540-019-21	SOCKET ASSY, CF	RT		
L501	1-408-976-21	INDUCTOR	33uH			******	*********	*************	*****	*****	*******

The components identified by mark ⚠ or dotted line with mark ⚠ are critical for safety.

Replace only with part number specified.

# VK-27 VS-95

Ref. No.	Part No.	Description	Remark	Ref. No.	Part No.	Description			Remark
*	A-7071-653-A	VK-27 BOARD, COMPLETE		C026	1-164-360-11	CERAMIC CHIP	0. 1uF		16V
		*******		C027		CERAMIC CHIP			16V
		(Ref.	No 9,000 Series)	C028	1-162-974-11	CERAMIC CHIP	0. 01uF		50V
				C029		CERAMIC CHIP			16V
		( DIODE )		C030	1-135-259-11	TANTAL. CHIP	10uF	20%	6. 3V
D976	8-719-404-46	DIODE MA110		C035		TANTALUM CHIP		20%	6. 3V
				C049		CERAMIC CHIP			50V
		( SWITCH )		C057		CERAMIC CHIP			50V
S976	1_572_021_21	SWITCH, KEY BOARD (STOP	٥١	C058		CERAMIC CHIP			50V
S977		SWITCH, KET BUARD (STOP	7)	C059	1-102-9/4-11	CERAMIC CHIP	0. 01uF		50V
S978		SWITCH, TACTIL (2 CLICK	O.	C061	1-162-074-11	CERAMIC CHIP	0.01		50V
3310	1 032 247 11	SHITOH, THOTTE (2 OF OF	(EDIT SEARCH (-)			CERAMIC CHIP			50V
S979	1-572-921-31	SWITCH, KEY BOARD (REW)		C064		CERAMIC CHIP			50V
S980		SWITCH, KEY BOARD (PB)		C065		CERAMIC CHIP			50V
				C066		CERAMIC CHIP			50V
S981	1-692-247-11	SWITCH, TACTIL (2 CLICK	()			0	0.0.4.		
		,	(EDIT SEARCH (+)	C067	1-162-995-11	CERAMIC CHIP	0. 022uF		50V
S983	1-572-921-31	SWITCH, KEY BOARD (FF)		C068			47PF	5%	50V
S984	1-572-921-31	SWITCH, KEY BOARD (PAUS	SE)	C069	1-162-948-11	CERAMIC CHIP	39PF	5%	50V
				C070	1-162-953-11	CERAMIC CHIP	100PF	5%	50V
		〈 CABLE, FLAT 〉		C072	1-162-943-11	CERAMIC CHIP	15PF	5%	50V
WAST	4 000 000 44	DE EA4 ELEVIDI E BAIDS							
W987	1-696-622-11	PF-591 FLEXIBLE BOARD		C073		CERAMIC CHIP		5%	50V
40 alle ale ale ale ale ale ale ale				C074			180PF	5%	50V
*****	******	**********	******	C075		CERAMIC CHIP		5%	50V
*	A-7063-316-A	VS-95 BOARD, COMPLETE		C077 C078			0. 022uF 3PF	10% 0. 25Pi	25V
Ψ.	A 1003 310 A	************		0076	1-102-934-11	CENAMIC CHIP	3rr	U. 23F	F3U <b>V</b>
			No 4,000 Series)	C080	1-162-970-11	CERAMIC CHIP	0. 01uF	10%	25V
		(,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,	,,,	C081			18PF	5%	50V
	1-691-471-11	CONNECTOR, TRANSLATION	11P	C082		CERAMIC CHIP		10%	25V
				C083	1-164-227-11	CERAMIC CHIP	0. 022uF	10%	25V
		( CAPACITOR )		C085	1-162-947-11	CERAMIC CHIP	33PF	5%	50V
C001	1-162-974-11	CERAMIC CHIP 0.01uF	50V	C086	1-162-970-11	CERAMIC CHIP	0 01uE	10%	25V
C002		CERAMIC CHIP 100PF	5% 50V	C091		CERAMIC CHIP		1070	50V
C003	1-162-955-11	CERAMIC CHIP 150PF	5% 50V	C121		CERAMIC CHIP			50V
C004	1-162-953-11	CERAMIC CHIP 100PF	5% 50V	C122		CERAMIC CHIP			50V
C005	1-162-953-11	CERAMIC CHIP 100PF	5% 50V	C123	1-135-181-21	TANTALUM CHIP	4. 7uF	20%	6. 3V
C006	1-164-622-11	CERAMIC CHIP 0. 1uF	10% 25V	C124	1-164-246-11	CERAMIC CHIP	1		16V
C009		CERAMIC CHIP 0.1uF	167	C125		CERAMIC CHIP			50V
C010		TANTALUM CHIP 10uF	20% 6. 3V	C126		CERAMIC CHIP	0. 001uF	10%	50V
C011		CERAMIC CHIP 0. 1uF	10% 25V	C127				5%	50V
C012	1-164-633-11	CERAMIC CHIP 0.1uF	10% 25V	C128		CERAMIC CHIP		5%	50V
C013		CERAMIC CHIP 0. 1uF	10% 25V	C129		CERAMIC CHIP		10%	50V
C014		CERAMIC CHIP 0. 1uF	10% 25V	C130		TANTAL. CHIP		20%	6. 3V
C018 C019		CERAMIC CHIP 0.01uF	50V	C131		CERAMIC CHIP		PW.	50V
C019			10% 25V	C132		CERAMIC CHIP		5% 20%	50V
0020	1 104-033-11	CERAMIC CHIP 0. 1uF	10% 25V	C133	1-135-149-21	TANTALUM CHIP	Z. ZUP	20%	10V
C021	1-162-974-11	CERAMIC CHIP 0.01uF	50V	C135	1-162-974-11	CERAMIC CHIP	0. 01uF		50V
C022		CERAMIC CHIP 0.01uF	50V	C136		CERAMIC CHIP			50V
C023		CERAMIC CHIP 0.01uF	50V	C137			0. 01uF		50V
C024	1-162-974-11	CERAMIC CHIP 0.01uF	50V	C150		CERAMIC CHIP			50V
C025	1-135-259-11	TANTAL. CHIP 10uF	20% 6. 3V	C151		CERAMIC CHIP			50V
				l					

Ref. No.	Part No.	Description			Remark	Ref. No.	Part No.	Description			Remark
C156	1-162-948-11	CERAMIC CHIP	39PF	5%	50V	C238	1-164-005-11	CERAMIC CHIP	0. 47uF		25V
C159			27PF	5%	50V	C239		CERAMIC CHIP	120PF	5%	50V
C161		CERAMIC CHIP		5%	50V	C240		CERAMIC CHIP	330PF	5%	50V
C167		CERAMIC CHIP			50V	C241	1-126-607-11	ELECT CHIP	47uF	20%	4V
C170		CERAMIC CHIP			25V	C242	1-162-960-11	CERAMIC CHIP	220PF	10%	50V
C171		•			16V	C245		CERAMIC CHIP			50V
C173					50V	C246		TANTALUM CHIP		20%	6. 3V
C175	1-128-004-11		10uF	20%	16V	C247		TANTAL, CHIP		20%	6. 3V
C176			0. 01uF		50V	C248		CERAMIC CHIP		E#/	50V
C177	1-162-974-11	CERAMIC CHIP	0. 01uF		50V	C249	1-102-959-11	CERAMIC CHIP	330PF	5%	50V
C178	1-164-145-11	CERAMIC CHIP	390PF	5%	50V	C250	1-164-145-11	CERAMIC CHIP	390PF	5%	50V
C179		CERAMIC CHIP	0. 01uF	2/4	50V	C254		CERAMIC CHIP		0,0	50V
C180		CERAMIC CHIP	33PF	5%	50V	C255		CERAMIC CHIP			50V
C181			0. 0015uF		50V	C256		CERAMIC CHIP			50V
C182		CERAMIC CHIP	270PF	5%	50V	C257		CERAMIC CHIP		5%	50V
C187		CERAMIC CHIP	15PF	5%	50V	C259		CERAMIC CHIP			50V
C188		CERAMIC CHIP	270PF	5%	50V	C260		CERAMIC CHIP	22PF	5%	50V
C189			470PF	5%	50V	C261		CERAMIC CHIP		F67	50V
C192		CERAMIC CHIP	270PF	5%	50V	C262		CERAMIC CHIP		5%	50V
C193	1-162-953-11	CERAMIC CHIP	100PF	5%	50V	C263	1-162-951-11	CERAMIC CHIP	68PF	5%	50V
C194	1_135_250_11	TANTAL. CHIP	10uE	20%	6. 3V	C264	1-162-950-11	CERAMIC CHIP	56PF	5%	50V
C199		TANTALUM CHIP		20%	107	C265		CERAMIC CHIP		5%	50V
C205		CERAMIC CHIP		5%	50V	C266		CERAMIC CHIP		5%	50V
C206		CERAMIC CHIP		0,0	16V	C267		CERAMIC CHIP		• • • • • • • • • • • • • • • • • • • •	50V
C207		CERAMIC CHIP		5%	50V	C268	1-162-955-11	CERAMIC CHIP	150PF	5%	50V
C208		CERAMIC CHIP	0. 0033uF	10%	50V	C269		CERAMIC CHIP	0. 1uF	ma/	16V
C209		TANTAL. CHIP	10uF	20%	6. 3V	C270		CERAMIC CHIP	33PF	5%	50V
C213		CERAMIC CHIP	0. 22uF		25V	C271	1-128-004-11		10uF	20%	16V
C214 C216		CERAMIC CHIP		20%	25V 16V	C272 C273	1-102-974-11	CERAMIC CHIP	0. 01uF 47uF	20%	50V 6. 3V
6210	1-128-004-11	ELECT CHIP	10uF	20%	104	(213	1-120-203-11	ELECT CHIP	41 UF	20%	U. 34
C217	1-135-181-21	TANTALUM CHIP	4. 7uF	20%	6. 3V	C278	1-162-638-11	CERAMIC CHIP	1uF		16V
C218		CERAMIC CHIP			50V	C279	1-162-974-11	CERAMIC CHIP	0. 01uF		50V
C219	1-135-259-11	TANTAL. CHIP	10uF	20%	6. 3V	C280	1-162-995-11	CERAMIC CHIP	0. 022uF		50V
C220	1-126-246-11		220uF	20%	4V	C281	1-135-146-21	TANTALUM CHIP	0. 68uF	20%	25V
C221	1-164-182-11	CERAMIC CHIP	0. 0033uF	10%	50V	C282	1-135-091-00	TANTALUM CHIP	1uF	20%	16V
0000	4 466 654 44	APPANIA ALLE	0.01 =		FOV	0000	1 105 004 04	TANTALINA OULO	15	201	161/
		CERAMIC CHIP		201/	50V			TANTALUM CHIP			16V
C223 C225	1-128-004-11	TANTAL. CHIP	10uF	20% 20%	16V 6. 3V	C284 C285		CERAMIC CHIP		20%	25V 6. 3V
C226		CERAMIC CHIP		20%	0. 3V 25V	C286		CERAMIC CHIP		20%	50V
C227		TANTAL. CHIP		20%	6. 3V	C288		CERAMIC CHIP			50V
	1 100 100 7				0.0.				• • • • • • • • • • • • • • • • • • • •		
C228	1-135-259-11	TANTAL. CHIP	10uF	20%	6. 3V	C289	1-164-360-11	CERAMIC CHIP	0. 1uF		16V
C229		TANTALUM CHIP		20%	6. 3V	C290		CERAMIC CHIP			50V
C230		TANTAL. CHIP		20%	6. 3V	C291		CERAMIC CHIP			50V
C231		CERAMIC CHIP			50V	C292		TANTALUM CHIP		20%	6. 3V
C232	1-135-180-21	TANTALUM CHIP	3. 3uF	20%	6. 3V	C294	1-162-638-11	CERAMIC CHIP	1uF		16V
C233	1-128-004-11	FIECT CHIP	10uF	20%	16V	C295	1-135-250-11	TANTAL. CHIP	10oF	20%	6. 3V
C234		CERAMIC CHIP		20/1	50V	C296		CERAMIC CHIP		20/8	50V
C235		CERAMIC CHIP			50V	C297		TANTAL. CHIP		20%	6. 3Y
C236		TANTAL. CHIP		20%	6. 3V	C298		CERAMIC CHIP		5%	50V
C237		TANTAL. CHIP		20%	6. 3V	C299		CERAMIC CHIP		5%	50V

Ref. No.	Part No.	Description			Remark	Ref. No.	Part No.	Description			Remark
C300	1162.052.11	CERAMIC CHIP	10000	FU	FOV	0.450	1 101 000 11				
C301		TANTAL. CHIP	100PF 10uF	5% 20%	50V 6. 3V	C450 C451		CERAMIC CHIP	0. 1uF		16V
C302		CERAMIC CHIP		20%	50V	C451		TANTAL. CHIP	0. 1uF 10uF	20%	25V
C303		TANTALUM CHIP	-	20%	10V	C453		CERAMIC CHIP	100PF	20% 5%	6. 3V 50V
C304		CERAMIC CHIP		20/6	50V	C454		CERAMIC CHIP	100PF	5%	50V 50V
		<b>42</b>			001	0101	1 102 321 11	CLIAMIC CITI	10011	J/I	5U <b>V</b>
C305	1-135-259-11	TANTAL. CHIP	10uF	20%	6. 3V	C455	1-162-969-11	CERAMIC CHIP	0. 0068uF	10%	25V
C306	1-162-974-11	CERAMIC CHIP	0. 01uF		50V	C456		CERAMIC CHIP	0. 1uF	10%	25V
C307		TANTALUM CHIP		20%	16V	C457		CERAMIC CHIP	0.0068uF	10%	25V
C401		CERAMIC CHIP			16V	C458	1-164-360-11	CERAMIC CHIP	0. 1uF	-	16V
C402	1-135-259-11	TANTAL. CHIP	10uF	20%	6. 3V	C459	1-162-964-11	CERAMIC CHIP	0. 001uF	10%	50V
0404	1 104 240 44	OFFINIA OUR	4.5		401						
C404 C406		CERAMIC CHIP	1uF		16V	C460		CERAMIC CHIP	0. 01uF		50V
C406		CERAMIC CHIP	0. 1uF		16V	C461		CERAMIC CHIP	0. 1uF	10%	25V
C407		TANTAL. CHIP	0. 022uF 10uF	20%	50V 6. 3V	C462 C463		CERAMIC CHIP	0. 001uF	10%	50V
C409		CERAMIC CHIP	0. 0022uF	10%	50V	C463		TANTAL CHIP		20%	16V
0.00	1 102 000 11	OLITARIO OIII	u. voltai	10/4	301	0404	1-135-160-21	TANTALUM CHIP	3. 3ur	20%	6. 3V
C412	1-163-037-11	CERAMIC CHIP	0. 022uF	10%	25V	C465	1-164-633-11	CERAMIC CHIP	0. 1uF	10%	25V
C413	1-162-970-11	CERAMIC CHIP	0. 01uF	10%	25V	C466		CERAMIC CHIP	0. 15uF	10%	25V
C414		CERAMIC CHIP	22PF	5%	50V	C467	1-162-970-11	CERAMIC CHIP	0. 01uF	10%	25V
C415	1-165-128-11	CERAMIC CHIP	0. 22uF		16V	C468	1-164-298-11	CERAMIC CHIP	0. 15uF	10%	25V
C416	1-162-916-11	CERAMIC CHIP	12PF	5%	50V	C469		CERAMIC CHIP	0. 0033uF	10%	50V
C417		CERAMIC CHIP	0. 1uF		16V	C470		CERAMIC CHIP	0.0033uF	10%	50V
C418		TANTAL. CHIP	10uF	20%	6. 3V	C471		CERAMIC CHIP	0. 01uF		50V
C420		CERAMIC CHIP	0. 022uF	0.007	50V	C472		TANTAL. CHIP	10uF	20%	6. 3V
C421 C422		TANTAL. CHIP	10uF	20%	6. 3V	C473		CERAMIC CHIP	0. 047uF	10%	16V
0422	1-135-255-11	TANTAL. CHIP	10uF	20%	6. 3V	C474	1-162-967-11	CERAMIC CHIP	0. 0033uF	10%	50V
C423	1-164-361-11	CERAMIC CHIP	0. 047uF		16V	C475	1-162-005-11	CERAMIC CHIP	0. 022uF		50V
C424			0. 022uF		50V	C476		TANTAL, CHIP	2. 2uF	20%	16V
C425			0. 022uF		50V	C477		CERAMIC CHIP	0. 01uF	20%	50V
C426			0. 022uF	10%	25V	C478		CERAMIC CHIP	33PF	5%	50V
C427	1-162-974-11	CERAMIC CHIP	0. 01uF		50V	C481			0. 1uF		16V
C428			0. 022uF		50V	C482		CERAMIC CHIP	0. 1uF		16V
C429			0. 001uF	10%	50V	C483		CERAMIC CHIP			25V
C430 C431			0. 1uF	109/	16V	C484	1-135-259-11				6. 3V
C431			0. 0015uF 0. 0039uF	10% 10%	50V 50V	C485	1-135-259-11				6. 3V
0432	1-104-175-11	CENAMIC CHIP	v. vvsaur	10%	50 V	C486	1-102-9/4-11	CERAMIC CHIP	0. 01uF		50V
C433	1-162-937-11	CERAMIC CHIP	6PF	0. 5PF	50V	C487	1-128-530-11	FLECT CHIP	33uF	20%	10V
C434		CERAMIC CHIP		5%	50V	0101	1 120 330 11	EEEGT OIII	Jour	20/8	104
C435	1-162-974-11	CERAMIC CHIP	0. 01uF		50V			( FILTER, CERA	MIC >		
C436	1-162-974-11	CERAMIC CHIP	0. 01uF		50V			(			
C437	1-162-995-11	CERAMIC CHIP	0. 022uF		50V	CF151	1-579-371-11	FILTER, CERAMI	C		
0.400	4 400 005 44										
C438		CERAMIC CHIP		A 050	50V			( CONNECTOR )			
C439 C440		CERAMIC CHIP		0. 25PI		OHOGO	4 500 500 5				
C440		CERAMIC CHIP		10%	50V			PIN, CONNECTOR			
C441		CERAMIC CHIP		10%	50V 50V	CNIUI	1-500-538-11	CONNECTOR, FPC	(NON ZIF)	6P	
077L	1 102 333 11	OLIMBIO OIII	v. vzzur		501	CNA01	1-500-789-21	PIN, CONNECTOR CONNECTOR, BOA	DO TO POAT	ח ממים	
C444	1-162-995-11	CERAMIC CHIP	0. 022uF		50V	CMAUS	1-573-310-11	CONNECTOR, BUA	BU TU BUYE	U 202	
_		TANTAL. CHIP		20%	6. 3V	014103	1 010 000 11	COMILCION, DUA	אטם טו שה	U 20F	
C446		CERAMIC CHIP			50V	CN404	1-695-325-11	CONNECTOR, BOA	RD TO ROAR	D 42P	
C447	1-162-974-11	CERAMIC CHIP	0. 01uF		507			CONNECTOR, BOA			
C449	1-164-360-11	CERAMIC CHIP	0. 1uF		16V			PIN, CONNECTOR		- 501	
					- 1			-	, i		

Ref. No.	Part No.	Description	Remark	Ref. No.	Part No.	Description	Remark
		( DIODE )		L008	1-410-658-3	1 INDUCTOR CHIP 220uH	
		( DIODE /		L009		1 INDUCTOR CHIP 8. 2uH	
D001	9_710_900_76	DIODE 1SS123				I INDUCTOR CHIP 120uH	
		DIODE MA142WK		L011	1-412-280-3		
D152		DIODE MA142WA		L012		1 INDUCTOR CHIP 33uH	
D152		DIODE MA142WK			1 410 007 1		
D160		DIODE MA142WK		L013	1-410-657-2	1 INDUCTOR CHIP 180uH	
D100	0-119-021 30	DIODE MAITZEN		L015		1 INDUCTOR CHIP 10uH	
D161	8-719-404-46	DIODE MATTO		L121		1 INDUCTOR CHIP 10uH	
		DIODE MA142WK		L150		1 INDUCTOR CHIP 18uH	
D163		DIODE MA142WK		L152		1 INDUCTOR CHIP 22uH	
	8-719-421-27				1 410 000 1		
D401				L154	1-410-390-1	1 INDUCTOR CHIP 56uH	
D402	6-119-021-50	DIODE MA142WK		L155		1 INDUCTOR CHIP 56uH	
D.400	0.740.404.40	DIODE MATIO		L160		1 INDUCTOR CHIP 10uH	
D403	8-719-404-46	DIODE MATTO		L161		1 INDUCTOR CHIP 22uH	
		/ FILTED \		L162	1-412-280-3		
		( FILTER )		L102			
FL121	1-236-188-11	FILTER, BAND PASS		L163		1 INDUCTOR CHIP 820uH	
FL152	1-236-849-21	FILTER, BAND PASS		L164		1 INDUCTOR CHIP 180uH	
FL153	1-236-186-11	FILTER, BAND PASS		L169		1 INDUCTOR CHIP 82uH	
FL154	1-239-055-21	FILTER, LOW PASS (CCD. PAL. Y)		L170		1 INDUCTOR CHIP 10uH	
		FILTER, LOW PASS		L171	1-410-384-3	1 INDUCTOR CHIP 18uH	
FI 401	1-406-452-11	COLL OSC		L175	1-410-393-1	1 INDUCTOR CHIP 100uH	
1 2 7 0 1	1 400 402 11	001E, 000		L176	1-410-656-1	1 INDUCTOR CHIP 150uH	
		( IC )		L177		1 INDUCTOR CHIP 10uH	
		( 10 /		L178		1 INDUCTOR CHIP 47uH	
10001	8-752-033-38	LIC CYA1202R		L179		1 INDUCTOR CHIP 6. 8uH	
	8-752-053-21						
IC121		IC CXA1203N		L180	1-410-393-1	1 INDUCTOR CHIP 100uH	
		IC CXA1207AR		L181		1 INDUCTOR CHIP 100uH	
	8-752-065-56			L182		1 INDUCTOR CHIP 120uH	
10132	0-732 003 30	) 10 UARI 20011		L185		1 INDUCTOR CHIP 10uH	
10154	8-752-333-24	LIC CYL1506M		L186		1 INDUCTOR CHIP 1uH	
	8-752-053-21						
IC156		2 IC M62353GP		L401	1-412-056-1	1 INDUCTOR CHIP 4. 7uH	
	8-759-055-82			L402		1 INDUCTOR CHIP 10uH	
	8-759-636-33			L403		1 INDUCTOR CHIP 47uH	
10133	0-755 050 50	) 10 OAA140216		L404		1 INDUCTOR CHIP 10uH	
10401	8-759-056-84	1 1C S-8420AF		L405		1 INDUCTOR CHIP 10uH	
		) IC CXP80624-428R				, ,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,	
		FC CAP60624-426N FC uPD75316GF-318-3B9		1406	1-412-058-1	1 INDUCTOR CHIP 10uH	
_		2 IC CXA1481AR		L407		1 INDUCTOR CHIP 1uH	
		B IC BR9011BF-RE2		L-401	1 412 002 2	THOUSE COME TO A	
10405	0-133-044-16	3 10 DU3011Dt UF7				(LINK, IC)	
10400	0_750_001_00	6 !C uPD6456GS-620				, =, /	
		3   C uPD7564G-540		A PSAN1	1-576-122-2	1 LINK, IC (CCP2E10 0.	4A)
	8-759-057-6					1 LINK, IC (CCP2E20 0.	
				451 5402	, 510 125-2	, 10 (0012220 0.	/
		2 IC TL1596CDB 2 IC MPC1720VM				( TRANSISTOR )	
10410	0-139-002-01	C 10 MT 01/204M				( instruction)	
		⟨ COIL ⟩		0001		2 TRANSISTOR 2SA1162	n
				0003		5 TRANSISTOR 2SB1218A-	
L001		I INDUCTOR CHIP 10uH		1		2 TRANSISTOR 2SD1819A-	К
L002		1 INDUCTOR CHIP 220uH		0010		5 TRANSISTOR UN5113	7. 0
L003		1 INDUCTOR CHIP 220uH		Q019	8-729-120-2	8 TRANSISTOR 2SC1623-1	_5L6
L005		1 INDUCTOR CHIP 22uH					
L007	1-412-058-1	1 INDUCTOR CHIP 10uH		Q020		8 TRANSISTOR 2SC1623-1	
				0021	8-729-905-2	3 TRANSISTOR 2SA1576-F	3

The components identified by mark  $\Lambda$  or dotted line with mark  $\Lambda$  are critical for safety.

Replace only with part number specified.

Ref. No.	Part No.	Description	1	Remark	Ref. No.	Part No.	Description			Ī	Remark
0022	8-729-402-55	TRANSISTOR	2SB1218A-R		0229	8-729-402-5	5 TRANSISTOR	2SR1218A-F			
Q024	8-729-102-07	TRANSISTOR	2SC2223-F13		Q230		2 TRANSISTOR				
Q025	8-729-014-16				0231		5 TRANSISTOR				
Q026	8-729-402-32	TRANSISTOR	2SD1819A-R		Q232	8-729-402-3	2 TRANSISTOR	2SD1810A-R	,		
Q121	8-729-403-35				0233		2 TRANSISTOR				
0123	8-729-402-42				0234		TRANSISTOR				
0124	8-729-403-35				0236		TRANSISTOR		1		
0125	8-729-117-73				0237		TRANSISTOR				
Q126	8-729-402-32	TRANSISTOR	2SD1819A-R		0401	8-729-402-40	B TRANSISTOR	IIN521F			
Q151	8-729-101-07				0403		TRANSISTOR				
Q152	8-729-402-32	TRANSISTOR	2SD1819A-R		0405		TRANSISTOR				
Q154	8-729-402-32				Q409		TRANSISTOR				
Q158	8-729-402-32										
Q160	8-729-403-35	TRANSISTOR	UN5113				< RESISTOR	>			
0161	8-729-402-32				R001	1-216-801-11	METAL CHIP	22	5%	1/16W	
0162	8-729-403-35				R002	1-216-818-11		560	5%	1/16W	
Q166	8-729-402-55				R004	1-216-815-11		330	5%	1/16W	
Q168	8-729-403-35				R005	1-216-817-11		470	5%	1/16W	
					R006	1-216-837-11		22K	5%	1/16W	
0170	8-729-420-20	TRANSISTOR	XN4312		11000	1 210 031 11	METAL CHIT	221	J/s	1/10#	
0171	8-729-117-73				R007	1-216-839-11	METAL CHID	33K	5%	1/16W	
0175	8-729-402-32				R012	1-216-835-11		15K	5%	1/16W	
0176	8-729-402-32				R013	1-216-841-11		47K	5%	1/16W	
0177	8-729-402-55				R016	1-216-837-11		22K	5%	1/16W	*
					R017	1-216-837-11		22K	5%	1/16W	
Q178	8-729-402-55	TRANSISTOR	2SB1218A-R		*****	1 210 001 11	WEINE OITH	221	5/1	1/10#	
0180	8-729-422-54				R020	1-216-823-11	METAL CHIP	1. 5K	5%	1/16W	
Q182	8-729-402-32				R021	1-216-836-11	METAL CHIP	18K	5%	1/16W	
Q183	8-729-420-53				R022	1-216-840-11		39K	5%	1/16W	
0184	8-729-402-32	TRANSISTOR	2SD1819A-R		R023	1-216-838-11		27K	5%	1/16W	
					R024	1-216-838-11		27K	5%	1/16W	
0189	8-729-402-32	TRANSISTOR	2SD1819A-R						0/4	17 10"	
Q191	8-729-402-32	TRANSISTOR	2SD1819A-R		R025	1-216-823-11	METAL CHIP	1. 5K	5%	1/16W	
0192	8-729-402-32	TRANSISTOR	2SD1819A-R		R026	1-216-832-11		8. 2K		1/16W	
Q194	8-729-402-32	TRANSISTOR	2SD1819A-R		R027	1-216-841-11		47K	5%	1/16W	
Q195	8-729-402-55	TRANSISTOR	2SB1218A-R		R028	1-216-837-11		22K	5%	1/16W	
					R029	1-216-824-11		1. 8K		1/16W	
0196	8-729-403-35										
0199	8-729-807-87	TRANSISTOR	2SB1295-UL6		R030	1-216-837-11	METAL CHIP	22K	5%	1/16W	
	8-729-013-88				R031	1-216-829-11	METAL CHIP	4. 7K	5%	1/16W	
0203	8-729-402-55				R033	1-216-791-11		3. 3	5%	1/16₩	
<b>Q204</b>	8-729-402-32	TRANSISTOR	2SD1819A-R		R049	1-216-824-11	METAL CHIP	1. 8K	5%	1/16W	
0005	0.700.400.40	TD 4410 LOTOD	11117040		R050	1-216-832-11	METAL CHIP	8. 2K	5%	1/16W	
Q205	8-729-402-42					4 444 45		_			
0207	8-729-403-35				R051	1-216-831-11			5%	1/16W	
0208	8-729-013-88				R052	1-216-823-11		1. 5K		1/16W	
0210	8-729-402-42				R054	1-216-817-11		470	5%	1/16W	
Q212	8-729-402-55	IMANSISTUR	Z981Z18A-K		R055	1-216-820-11		820	5%	1/16W	
0214	8-729-420-12	TRANSISTOR	YNA212		R056	1-216-864-11	METAL CHIP	0	5%	1/16W	
0217	8-729-420-12				DUCA	1 010 010 11	WETAL COLO	***	E0/	4 /4	
0219	8-729-402-42				R057	1-216-818-11			5%	1/16W	
0219	8-729-403-33			ļ	R058	1-216-818-11			5%	1/16W	
0221	8-729-402-42				R060	1-216-830-11		5. 6K		1/16W	
4221	0 123 420-12	MUICICHAM	AIITE ( )	1	R061	1-216-821-11			5%	1/16W	
0222	8-729-402-32	TRANSISTOR	25D1810A_P		R062	1-216-818-11	METAL CHIP	560	5%	1/16W	
Q223	8-729-402-32				R063	1_216_020_14	METAL CHIE	E 01/	EW	1 /4 000	
4550	0 123 402 42	HUISISIUN	UNULIU		NU03	1-216-830-11	METAL CHIP	5. 6K	ጋሕ	1/16W	

Ref. No.	Part No.	Descripti	<u>on</u>		Remark	Ref. No.	Part No.	Descrip	otion			Re	mark
R064	a1-216-817-11	METAL CHI	P 470	5%	1/16W	R158	1-216-829-1	1 METAL	CHIP	4. 7K	5%	1/16W	
R065	1-216-829-11				1/16W	R160	1-216-819-1			680	5%	1/16W	
R066	1-216-809-11			5%	1/16W	R161	1-216-809-1			100	5%	1/16W	
R067	1-216-836-11			5%	1/16W	R164	1-216-811-1			150	5%	1/16W	
11001	1 210 030 11	MEINE OIL	1010	270	1, 10"	""	. 2.0 0		•			,	
R070	1-216-834-11	METAL CH	P 12K	5%	1/16W	R167	1-216-820-1	1 METAL	CHIP	820	5%	1/16W	
R071	1-216-823-11				1/16W	R168	1-216-820-1	1 METAL	CHIP	820	5%	1/16W	
R072	1-216-826-11				1/16W	R170	1-216-822-1			1. 2K	5%	1/16W	
R076	1-216-824-11				1/16W	R175	1-216-810-1	1 METAL	CHIP	120	5%	1/16W	
R078	1-216-831-11				1/16W	R177	1-216-819-1	1 METAL	CHIP	680	5%	1/16W	
,,,,,,	,, =,,,												
R079	1-216-833-11	METAL CH	IP 10K	5%	1/16W	R178	1-216-817-1			470	5%	1/16W	
R081	1-216-830-11	METAL CH	IP 5. 6K	5%	1/16W	R179	1-216-820-1	1 METAL	CHIP	820	5%	1/16W	
R082	1-216-804-11	METAL CH	IP 39	5%	1/16W	R189	1-216-828-1	1 METAL	CHIP	3. 9K	5%	1/16W	
R083	1-216-821-11	METAL CH	IP 1K	5%	1/16W	R190	1-216-837-1			22K	5%	1/16W	
R085	1-216-821-11	METAL CH	IP 1K	5%	1/16W	R191	1-216-864-1	1 METAL	CHIP	0	5%	1/16W	
												4 /4 000	
R086	1-216-817-11			5%	1/16W	R192	1-216-833-1			10K	5%	1/16W	
R087	1-216-824-11				1/16W	R193	1-216-841-1			47K	5%	1/16W	
R088	1-216-808-11			5%	1/16W	R194	1-216-833-1			10K	5%	1/16W	
R090	1-216-836-11			5%	1/16W	R196	1-216-815-1			330	5%	1/16W	
R097	1-216-821-11	I METAL CH	IP 1K	5%	1/16W	R198	1-216-817-1	II MEIAL	CHIP	470	5%	1/16₩	
R122	1-216-833-11	METAL CH	IP 10K	5%	1/16W	R200	1-216-821-1	1 METAL	CHIP	1K	5%	1/16W	
R123	1-216-845-11				1/16W	R201	1-216-815-1			330	5%	1/16W	
R124	1-216-845-11				1/16W	R202	1-216-840-1			39K	5%	1/16W	
R125	1-216-845-11				1/16W	R203	1-216-837-1			22K	5%	1/16W	
R126	1-216-845-1				1/16W	R204	1-216-821-1			1K	5%	1/16W	
11120	,1 210 043 1	1 ME 1715 OIT	., .,	0/4	,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,				•			.,	
R127	1-216-825-1	1 METAL CH	IP 2. 2K	5%	1/16W	R205	1-216-824-1	11 METAL	CHIP	1. 8K	5%	1/16W	
R129	1-216-845-1	1 METAL CH	IP 100K	5%	1/16W	R206	1-216-813-1	11 METAL	CHIP	220	5%	1/16W	
R130	1-216-833-1	1 METAL CH	IP 10K	5%	1/16W	R208	1-216-864-1	11 METAL	CHIP	0	5%	1/16W	
R131	1-216-841-1	1 METAL CH	IP 47K	5%	1/16W	R211	1-216-825-1	II METAL	CHIP	2. 2K	5%	1/16W	
R132	1-216-833-1	1 METAL CH	IP 10K	5%	1/16W	R213	1-216-835-1	11 METAL	CHIP	15K	5%	1/16W	
D122	1-216-827-1	1 METAL CH	IP 3. 3K	5%	1/16W	R216	1-216-837-1	11 METAL	CHIP	22K	5%	1/16W	
R133	1-216-833-1			5%	1/16W	R217	1-216-837-1			22K	5%	1/16₩	
R134 R135	1-216-832-1				1/16W	R218	1-216-824-1			1. 8K	5%	1/16W	
R136	1-216-825-1				1/16W	R219				1K	5%	1/16W	
R137	1-216-821-1			5%	1/16W	R220	1-216-811-			150	5%	1/16W	
11107	7 210 021 1	I MEINE OF		3/1	171011	,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,			••••			.,	
R138	1-216-839-1	1 METAL CH		5%	1/16W	R221	1-216-864-			0	5%	1/16W	
R139	1-216-817-1	1 METAL CH	IIP 470	5%	1/16W	R222	1-216-831-	11 METAL	CHIP	6. 8K	5X	1/16W	
R140	1-216-833-1	1 METAL CH	HP 10K	5%	1/16W	R223				15K	5%	1/16W	
R141	1-216-821-1	1 METAL CH		5%	1/16W	R224				2. 2K		1/16W	
R142	1-216-825-1	1 METAL CH	IIP 2. 2K	5%	1/16W	R226	1-216-819-	11 METAL	CHIP	680	5%	1/16W	
R143	1-216-839-1	1 METAL OL	HP 33K	5%	1/16W	R228	1-216-813-	11 METAL	CHIP	220	5%	1/16W	
				5%	1/16W	R230				68	5%	1/16W	
R144	1-216-817-1			5%	1/16W	R231	1-216-821-			1K	5% 5%	1/16W	
R145	1-216-837-1			5%	1/16W	R231				10K	5%	1/16W	
R146 R150	1-216-821-1			5% 5%	1/16W	R232				1K	5%	1/16W	
NIOU	1-216-864-1	I MEIAL U	HIF V	3/0	1/10#	N230	1 210-021	II MEINE	UIIII	111	V/I	1/10#	
R151	1-216-296-0	O METAL CH	IIP 0	5%	1/8W	R242	1-216-818-	11 METAL	CHIP	560	5%	1/16W	
R152	1-216-830-1	1 METAL CH	HP 5. 6K	5%	1/16W	R243	1-216-809-	11 METAL	CHIP	100	5%	1/16W	
R153	1-216-304-1	1 METAL CH	IIP 3. 3	5%	1/10W	R244				15K	5%	1/16W	
R154	1-216-820-1	1 METAL CH	HP 820	5%	1/16W	R245				470	5%	1/16W	
R155	1-216-836-1	1 METAL CH	HP 18K	5%	1/16W	R246	1-216-817-	11 METAL	CHIP	470	5%	1/16W	
R156	1-216-296-0	0 METAL C	IP 0	5%	1/8W	R247	1-216-296-	00 METAL	CHIP	0	5%	1/8W	

Ref. No.	Part No.	Description			Remark	Ref. No.	Part No.	Description			Re	emark
D0.40			0.04	***	4.44.694						_	
R248	1-216-825-11		2. 2K		1/16W	R316		1 METAL CHIP	470	5%	1/16W	
R250	1-216-810-11		120	5%	1/16W	R318		1 METAL CHIP	10K	5%	1/16W	
R251	1-216-806-11		56	5%	1/16W	R320		1 METAL CHIP	2. 2K		1/16W	
R253	1-216-821-11	METAL CHIP	1K	5%	1/16W	R321	1-216-816-1	METAL CHIP	390	5%	1/16W	
R254	1-216-818-11	METAL CHIP	560	5%	1/16W	R323	1-216-825-1	1 METAL CHIP	2. 2K	5%	1/16W	
R255	1-216-833-11	METAL CHIP	10K	5%	1/16W	R324	1-216-817-11	METAL CHIP	470	5%	1/16W	
R256	1-216-864-11	METAL CHIP	0	5X	1/16W	R329		METAL CHIP	1. 8K		1/16W	
R257	1-216-818-11		560	5X	1/16W	R331		METAL CHIP	1. 8K		1/16W	
R258	1-216-821-11		1K	5%	1/16W	R333		METAL CHIP	1. 2K		1/16W	
R259	1-216-816-11	METAL CHIP	390	5%	1/16W	R334	1-216-833-11	METAL CHIP	10K	5%	1/16W	
R260	1-216-825-11		2. 2K		1/16W	R335	1-216-821-11		1K	5%	1/16W	
R263	1-216-864-11		0	5X	1/16W	R337	1-216-864-11		0	5%		
R266	1-216-864-11		Ŏ	5%	1/16W	R339	1-216-825-11		-		1/16W	
R267	1-216-864-11		ŏ	5%	1/16W	R341			2. 2K		1/16W	
11207	1 210 004 11	MEINE OIII	v	3/6	1/10#	n341	1-210-041-11	METAL CHIP	47K	5%	1/16W	
R270	1-216-864-11		0	5%	1/16W	R342	1-216-829-11		4. 7K		1/16W	
R271	1-216-841-11		47K	5%	1/16W	R343	1-216-839-11		33K	5%	1/16W	
R272	1-216-829-11		4. 7K		1/16W	R344	1-216-825-11		2. 2K		1/16W	
R276	1-216-822-11		1. 2K		1/16W	R345	1-216-827-11		3. 3K		1/16W	
R277	1-216-823-11	METAL CHIP	1. 5K	5%	1/16W	R346	1-216-845-11	METAL CHIP	100K	5%	1/16W	
R278	1-216-825-11	METAL CHIP	2. 2K	5%	1/16W	R347	1-216-823-11	METAL CHIP	1. 5K	5%	1/16W	
R279	1-216-818-11		560	5%	1/16W	R349	1-216-834-11		1. JK	5%	1/16W	
R280	1-216-827-11		3. 3K		1/16W	R350	1-216-838-11		27K	5%	1/16W	
R281	1-216-823-11		1. 5K		1/16W	R352	1-216-864-11		0	5%		
R282	1-216-829-11		4. 7K	5%	1/16W	R353	1-216-864-11		-		1/16W	
	7 210 020 71	METAL VIIII	4. IK	3/4	1710#	11000	1-210-004-11	MCIAL GHIP	0	5%	1/16₩	
R283	1-216-821-11		1K	5%	1/16W	R357	1-216-830-11	METAL CHIP	5. 6K	5%	1/16W	
R285	1-216-833-11	METAL CHIP	10K	5%	1/16W	R358	1-216-828-11	METAL CHIP	3. 9K	5%	1/16W	
R286	1-216-833-11	METAL CHIP	10K	5X	1/16W	R359	1-216-296-00	METAL CHIP	0	5%	1/8W	
R290	1-216-821-11	METAL CHIP	1K	5%	1/16W	R360	1-216-296-00	METAL CHIP	0	5%	1/8W	
R291	1-216-820-11	METAL CHIP	820	5%	1/16W	R361	1-216-864-11		0	5%	1/16W	
R293	1-216-807-11	METAL CHIP	68	5%	1/16W	R362	1-216-810-11	METAL CHIP	120	5%	1/16W	
R294	1-216-845-11	METAL CHIP	100K		1/16W	R366	1-216-844-11		82K	5%	1/16W	
R295	1-216-853-11	METAL CHIP	470K	5%	1/16W	R371	1-216-857-11		1M	5%	1/16W	
R297	1-216-820-11	METAL CHIP	820	5%	1/16W	R373	1-216-817-11	METAL CHIP	470	5%	1/16W	
R298	1-216-820-11	METAL CHIP	820	5%	1/16W	R374	1-216-826-11		2. 7K		1/16W	
R299	1-216-829-11	METAL CHIP	4. 7K	5%	1/16W	R375	1-216-825-11	METAL CHIP	2. 2K	54	1/16W	
	1-216-822-11		1. 2K		1/16W		1-216-817-11	METAL CHIP	470	5%	1/16W	
R301	1-216-827-11	METAL CHIP	3. 3K		1/16W	R377	1-216-821-11	METAL CHIP	1K	5%	1/16W	
R302	1-216-827-11		3. 3K		1/16W	R378	1-216-825-11		2. 2K		1/16W	
R303	1-216-846-11		120K		1/16W	R379	1-216-821-11		1K	5%	1/16W	
R304	1-216-829-11	METAL CHID	4. 7K	54	1/16W	0200			224	EN		
R305	1-216-818-11		560	5%	1/16W	R380 R381	1-216-839-11		33K	5%	1/16W	
R306	1-216-821-11						1-216-839-11		33K	5%	1/16W	
R307	1-216-821-11		1K	5% Ew	1/16W	R382	1-216-842-11		56K	5%	1/16W	
			1K	5%	1/16W	R383	1-216-821-11		1K	5%	1/16W	
R308	1-216-819-11	METAL UNIP	680	5%	1/16W	R384	1-216-825-11	METAL CHIP	2. 2K	5%	1/16W	
R309	1-216-826-11	METAL CHIP	2. 7K	5%	1/16W	R385	1-216-825-11	METAL CHIP	2. 2K	5%	1/16W	
R310	1-216-848-11	METAL CHIP	180K		1/16W	R386	1-216-842-11		56K	5%	1/16W	
R311	1-216-829-11		4. 7K		1/16W	R387	1-216-821-11		1K	5%	1/16W	
R312	1-216-829-11		4. 7K		1/16W	R388	1-216-825-11		2. 2K		1/16W	
R314	1-216-829-11		4. 7K		1/16W	R389	1-216-821-11		1K	5%	1/16W	
R315	1-216-833-11	METAL CHIP	10K	5%	1/16W	R390	1-216-825-11	METAL CHIP	2. 2K	5%	1/16W	4

Ref. No.	Part No.	Description			Remark	Ref. No.	Part No.	Description			Remark
D004	1 040 005 44	METAL ALLE	0.01/	F47	4 /4 000	Dara	1 010 041 4	4 METAL ALLID	471/	<b>-</b> N/	4 /4 000
R391	1-216-825-11		2. 2K		1/16W	R451		1 METAL CHIP	47K	5% E%	1/16W
R392	1-216-837-11		22K	5%	1/16W 1/16W	R452		1 METAL CHIP 1 METAL CHIP	10K	5%	1/16W
R393	1-216-833-11		10K	5%		R453			47K	5%	1/16W
R394	1-216-841-11	METAL CHIP	47K	5%	1/16W	R454	1-216-825-1	1 METAL CHIP	2. 2K	5%	1/16W
R397	1-216-820-11	METAL CHIP	820	5%	1/16W	R456	1-216-833-1	1 METAL CHIP	10K	5%	1/16W
R398	1-216-829-11	METAL CHIP	4. 7K	5%	1/16W	R457	1-216-837-1	1 METAL CHIP	22K	5%	1/16W
R401	1-216-827-11	METAL CHIP			1/16W	R460		1 METAL CHIP	0	5%	1/16W
R403	1-216-845-11		100K		1/16W	R461		1 METAL CHIP	100K	5%	1/16W
R404	1-216-826-11	METAL CHIP	2. 7K	5%	1/16W	R462	1-216-809-1	1 METAL CHIP	100	5%	1/16W
R405	1-216-821-11	METAL CHIP	1K	5%	1/16W	R463	1-216-827-1	1 METAL CHIP	3. 3K	5%	1/16W
R407	1-216-821-11		1K	5%	1/16W	R468	1-216-039-0	O METAL CHIP	390	5%	1/10W
R408	1-216-833-11	METAL CHIP	10K	5%	1/16W	R469	1-216-838-1	1 METAL CHIP	27K	5%	1/16W
R409	1-216-841-11	METAL CHIP	47K	5%	1/16W	R470	1-216-838-1	1 METAL CHIP	27K	5%	1/16W
R410	1-216-821-11	METAL CHIP	1K	5%	1/16W	R471	1-216-838-1	1 METAL CHIP	27K	5%	1/16W
R411	1-216-821-11	METAL CHIP	1K	5%	1/16W	R472	1-216-833-1	1 METAL CHIP	10K	5%	1/16W
R412	1-216-821-11		47K	5%	1/16W	R473		1 METAL CHIP	10K	5%	1/16W
R413	1-216-821-11		1K	5%	1/16W	R474		1 METAL CHIP	1	5%	1/10W
R414	1-216-821-11		1K	5%	1/16W	R475		1 METAL CHIP	1	5%	1/10W
R415	1-216-821-11		1K	5%	1/16W	R476		1 METAL CHIP	2. 7K	5%	1/16W
			414	Fe/		D.470		4 METAL OULD	1001		
R416	1-216-821-11		1K	5%	1/16W	R479		1 METAL CHIP		5%	1/16₩
R417	1-216-833-11		10K	5%	1/16W	R480		1 METAL CHIP	1	5%	1/10W
R418	1-216-829-11		4. 7K		1/16W	R481		1 METAL CHIP	1	5%	1/10W
	1-216-845-11		100K		1/16W	R484		1 METAL CHIP		5X	1/16W
R420	1-216-856-11	METAL CHIP	820K	5%	1/16W	R485	1-210-045-1	1 METAL CHIP	100K	5%	1/16W
R421	1-216-851-11	METAL CHIP	330K		1/16W	R487	1-216-864-1	1 METAL CHIP	0	5%	1/16W
R422	1-216-829-11	METAL CHIP	4. 7K	5%	1/16W	R489	1-216-831-1	1 METAL CHIP	6. 8K	5%	1/16W
R423	1-216-837-11		22K		1/16W	R490		1 METAL CHIP	10K	5%	1/16W
R424	1-216-845-11		100K		1/16W	R491		O METAL CHIP	0	5%	1/8W
R425	1-216-849-11	METAL CHIP	220K	5%	1/16W	R492	1-216-864-1	1 METAL CHIP	0	5%	1/16W
R426	1-216-856-11	METAL CHIP	820K	5%	1/16W	R493	1-216-864-1	1 METAL CHIP	0	5%	1/16W
R427	1-216-833-11	METAL CHIP	10K	5%	1/16W						
R428	1-216-833-11	METAL CHIP	10K	5%	1/16W			( THERMISTOR )	<b>)</b>		
R429	1-216-821-11	METAL CHIP	1K	5%	1/16W						
R430	1-216-851-11	METAL CHIP	330K	5%	1/16W	R073 R113		1 THERMISTOR, N 1 THERMISTOR, N			
R431	1-216-841-11	METAL CHIP	47K	5%	1/16W	"""	1 000-000-2	i illimiolon, N	(£120)	500	
R432	1-216-833-11		10K	5%	1/16W			( NETWORK, RES	\$ >		
R433		METAL CHIP	1K	5%	1/16W			, mernomy nec	,		
R435		METAL CHIP	1K	5%	1/16W	RB401	1-236-442-1	1 NETWORK, RES 3	330K		
R436		METAL CHIP	0	5%	1/16W			1 NETWORK, RES		PE) 100	)K
			-					1 NETWORK, RES	•	-	
R437	1-216-817-11	METAL CHIP	470	5%	1/16W			1 NETWORK, RES			
R438	1-216-841-11		47K	5%	1/16W			1 NETWORK, RES 1		.,	
R439		METAL CHIP	0	5%	1/16W						
R441	1-216-864-11		Ö	5%	1/16W	RB406	1-236-908-1	1 NETWORK, RES	CHIP TYP	PE) 10k	(
R442		METAL CHIP	Ö	5%	1/16W			1 NETWORK, RES	• -		
			4000			RB408	1-236-908-1	1 NETWORK, RES	(CHIP TYP	PE) 10k	(
R443		METAL CHIP	100K		1/16W			1 NETWORK, RES		'E) 1. (	JK
R445	1-216-837-11		22K	5%	1/16W	RB410	1-236-412-1	1 NETWORK, RES 1	1. OK		
R447	1-216-864-11		0	5%	1/16W		4 000	4 11570000 555	AV		
R448		METAL CHIP	100	5%	1/16W	•		1 NETWORK, RES 1		\F\	
R449	1-216-845-11	METAL CHIP	100K	5%	1/16W			1 NETWORK, RES ( 1 NETWORK, RES 1		't) 1.(	)K
R450	1-216-833-11	METAL CHIP	10K	5%	1/16W	ł.		1 NETWORK, RES			

Ref. No.	Part No.	Description	Remark	Ref. No.	Part No.	Description	Remark
		NETWORK, RES 1. 0K		*****	******	************	*****
RB420 RB421 RB422 RB423	1-236-904-11 1-236-908-11 1-236-424-11 1-236-424-11	NETWORK, RES (CHIP TYPE) 1. 0K NETWORK, RES (CHIP TYPE) 10K NETWORK, RES 10K NETWORK, RES 10K NETWORK, RES 10K			ACCESSOR! ********* A-6768-254- A-6767-707-	ES & PACKING MATERIALS ************************************	
		NETWORK, RES 10K NETWORK, RES 1.0K			A-6768-255-	A RFU ADAPTOR (RFU-89EA) (E) A RFU ADAPTOR (RFU-90AS) (Austrai 1 REMOTE COMMANDER (CAM CORDER) (I	
		<pre>〈 VARIABLE RESISTOR 〉</pre>				1 SWITCH, ANTENNA CHANGE (CABLE) 1 SCREWDRIVER (UK, E)	(UK, E)
RV151	1-238-087-11	RES, ADJ, CERMET 1K  ( FLEXIBLE BOARD )		*	3-738-517-0 3-754-318-0	1 BELT (S), SHOULDER 1 INSTRUCTION 1 MANUAL, INSTRUCTION (ENGLISH) (A	AEP. UK)
		FP-588 FLEXIBLE BOARD FP-572 FLEXIBLE BOARD				1 MANUAL, INSTRUCTION (FRENCH, GERMAN, SPANIS	
		( CRYSTAL )				1 MANUAL, INSTRUCTION (DUTCH, SWEDISH, ITALI) 1 MANUAL, INSTRUCTION (ENGLISH)	AN) (AEP)
X401	1-579-063-21	VIBRATOR, CRYSTAL (4. 43MHz) VIBRATOR, CERAMIC (4. 19MHz)			3-755-774-7	1 MANUAL, INSTRUCTION	stralian)
X403	1-579-368-31	VIBRATOR, CRYSTAL (32kHz) VIBRATOR, CRYSTAL (11. 719MHz) VIBRATOR, CERAMIC (700kHz)			3-755-774-8	(FRENCH, GERMAN, SPAI 1 MANUAL, INSTRUCTION (ARABIC) (E)	
		***************************************	*****		3-755-493-7	1 MANUAL, INSTRUCTION (CHINESE) (E 1 MANUAL, INSTRUCTION (PORTUGUESE) 1 MANUAL, INSTRUCTION	
		MISCELLANEOUS ************************************			3-756-122-1	(DANISH, FINNIS 1 INSTRUCTION (CARRYING CASE) (TR: 1 BELT, SHOULDER	
14 18 80 106 108	A-7091-800-A 1-692-257-11 1-547-558-21 1-547-548-11	CABLE, FLAT (FFC-90) MICROPHONE UNIT SWITCH, PUSH (ZOOM) FILTER BLOCK, OPTICAL LENS, ZOOM (VCL-6210WC)		* * * *	3-949-004-0 3-949-005-0 3-949-006-1	1 HOLDER (B), REMOTE CONTROL 1 CUSHION, ACC (TR303E) 1 CUSHION (LOWER) (TR303E) 1 INDIVIDUAL CARTON (TR303E) 1 CASE, CARRYING, SOFT (TR303EP)	
	A-7030-369-A	LENS, ZOOM (VCL-6210WC) CCD BLOCK ASSY (AUTO) (ICX055AK-2) (CCD I HOLDER, BATTERY DRUM ASSY (DGH-90A-R)	MAGER)	* * * *	3-950-792-0 3-950-793-0	1 CUSHION (FRONT), INNER (TR303EP) 1 CUSHION (REAR), INNER (TR303EP) 1 SPACER (TR303EP) 1 PLATE, INNER (TR303EP)	1
M902		MOTOR, DC SCE-0101A (CAPSTAN)		*	3-950-795-1	1 INDIVIDUAL CARTON (TR303EP)	
M903 M904 M905 M906	3-708-494-01 3-708-491-01	MOTOR BLOCK ASSY, LM (LOADING) METER ASSY, IG (IRIS) MOTOR ASSY, STEPPING (FOCUS) MOTOR ASSY, PZ (ZOOM)		* *		1 BELT, CARRYING (TR303EP) 1 CASE (LOWER) CARRYING, SOFT (TR3 AC POWER ADAPTOR	303EP)
		LINK, IC 1. 6A/90V		*** Note	NP-55	BATTERY PACK	
⚠PS902 S001 S002	1-572-986-11	LINK, IC 1.6A/90V SWITCH, ROTARY (ENCODER) SWITCH, PUSH (3 KEY)		***		IS AVAILABLE FOR REPAIR SERVICE. IS AVAILABLE AS AN OPTIONAL ACCESS	ORY.
S005 V901	1-570-771-21 1-452-565-11	SWITCH (C DOWN) CRT ASSY		******	*********	****************************	******
1 W501 W517 W519 W971 W991	1-696-482-11 1-696-488-11 1-696-484-11	SOCKET ASSY, CRT CABLE, FLAT (FFC-85) CABLE, FLAT (FFC-92) CABLE, FLAT (FFC-87) CABLE, FLAT (FFC-86)		#1	7-627-853-5	HARDWARE LIST ************* 7 PRECISION SCREW +2X5	
пээі	1 030-403-11	VNDEE, LENI (FFG-00)		l			<b>-</b>

The components identified by mark 
⚠ or dotted line with mark ⚠ are critical for safety.

Replace only with part number specified.

# SECTION 7 CAMERA SECTION ADJUSTMENTS

When performing adjustments, refer to the layout diagrams for adjustment related parts beginning from page 198.

## 7-1. PREPARATIONS BEFORE ADJUSTMENT (CAMERA SECTION)

#### 7-1-1. List of Service Tools

- Oscilloscope
- Stabilized power supply
- Vectorscope

- · Adjusting driver
- Color monitor
- Digital voltmeter

Ref. No.	Name	Part Code	Usage
J-1	Filter for color temperature correction (C14)	J-6080-058-A	Auto white balance adjustment/check White balance adjustment/check
	ND filter 1.0	J-6080-808-A	Max gain adjustment (2 used) White balance check
J-2	ND filter 0.4	J-6080-806-A	Max gain adjustment
	ND filter 0.3	J-6080-818-A	White balance adjustment
	ND filter 0.1	J-6080-807-A	Max gain adjustment
J-3	Pattern box PTB-500	J-6029-140-A	
J-4	Color chart for pattern box	J-6020-250-A	
J-5	Adjusting remote control unit (RM-95-remodeled in part) <sup>Note 1</sup>	J-6082-053-B	
J-6	Extension cord (10P, 1 mm)	J-6082-064-A	For extension of JK-91 board
	Extension cord (20P, 0.8 mm)	J-6082-196-A	For extension of CN-65 board (Cabinet (R)) (For the video and the camera section adjustment)
J-7			For extension of AU-138 board (During the repair of AU-138 board)
J-8	Extension cord (16P, 0.8 mm)	J-6082-136-A	For the extension of the lens block (During the repair of the camera section)
J-9	Relay board (21P, 0.5 mm) <sup>Note 2</sup>	J-6082-176-A	For the extension of the lens block (During the repair of the camera section)
J-10	Measuring pin for camera section	J-6082-139-A	For the camera section adjustment
J-11	Extension cord (42P, 0.8 mm)	J-6082-195-A	For the extension of DD-48 board (During the repair of the video section)
J-12	Siemens star	J-6080-875-A	For flange back check
J-13	Extension cord (20P, 0.5 mm) <sup>Note 2</sup>	J-6082-138-A	For extension between the lens block (FPC) and VC-122 board (CN851) (During the repair of the camera section)
J-14	Extension board (30P, 0.8 mm)	J-6082-167-A	For the extension of VS-95 board (For the mecha deck check)

Note 1: If the micro processor IC in the adjusting remote control unit is not the new micro processor (UPD7503G-C56-12), the switchover of the page cannot be carried out. In this case, replace with the new micro processor (8-759-148-35).

Note 2: The extension code (J-6082-138-A) is also attached with a 21P, 0.5 mm code. Connect this code to the relay board (J-6082-176-A) for extensions between the lens block (FPC) and VC-122 board (CN851).




Fig. 7-1.

#### 7-1-2. Preparations

**Note:** For further details on how to remove the cabinet and each board, refer to "1. Disassembly".

- 1) Connect the equipments for adjustment as shown in Fig. 7-3.
- The EVF (Electronic viewfinder) is required for checking the white balance mode and shutter speeds. If the EVF is not required, remove the VS-95 board CN102.




Fig. 7-2.




Fig. 7-3.

#### 7-1-3. Precautions

#### 1. Switch settings

Adjust the switches to the following positions, and perform the adjustments without inserting the tape, unless specified otherwise.

- 1. Camera/player power switch (VK-27 board S977)····Camera
- 2. Standby switch (SW-205 board S519) ····· Standby
- 3. LENS OPEN switch (MF-191 board S973) ····· OPEN
- 4. FOCUS button (MF-191 board S971) ······MANUAL
- 5. PROGRAM AE selector (CF-32 board S997) ····· NORMAL

#### 2. Adjustment Procedure

Perform in the given order as a rule.

#### 3. Subject

- Color bar chart (Standard picture frame)
   Adjust the display frame as shown in Fig. 7-4. if adjustments are performed using the color bar chart.
   (Standard picture frame)
- White pattern (Standard picture frame) Remove the color bar chart from the pattern box, and adjust the zoom lever so that the white pattern becomes the same size and is in the same position as the color bar chart (Standard picture frame).





Fig. 7-4.

3) Chart for flange back adjustment Combine a white A0 size (1189 mm× 841 mm) paper to a black one, and make the chart shown in Fig. 7-5.



**Note:** Use the non-reflecting and non-glazing vellum paper whose size is more than A0, and make the boundary between white and black to be smoothly flat.

#### 7-1-4. Adjusting Remote Control Unit

The camera section is adjusted by changing the constant using the coefficient of the digital signal processing calculation, or modifying the output voltage of EVR IC (VC-122 board IC702). These processes are carried out by the camera micro processor (VC-122 board IC709). This micro processor reads the data written in the non-volatile memory (VC-122 board IC712), and transmits it to the digital signal processing circuit and EVR.

The adjusting remote control unit is used for rewriting the adjustment data written in the non-volatile memory necessary for performing the adjustments.

The adjusting remote control unit uses the remote control signal line (LANC) to correspond mutually with the camera micro processor. The page, address and the up/down command of the data can be transmitted from the remote control unit to the camera micro processor. On the other hand, the page, address, and data can also be transmitted the other way round.

#### 1. Using the adjusting remote control unit

- Connect the adjusting remote control unit to the remote terminal (DD-48 board J902).
- 2) Adjust the HOLD switch of the adjusting remote control unit to HOLD (SERVICE position).
  - If it has been properly connected, the LCD on the adjusting remote control unit will show the display in Fig. 7-6.




Fig. 7-6.

- 3) Operate the adjusting remote control unit as follows.
  - · Changing the page

The page will increase when the EDIT SEARCH+ button is pressed. It will decrease when the EDIT SEARCH-button is pressed. There are altogether 16 pages, from 0 to F.

Hexadecimal notation	0	1	2	3	4	5	6	7	8	9	Α	В	С	D	Е	F
Display on LCD	0	1	2	3	Ч	5	8	7	8	9	R	ь	C	d	ε	F
Decimal notation conversion value	0	1	2	3	4	5	6	7	8	9	10	11	12	13	14	15

Table 7-1.

· Changing the address

The address will increase when the FF ( → ) button is pressed, and decrease when the REW ( ← ) button is pressed. There are altogether 256 addresses, from 00 to FF

- Changing the data (Data setting)
  - The data will increase when the PLAY (►) button is pressed, and decrease when the STOP (■) button is pressed.
  - There are altogether 256 data, from 00 to FF.
- · Writing the adjustment data
  - It is necessary to press the PAUSE button to write the adjustment data (F page, D page) in the non-volatile memory.
  - (The new adjustment data will not be recorded in the non-volatile memory if this operation is not performed.)
- Select page: 6, address: 00, and adjust the data to 01. This
  releases the write protect of page F, and the camera section
  (F page) can be adjusted.
- After completing all adjustments, turn off the main power (6.3V) once. This can release the adjustment mode (other than page F).

## 2. Precautions upon using the adjusting remote control unit

The correct adjustment data may be erased at times, due to operation errors of the adjusting remote control unit. To prevent this from occurring, it is recommended that all adjustment data be recorded in the memory before beginning adjustments, and the new adjustment data be recorded in the memory after each adjustment.

#### 7-1-5. Page F Address List

- **Note 1:** The data listed in the adjustment data memo column are fixed values.
- Note 2: The adjustment data initial values are the values after performing "Page F Data Initialization" and "Page F Data Modification". They are different from the value after performing all the adjustments.

			Adjustn	nent data
Address	Name	Function [ ] Indicate the adjustment voltage output terminal	Initial value	Memo column
00	ID	Set ID	3E	3E
01	FADER LEVEL	AE REF level modification during fader	E0	E0
02	FADER ENDTIM	The setting of the AE REF modulation time during fader	10	10
03	CS SL	Carrier balance adjustment	35	
04	VSUB	CCD imager V SUB adjustment [IC702 ③]	80	
05	VPGH	CCD imager VRG adjustment [IC702 4]	80	
06	VREF Y	Camera core Y D/A standard voltage, SYNC level adjustment [IC702 ⑤]	7B	
07	VREF C	Camera core CHROMA D/A standard voltage, BURST level adjustment [IC702 ⑥]	99	
08	HALL GAIN	Hole amplifier gain adjustment [IC702 ⑦] HALL	47	
09	HALL OFFSET	Hole amplifier offset adjustment [IC702 ®]	71	
0A	LOWLIGHT CS	Low luminance intensity REF level modulation start setting	C0	C0
0B	REF 2V	2V standard voltage for hole element [IC702 ②]	68	68
0C	AD REF	Black level setting during A/D conversion, A/D off set adjustment [IC702 ③]	72	
0D	CORE DETH	CCD correction control	04	04
0E	CORE VTR DELAY	1HDL longitudinal setting during VTR playback	16	16
0F	CORE APCN4	Horizontal aperture setting	35	35
10	CORE APCN5	Vertical aperture setting	3D	3D
11	CORE EFECT	Special effect control	A0	A0
12	CORE MATR	BLUE matrix constant	24	24
13	CORE MATB	RED matrix constant	6C	6C
14	CORE BURST LEVEL	Burst flag level setting, color modulation ON/OFF  Data Adjustment modeAdjustment  2E Color modulation stopped  38 Normal level	38	38
15	CORE CHROMA DLY	Y/C delay adjustment	02	02
16	CORE Y SETUP	Set up level setting	06	06
17	CORE VHAPCN	Slice and level setting of the aperture signal	17	17
18	CORE B-Y GAIN	B-Y GAIN	13	
19	CORE R-Y GAIN	R-Y GAIN Color reproduction adjustments	11	
1A	CORE R-Y HUE	R-Y HUE	FF	
1B	CORE B-Y HUE	B-Y HUE	FD	
1C	CS/APCCUT	Low luminance intensity aperture and chroma suppress level	22	22

Table 7-2 (1).

		Function	Adjustn	nent data
Address	Name	Function [ ] Indicate the adjustment voltage output terminal	Initial value	Memo column
1D	NEXT LINE DEFECT BIT	CCD correction pattern	00	
1E	CCD DEFECTO	CCD correction data	00	
1F	CCD DEFECT1	CCD correction data	00	
20	CCD DEFECT2	CCD correction data	00	
21	CCD DEFECT3	CCD correction data	00	
22	CCD DEFECT4	CCD correction data	00	
23.	CCD DEFECT5	CCD correction data	00	
24	CCD DEFECT6	CCD correction data	00	
25	CCD DEFECT7	CCD correction data write	00	
26	CCD DEFECT8	CCD correction data	00	
27	CCD DEFECT9	CCD correction data	00	
28	CCD DEFECT10	CCD correction data	00	
29	CCD DEFECT11	CCD correction data	00	
2A	CCD DEFECT12	CCD correction data	00	
2B	CCD DEFECT13	CCD correction data	00	
2C	CCD DEFECT14	CCD correction data	00	
2D	RREF L	3200k Red standard data LSB	72	
2E	RREF H	3200k Red standard data MSB	5F	
2F	GREF L	3200k Green standard data LSB Auto white balance preset	D4	
30	GREF H	3200k Green standard data MSB adjustment	63	
31	BREF L	3200k Blue standard data LSB	3B	
32	BREF H	3200k Blue standard data MSB	2C	
33	RCONTREF	3200k RCONT adjustment value	42	
34	BCONTREF	3200k BCONT adjustment value Pre-white balance adjustment	4A	
35	AWB NOWM R	Red regular correction coefficient Auto white balance	7E	
36	AWB NORM B	Blue regular correction coefficient adjustment	96	
37	AWB SHUT IN	Indoor determination shutter data	A8	A8
38	ABW SHUT OUT	Outdoor determination shutter data	A0	A0
39	AWB IRIS IN	Indoor determination hole data	79	
3A	AWB IRIS OUT	Outdoor determination hole data    IRIS IN/OUT adjustment	7F	
3B	AWB G LEVEL	High luminance section green integral level	02	02
3C	AWB G WIDTH	High luminance section green integral level range	03	03
3D	DMAT HUE	Variable linear matrix HUE coefficient Linear matrix	00	
3E	DMAT GAIN	Variable linear matrix GAIN coefficient adjustment	00	
3F	AWB SELECT	AWB mode selection	00	00
40	AWB DIFF	Standard difference from the outdoor fixed value	0A	0A
41	AWB BOTTOM SLP R	AWB incoming frame bottom R coefficient	48	48
42	AWB BOTTOM SLP B	AWB incoming frame bottom B coefficient	78	78
43	AWB MIDDLE SLP R	AWB incoming frame middle R coefficient	60	60
44	AWB MIDDLE SLP B	AWB incoming frame middle B coefficient	40	40
45	AWB TOP SLP R	AWB incoming frame top R coefficient	66	66
46	AWB TOP SLP B	AWB incoming frame top B coefficient	18	18

Table 7-2 (2).

	<u> </u>	Funda	Adjustn	nent data
Address	Name	Function [ ] indicate the adjustment voltage output terminal	Initial value	Memo column
47	AWB KEIKO R	AWB incoming frame fluorescent light R coefficient	66	66
48	AWB KEIKO B	AWB incoming frame fluorescent light B coefficient	18	18
49	AWB BOTTOM UP	AWB incoming frame bottom upper value	C2	C2
4A	AWB BOTTOM DWN	AWB incoming frame bottom lower value	8C	8C
4B	AWB MIDDLE UP	AWB incoming frame middle upper value	AD	AD
4C	AWB MIDDLE DWN	AWB incoming frame middle lower value	96	96
4D	AWB TOP UP	AWB incoming frame top upper value	78	78
4E	AWB TOP DWN	AWB incoming frame top lower value	60	60
4F	AWB KEIKO	AWB incoming frame fluorescent light output lower value	66	66
50	AWB KEIKO DWN	AWB incoming frame fluorescent light lower value	59	59
51	AWB R TOP LMT	AWB incoming frame Rcont upper value	6E	6E
52	AWB R DWN LMT	AWB incoming frame Rcont lower value	20	20
53	AWB B TOP LMT	AWB incoming frame Boont upper value	83	83
54	AWB B IN TOP	AWB incoming frame Bcont	67	67
55	AWB B IN MAX	AWB incoming frame Bcont	5C	5C
56	AWB B OUT MIN	AWB incoming frame Bcont	5C	5C
57	AWB B OUT DWN	AWB incoming frame Bcont	4A	4A
58	AWB B DWN LMT	AWB incoming frame Bcont lower value	1B	1B
59	AWB LL LMT	Low luminance intensity limiter	06	06
5A	AWB T M DIVID	AWB incoming frame upper, middle border value	5E	5E
5B	AWB B M DIVID	AWB incoming frame middle, lower border value	39	39
		AWB tracking speed		
		Data Adjustment mode	000	OC.
5C	AWB DELAY TM	01 High speed tracking mode	OC	W
		OC Normal		
5D	AWB FAST TM	AWB initial high speed tracking amount	40	40
5E	AWB OUT HYS OFF	AWB outdoor hysteresis off difference	OC.	0C
5F	AWB OUT B HYS	AWB outdoor hysteresis amount	06	06
	Amboorbins	AWB adjustment mode		
		Data Adjustment mode		
60	AWB MODE	00 Normal	00	00
00	AMBINODE	DO AWB adjustment mode		
		F1 All area tracking mode		
61	AE REFL	Reference value (lower) for AE	00	00
62	AE REFH	Reference value (upper) for AE	1E	1E
63	AGC MIN	AGC MIN value (AGCREF value), IRIS level adjustment	E3	
64	AE MIML	Low luminance intensity side limiter (MAXGAIN), MAX GAIN adjustment	32	
65	AE MAXL	High luminance intensity side limiter (lower)	80	80
65	IRIS OFFSET	Iris ROM table OPEN side off set	D0	D0
66	<u> </u>		00	00
67	AE KEISU	Correction coefficient during detection weighting	1 00	1 00

Table 7-2 (3).

		Adjustn	nent data	
Address	Name	Function [ ] indicate the adjustment voltage output terminal	initial value	Memo column
69	BL HOSEIH	Forcible back light level setting (upper)	40	40
6A	JITEISU DOWN	Constant during loop response DOWN side	28	28
6B	JITEISU UP	Constant during loop response UP side	0D	0D
6C	AE KNEE	KNEE setting value for AE	FF	FF
6D	ORETEN SET	Variable point due to time constant error amount	13	13
6E	OMOMIOUT	Outer frame weighting amount	40	40
6F	AFC WIDE	Coefficient required for the ANF integral loop	03	03
70	AFC GAIN	Loop gain of the flickerless loop	01	01
71	AFC LIMIL	Limiter corresponding to the error rate (Lower)	60	60
72	HIST P KEISU	Histocomp level setting P for counter light determination	20	20
73	HIST H KEISU	Histocomp level setting H for counter light determination	E0	E0
74	HIST L KEISU	Histocomp level setting L for counter light determination	90	90
75	GYAKOU JITEISU	Constant during auto back light response	08	08
76	SABUN LIMIT	Limiter for counter light determination	40	40
77	FUZZY RULE1	Correction amount 1 for auto back light	A0	A0
78	FUZZY RULE2	Correction amount 2 for auto back light	D0	D0
79	FUZZY RULE3	Correction amount 3 for auto back light	E0	E0
7A	FUZZY RULE4	Correction amount 4 for auto back light	B0	B0
7B	FUZZY RULE5	Correction amount 5 for auto back light	70	70
7C	FUZZY RULE6	Correction amount 6 for auto back light	90	90
7D	FUZZY RULE7	Correction amount 7 for auto back light	B0	B0
7E	FUZZY RULE8	Correction amount 8 for auto back light	B8	B8
7F	FUZZY RULE9	Correction amount 9 for auto back light	98	98
80	FUZZY RULE10	Correction amount 10 for auto back light	78	78
81	IRIS MIN L	Iris limit value (lower)	42	42
82	IRIS MIN H	Iris limit value (upper)	02	02
83	DELTA SHUT GAIN	Shutter smoothing value setting	04	04
84	AE WAKUH	Frame data for AE detection (vertical line)	0F	0F
85	AE WAKUV	Frame data for AE detection (horizontal line)	4F	4F
86	WIDE LIMIT	ZOOM limiter WIDE (lower)	DE	
87	WIDE LIMITH	ZOOM limiter WIDE (upper)	02	
88	TELE LIMIT	ZOOM limiter TELE (lower)	22	
89	TELE LIMITH	ZOOM limiter TELE (upper)	1D	
8A	STEP ZERO	Flange back value	90	
8B	STEP ZERO SPAN	Frange back value 2	A0	
8C	ZOOM SPD FAST	Zoom speed (fast)	73	73
8D	ZOOM SPD SUPER	Zoom speed (For adjustment)	6A	6A
8E	ZS INIT SLOW	Zoom speed initial value (slow)	6A	6A
8F	ZS INIT FAST	Zoom speed initial value (fast)	6A	6A
90	ZMSPD DAMIN	Zoom speed D/A MIN value	3D	3D
91	ZSK	Zoom servo coefficient K	11	11
92	ZSL	Zoom servo coefficient L	04	04

Table 7-2 (4).

		Paradian	Adjustn	nent data
Address	Name .	Function [ ] Indicate the adjustment voltage output terminal	Initial value	Memo column
93	ZP HYS	Zoom potential hysteresis	03	03
94	ZOOM SPD SLOW	Zoom speed (slow)	29	29
95	AF MD2THL	MODE2 THR	20	20
96	MAXCHG THR	MAX value renewal THR	1A	1A
97	ERR THRL	Wobbling width THR	18	18
98	WOB INTV	Wobbling second interval	04	04
99	ERRPOL THR	MODE2 error possible THR	13	13
9A	MAXCHK THR	MAX CHECK THR	12	12
9B	REWOB THR	Wobbling second THR	0A	0A
· 9C	MODE2 INOUT	MODE2 speed switchover	8B	8B
9D	SMLWD THR	Small frame THR	0A	0A
9E	ZOOM PULSE LIMIT	Maximum zoom pulse value	EE	EE
9F	ZOOM RIZE	Zoom rise minimum speed time	0A	0A
A0	FB CURVEPEAKL	Constant for flange back adjustment	F5	F5
A1	FB CURVEPEAKH	Constant for flange back adjustment	0B	0B
A2	FB ZOOMSL	Constant for flange back adjustment	02	02
A3	FB ZOOMSH	Constant for flange back adjustment	07	07
A4	LIMITREST WIDE	Zoom limiter WIDE side	14	14
A5	LIMITREST TELE	Zoom limiter TELE side	17	17
A5	FB PEAKTHR	Constant for flange back adjustment	FF	FF
A7	FB ZOOM SLOW	Constant for flange back adjustment	1C	1C
A8	DET IRIS ALT	Iris variation check THR	02	02
A9	DET AGC ALT	AGC variation check THR	02	02
AA	LIMIT INSURANCE	Focus limiter insurance value	02	02
AA	LIMIT MOURANCE	Focus mode		
		Data Adjustment mode		
AB	FOCUS MODE	08 Zoom, Focus fixed	00	00
		00 Normal		
		Flange back adjustment mode  Data Adjustment mode		
AC	LENS ADJ MODE		00	00
		00 Nomal 01 Flange back adjustment		
	1 DNO DN (DC		00	00
AD	LENS EMRG	Lens emergency  DELAY bit=0: NTSC, 1: PAL, bit4-7=CCD correction delay	21	21
AE	NTSC PAL/H DEF DELAY	DDS display mode switchover	21	
AF	FT SW	Data DDS display mode  00 Y sampling display  02 R-Y display  40 HALL data display  82 R ratio display	00	00
		83 B ratio display 91 R, B ratio (M) display B0 Focus step display		

Table 7-2 (5).

		Function	Adjustment data		
Address	Name	Function [ ] indicate the adjustment voltage output terminal	initial value	Memo column	
В0	CORE OTHER	CORE MODE DATA 13 byte	10	10	
B1	CORE Y GAIN	CORE FIELD DATA 0 byte	3A	3A	
B2	E LOW LIGHT START	Low light chroma suppress start point	30	30	
В3					
B4	YAKEI LEVEL	YAKEI mode gain setting value	40	40	
B5					
В6	ZOOM DROP 1	F-No. dropping (1) by Zoom lens	60	60	
B7	ZOOM DROP 2	F-No. dropping (2) by Zoom lens	75	75	
B8					
В9					
BA	AWB IN B HYS	Hysteresis of AWB indoor BLUE	04	04	
BB	AWB IN R HYS	Hysteresis of AWB indoor RED	02	02	
BC	AWB KAKE NORM R	ADD: 35 NORM R × 1000H	20	20	
BD	AWB KAKE NORM B	ADD: 36 NORM B × 1000H	20	20	
BE	MF STEP CHNGE	Coefficent of MODE 2 THR	46	46	
BF	MD2 LOWCON SPD	Speed for Low-contrast at MODE 2	07	07	
C0	MAX CHECK NG CNT	MAX CHECK NG count	14	14	
C1	AF CONTROL FLAG		0E	0E	
C2	AE Y THR	Low light AE fluctuation THR 1	28	28	
C3	AE Y MIN	Low light AE fluctuation THR 2	20	20	
C4	MD2 SPD	Focus speed at MODE 2	61	61	
C5	AE CHECK	Re-start up AE THR	10	10	
C6	LOW CON THR	THR 1 for judging Low-contrast at MODE 2	10	10	
C7	LOW CON THR2	THR 2 for judging Low-contrast at MODE 2	20	20	
C8~EF		Not used			
F0			FF		
F1			FF		
F2			FF		
F3			FF		
F4			FF		
F5			FF		
F6			FF		
F7		Input column of the unit ID No., etc. Not related to unit	FF		
F8		operations.	FF		
F9			FF		
FA			FF		
FB			FF		
FC			FF		
FD			FF		
FE			FF		
FF			FF		

Table 7-2 (6).

#### 7-1-6. 6 Page, 1 Page Address List

The camera adjustment mode can be set by performing the following data settings at page: 6 or page: 1. (These page data can be set temporary, but when the main power (6.3V) is turned off, the original value (normal value) will be returned.

Therefore, these adjustment modes can be released very simply by turning the main power off.)

(Example) The camera adjustment mode (1) is set by setting data: 01 to page: 6, address: 00. The F page write protect will also be released.

#### 1. Page 6

Address	Adjustment Mode	Data	Function
00	Camera adjustment mode	01	Camera adjustment mode (1), F page write protect released
	•	10	Normal
		11	Camera adjustment mode (2), F page write protect released
01	Camera adjustment switch	00	Normal
	Note: To set this address adjustment	01	IRIS OPEN, AGC HOLD
	mode, it is necessary to press the	03	IRIS CLOSEI, AGC HOLD
	PAUSE button of the adjusting	05	IRIS CLOSE2, AGC MIN
	remote control unit after setting	07	IRIS CLOSE3, AGC MAX
	the data.	09	ND0.5 SHUTTER (PAL=1/160, NTSC=1/190)
		0B	ND0.8 SHUTTER (PAL=1/320, NTSC=1/380)
		0D	AWB PRESET1: 3200K PRESET DATA take in
		0F	WB 3200K PRESET: Indoor white balance mode
		11	AWB PRESET2: Preparation of 3200K PRESET DATA take in
		13	ZOOM HUNTING1 ZOOM SPDSLOW
		15	ZOOM HUNTING2 ZOOM SPDFAST
		17	AE FB adjustment mode
	l '		(IRIS: OPEN, AGC: REF, SHUTTER: 1/100 (NTSC), 1/120 (PAL)
		1D	EEPROM PRE WRITE: Page F initial data write
05	Shutter mode	00	NTSC=1/60, PAL=1/50
		19	1/2000
06	FOCUS limiter ON/OFF	00	FOCUS limiter ON (Normal)
00		01	FOCUS limiter OFF
07	ZOOM limiter ON/OFF	00	ZOOM limiter ON (Normal)
		01	ZOOM limiter OFF
08	ZOOM speed SLOW/FAST	00	Normal
		01	ZOOM speed SLOW
		02	ZOOM speed FAST
		03	ZOOM speed SUPER SLOW
09	COMPLEATED FLAG	00	Camera Adjustment not completed
*		01	Camera adjustment completed
11	ROM VERSION	01	Camera micro processor verl
*		02	Camera micro processor ver2
,		03	Camera micro processor ver3
0C	LENS INITIAL END	00	During the initial operation of the lens
*		01	Lens initial operation completed

Addresses with \* are exclusively for reading.

Table 7-3.

#### 2. Page 1

Address	Adjustment Mode	Adjustment Mode Data Function			
E6	VH address L		Title horizontal/vertical position (L)		
E7	VH address H		Title horizontal/vertical position (H)		

Table 7-4.

#### 7-1-7. Adjustment Connector

Most of the measuring points for the camera section adjustment are concentrated on CN701 of the VC-122 board. Connect the oscilloscope and etc. via the measuring pin (J-6082-139-A). The following table lists the terminal numbers and the signal names of CN701.

Terminal Number	Signal Name	Terminal Number	Signal Name		
1	D5V	2	NC		
3	NC	4	CAM SI		
5	NC	6	CAM SO		
7	CS OPD 8		CAM SCK		
9	CS CORE	10	GND		
11	IRIS OUT	12	NC		
13	V SUB CHK 14		CAM C		
15	PG CONT	16	GND		
17	NC	18	CAM Y		

Table 7-5.

#### 7-1-8. Data Processing

The calculation of the DDS display and the adjusting remote control unit display data (hexadecimal notation) are required for obtaining the adjustment data of some adjustment items. In this case, after converting the hexadecimal notation to decimal notation, calculate and convert the result to hexadecimal notation, and use it as the adjustment data. Table 7-6. indicates the hexadecimal notation-the decimal notation calculation table.

											<b></b>						
	The lower digits of the hexadecimal notation The upper digits of the hexadecimal notation	0	1	2	3	4	5	6	7	8	9	A (吊)	В (b)	C (∈)	D ( d )	<b>E</b> (€)	(
	0	0	1	2	3	4	5	6	7	8	9	10	11	12	13	14	
ľ	1	16	17	18	19	20	21	22	23	24	25	26	27	28	29	30	
	2	32	33	34	35	36	37	38	39	40	41	42	43	44	45	46	Ŀ
	3	48	49	50	51	52	53	54	55	56	57	58	59	60	61	62	
	4	64	65	66	67	68	69	70	71	72	73	74	75	76	77	78	
ſ	5	80	80	82	83	84	85	86	87	88	89	90	91	92	93	94	L
ſ	6	96	97	98	99	100	101	102	103	104	105	106	107	108	109	110	1
	7	112	113	114	115	116	117	118	119	120	121	122	123	124	125	126	1
ļ	8	128	129	130	131	132	133	134	135	136	137	138	139	140	141	142	1
Ī	9	144	145	146	147	148	149	150	151	152	153	154	155	156	157	158	1
	A(8)	160	161	162	163	164	165	166	167	168	169	170	171	172	173	174	1
-	B(b)	176	177	178	179	180	180	182	183	184	185	186	187	188	189	190	]
Ī	C(c)	192	193	194	195	196	197	198	199	200	201	202	203	204	205	206	2
Ī	D(d)	208	209	210	211	212	213	214	215	216	217	218	219	220	221	222	2
Ī	<b>E</b> ( <i>E</i> )	224	225	226	227	228	229	230	231	232	233	234	235	236	237	238	2
Ì	<b>F</b> ( <i>F</i> )	240	241	242	243	244	245	246	247	248	249	250	251	252	253	254	2

Note: ( ) indicate the adjusting remote control unit display.

(Example) In the case that the DDS display and the adjusting remote control unit display are BD ( & d ).

As the upper digit of the hexadecimal notation is **B** ( b ), and the lower digit is D ( d ), the intersection "189" of the ① and ② in the above table is the decimal notation to be calculated.

Table 7-6.

#### 7-2. CAMERA SYSTEM ADJUSTMENT

#### 1. Power Supply Voltage Check (DD-48 board)

Subject	Option
Measuring instrument	Digital voltmeter
D5V check	
Measurement point	Pins (5) and (8) of CN901
Specified value	4.92 ± 0.15 Vdc
D4V check	
Measurement point	Pin 4 of CN901
Specified value	3.98 ± 0.15 Vdc
CAM 5V check	
Measurement point	Pins 7 and 10 of CN901
Specified value	4.86 +0.15 Vdc
CAM 15V check	
Measurement point	Pin ② of CN901
Specified value	15.05 ± 0.4 Vdc
CAM –9V check	
Measurement point	Pin   of CN901
Specified value	$-8.5 \pm 0.4  \text{Vdc}$

#### Checking method:

 Check that each power supply voltage satisfies the specified value.

#### 2. Page F Data Initialization

Note: It is necessary to perform all adjustments of the camera section from the beginning again if the data of page F has been initialized.

#### Initializing method:

- Check that the data of page: 6, address: 09 is 00.
   (Display indicating that page F data can be initialized)
- 2) Check that the data of page: 6, address: 01 is 00.
- 3) Set data: 1D to page: 6, address: 01, and press the PAUSE button of the adjusting remote control unit.

  (Page F data initialization execution.

  The data of all addresses of page F will be initialized.)
- Check that the data of page: 6, address: 09 is 01.
   (Displays that the initialization of page F data has been completed)
- Set data: 00 to page: 6, address: 01. and press the PAUSE button of the adjusting remote control unit.
   (Releases the page F data initialization mode)
- 6) After performing "Page F data modification", perform all the adjustments of the camera section (page F).

#### 3. Page F Data Modification

The data (initial data) that is automatically written on page F after the initialization of the page F data will differ according to some camera micro processor versions. Change the data by manual input, and arrange it.

Note: When changing the data, to write the data to the non-volatile memory, press the PAUSE button of the adjusting remote control unit every time the new data is set.

Address	Data
00 (ID)	3E
0A (LOW LIGHT CS)	C0
11 (CORE EFFECT)	A0
12 (CORE MAT R)	24
14 (CORE BURST LEVEL)	38
15 (CORE CHROMA DLY)	02
17 (CORE VHAPCN)	17
5C (AWB DELAY TM)	0C
68 (AE FUNCTION)	02
6A (JITEISU DOWN)	28
6B (JITEISU UP)	0D
8C (ZOOM SPD FAST)	73
8D (ZOOM SPD SUPER)	6A
8E (ZS INIT SLOW)	6A
8F (ZS INIT FAST)	6A
94 (ZOOM SPD SLOW)	29
9E (ZOOM PULSE UNIT)	EE
A2 (FB ZOOM SL)	02
A3 (FB ZOOM SH)	07
AE (NTSC PAL/H DEF DELAY)	21
B0 (CORE OTHER)	10
B1 (CORE Y GAIN)	3A
B2 (E LOW LIGHT START)	30
C0 (MAX CHK NGCNT)	14

#### [Distinguishing the Camera Micro Computer (IC709) Versions]

Each version can be distinguished by looking at the part name of the camera micro processor or the data of page: 6, address: 11.

Version	Part Name	Page: 6 Address: 11
Ver.2	CXP80624-424R	02
Ver.3	CXP80624-434R	03

## 4. 28 MHz Original Oscillation Adjustment (VC-122 board)

Subject	Not required	
Measurement Point	Pin ① of IC706 (14 MHz)	
Measuring Instrument	Frequency counter	
Adjusting Element	CT801	
Specified Value	14187500 ± 71 Hz	

#### Adjusting method:

 Use CT801 to adjust the oscillation frequency to 14187500 ± 71 Hz.

#### 5. V SUB Adjustment (VC-122 board)

Subject	Not required
Measurement Point	Pin (3) of CN701 (V SUB CHK)
Measuring Instrument	Digital voltmeter
Adjustment Page	F
Adjustment Address	04 (V SUB)
Specified Value	(Imager display voltage) ± 0.1 Vdc

#### Adjusting method:

1) Release the protect.

Page: 6, address: 00, data: 01

- Change the data of page: F, address: 04, and adjust the voltage of pin (3) of CN701 to (imager display voltage) ± 0.1 Vdc.
- Press the PAUSE button of the adjusting remote control unit.




Fig. 7-7.

**Note:** This VSUB voltage code address can not be used for other models.

#### 6. VRG Adjustment (VC-122 board)

Subject	Not required
Measurement Point	Pin (5) of CN701 (PG CONT)
Measuring Instrument	Digital voltmeter
Adjustment Page	F
Adjustment Address	05 (VRG)
Specified Value	(Imager display voltage) ± 0.1 Vdc

#### Adjusting method:

- 1) Release the protect.
  - Page: 6, address: 00, data: 01
- 2) Change the data of page: F, address: 05, and adjust the voltage of pin (5) of CN701 to (imager display voltage) ± 0.1 Vdc.
- Press the PAUSE button of the adjusting remote control unit.

#### 7. CCD Imager Correction Data Write

Subject	Not required
Adjustment Page	F
Adjustment	1D to 2C (CCD-DEFECT)

Perform CCD imager correction data write in the following cases.

- 1. When the CCD imager has been replaced
- 2. The ocassion of exchaning a camera micro processor or EEPROM (IC712).
- 3. When the page F data has been initialized

In the case of 1, as the correction data is not required for the CCD imager for repair, adjust all data of addresses 1D to 2C to "00"

In the case of 2 and 3, write the correction data attached to the shield case of VC-122 board to addresses 1D to 2C.

If the correction data are not attached, adjust all data of addresses 1D to 2C to "00".

#### Adjusting method:

- 1) Release the protect.
  - Page: 6, address: 00, data: 01
- 2) Write the correction data to page: F, addresses: 1D to 2C.

**Note:** To perform write to the non-volatile memory, press the PAUSE button of the adjusting remote control unit before changing addresses.

#### Processing after completing adjustments

 If the CCD imager has been replaced, remove the old correction data label attached on the shield case (UPPER) of VC-122 board.

#### 8. HALL Adjustment

Subject	Not required
Measurement Point	DDS display of EVF or monitor TV
Measuring Instrument	
Adjustment Page	F
Adjustment Address	08 (HALL GAIN) 09 (HALL OFFSET)
Specified Value	31 to 35 during IRIS OPEN B1 to B5 during IRIS CLOSE

#### Adjusting method:

- 1) Release the protect.
  - Page: 6, address: 00, data: 01
- Set data: 40 to page: F, address: AF, and press the PAUSE button of the adjusting remote control unit. (HALL output display mode setting)
- Set data: 03 to page: 6, address: 01, and press the PAUSE button of the adjusting remote control unit. (IRIS CLOSE mode setting)
- 4) Set data: 40 to page: F, address: 08, and press the PAUSE button of the adjusting remote control unit.
- Read the DDS display data (the bottom two digits of the display data at the bottom right of the EVF or the monitor TV display), and set to W2.
- 6) Set data: 30 to page: F, address: 08, and press the PAUSE button of the adjusting remote control unit.
- 7) Read the DDS display data, and set to W1.
- Set data: 01 to page: 6, address: 01, and press the PAUSE button of the adjusting remote control unit. (IRIS OPEN mode setting)
- 9) Read the DDS display data, and set to K1.
- Set data: 40 to page: F, address: 08, and press the PAUSE button.
- 11) Read the DDS display data, and set to K2.
- 12) Convert W1, W2, K1, K2 to decimal notation, and obtain W1', W2', K1', K2'. (Refer to Table 7-6. "Hexadecimal notation-decimal notation conversion table".)
- 13) Calculate X1' using the following equations (decimal notation calculation).
  - $A'=W_2'+K_1'-W_1'-K_2'-\cdots$ Equation 1  $B'=W_1'-K_1'-\cdots$ Equation 2  $X1'=\frac{2048+(48\times A')-(16\times B')}{A'}$ Equation 3
- Convert X1' to hexadecimal notation, and obtain X1.
   (Round off to one decimal place)
- 15) Set data: X1 to page: F, address: 08, and press the PAUSE button of the adjusting remote control unit.
- Change the data of page: F, address: 09, and adjust the DDS display data to "33".
- Press the PAUSE button of the adjusting remote control unit.
- 18) Set data: 03 to page: 6, address: 01, and press the PAUSE button of the adjusting remote control unit. (IRIS CLOSE mode setting)

- 19) Read the DDS display data, and set to Wo. If Wo lies within the "B1" to "B5" range, perform "Processing after completing adjustments". If it lies outside the range, perform the following adjustments.
- 20) Convert Wo to hexadecimal notation, and obtain Wo'.
- - (X1' and B' are values obtained from equations 2 and 3)
- 22) Convert X2' to hexadecimal notation and obtain X2. (Round off to one decimal place)
- 23) Set data X2 to page: F, address: 08, and press the PAUSE button of the adjusting remote control unit.
- 24) Change the data of page: F, address: 09, and adjust the DDS display data to "B3".
- 25) Press the PAUSE button of the adjusting remote control
- 26) Set data: 01 to page: 6, address: 01, and press the PAUSE button of the adjusting remote control unit. (IRIS OPEN mode setting)
- 27) Check that the DDS display data lies within the "31" to "35" range.

#### Processing after Completing Adjustments

 Set data: 00 to page: 6, address: 01, and press the PAUSE button of the adjusting remote control unit. (IRIS NORMAL mode setting)

### 9. Flange Back Adjustment

Subject	Chart for flange back adjustment (1998 ± 5mm from the front side of the lens Luminance: 300 ± 50 lux
Measurement Point	Check the operations on the TV
Measuring Instrument	monitor
Adjustment Page	F
Adjustment Address	86 (WIDE LIMIT), 87 (WIDE LIMIT H), 88 (TELE LIMIT), 89 (TELE LIMIT H), 8A (STEP ZERO), 8B (STEP ZERO SPAN)

### Adjusting method:

- 1) Turn the auto focus off.
- 2) Adjust the focus using the focus knob.
- Check that the flange back adjustment chart center and the exposure display center coincide at both zoom lens TELE end and WIDE end.
- 4) Release the protect.

Page: 6, address: 00, data: 01

- 5) Check that the data of page: 6, address: 09 is 00. (Flange back adjustment possible display)
- 6) Check that the page: F, address: 86 to 8B data is at the initial value. (Refer to Table 7-2. "Page F address list")
- 7) Set data: 01 to page: F, address: AC.

  This causes automatic adjustment to be performed.\
  Adjustments are performed at the zoom lens TELE end first, and then at the WIDE end. The adjustment data is automatically input to page: F, addresses: 86 to 8B.
- 8) Check that the data of page: 6, address: 09 is 01.(Display indicating flange back adjustment completion)

### Processing after completing adjustments

- 1) Set data: 00 to page: F, address: AC.
- 2) Turn off the main power supply (6.3V).

### 10. Flange Back Check

Subject	Siemens star (2m (or 1.4m) from the front of the lens)
Measurement Point	DDS display of EVF or TV monitor
Measuring Instrument	
Specified Value	D2=D1 ± 5

### Checking method:

- Set data: 01 to page: 6, address: 00. (Camera adjustment mode)
- Set data: B0 to page: F, address: AF. (Focus step display mode)
- 3) Place the Siemens star 2m (or 1.4m) from the front of the lens.
- 4) To open the IRIS, decrease the luminous intensity to the Siemens star up to a point before noise appears on the image displayed on the monitor TV screen.
- 5) Turn off the auto-focus.
- 6) Shoot the Siemens star with the zoom TELE end.
- 7) Rotate the focus ring, and adjust the focus.
- 8) Adjust to the zoom WIDE end.
- Read the focus step value (4 digits) displayed on the TV monitor, and take the value as D1.
- Rotate the focus ring, and adjust the focus.
   Read the focus step value here, and take the value as D2.
- 11) Check that  $D_2=D_1 \pm 5$ .

### Process after checking

 Set data: 00 to page: F, address: AF, and press the PAUSE button of the adjusting remote control unit.

### 11. SYNC Level Adjustment (VC-122 board)


Subject	Not required
Measurement Point	Pin ® of CN701 (CAM Y)
Measuring Instrument	Oscilloscope
Adjustment Page	F
Adjustment Address	06 (VREF-Y)
Specified Value	A=150 ± 5 mV

### Adjusting method:

- 1) Release the protect.
  - Page: 6, address: 00, data: 01
- Set data: 05 to page: 6, address: 01, and press the PAUSE button of the adjusting remote control unit. (IRIS CLOSE mode setting)
- 3) Change the data of page: F, address: 06, and adjust so that the SYNC level (A) becomes the specified value.
- Press the PAUSE button of the adjusting remote control unit.

### Processing after completing adjustments

 Set data: 00 to page: 6, address: 01, and press the PAUSE button of the adjusting remote control unit. (Release of IRIS CLOSE mode)



### 12. BURST Level Adjustment (VC-122 board)


Subject	Not required
Measurement Point	Pin (4) of CN701 (CAM C)
Measuring Instrument	Oscilloscope
Adjustment Page	F
Adjustment Address	07 (VREF-C)
Specified Value	A=150 ± 5 mVp-p

### Adjusting method:

- 1) Release the protect.
  - Page: 6, address: 00, data: 01
- Set data: 05 to page: 6, address: 01, and press the PAUSE button of the adjusting remote control unit. (IRIS CLOSE mode setting)
- 3) Change the data of page: F, address: 07, and adjust so that the burst level (A) becomes the specified value.
- Press the PAUSE button of the adjusting remote control unit.

### Processing after completing adjustments

 Set data: 00 to page: 6, address: 01, and press the PAUSE button of the adjusting remote control unit. (Release of IRIS CLOSE mode)



### 13. A/D Offset Adjustment

Subject	Not required
Measurement Point	DDS display on the EVF or the TV
Measuring Instrument	monitor
Adjustment Page	F
Adjustment Address	OC (AD REF)
Specified Value	46 to 47

### Adjusting method:

1) Release the protect.

Page: 6, address: 00, data: 01

- Set data: 05 to page: 6, address: 01, and press the PAUSE button of the adjusting remote control unit. (IRIS CLOSE AGC MIN mode setting)
- Set data: 00 to page: F, address: AF, and press the PAUSE button of the adjusting remote control unit.
   (Y sampling output mode setting)
- 4) Set data: 35 to page: 1, address: E6. (Setting 1 of the sampling position)
- 5) Set data: 6D to page: 1, address: E7. (Setting 2 of the sampling position)
- 6) Change the data of page: F, address: OC, and adjust the average value of the DDS display (the bottom two digits of the display data at the bottom right of the EVF or the TV monitor display) to 46 to 47.

(Set the data of address OC to the maximum value) satisfying the specification.

 Press the PAUSE button of the adjusting remote control unit.

### Processing after completing adjustments

1) Turn the main power supply (6.3V) off.

### 14. Carrier Balance Adjustment

Subject	Not required
Measurement Point	Video output terminal
Measuring Instrument	Vectorscope
Adjustment Page	F
Adjustment Address	03 (CS SL)
Specified Value	The center of the black luminance point should lie within the 1 $\phi$ circle whose center is the principle point.

### Adjusting method:

1) Release the protect.

Page: 6, address: 00, data: 01.

- Set data: 07 to page: 6, address: 01, and press the PAUSE button of the adjusting remote control unit. (IRIS CLOSE, AGC MAX mode setting)
- 3) Change the data of page: F, address: 03, and adjust so that the center of the black luminance point coincides with the principle point.
- 4) Press the PAUSE button of the adjusting remote control unit.

### Processing after completing adjustments

 Set data: 00 to page: 6, address: 01, and press the PAUSE button of the adjusting remote control unit. (IRIS NORMAL mode setting)

The center of the black luminance point should be within this




Fig. 7-10.

### 15. Picture Frame Setting


Subject	Color bar chart standard picture frame
Measurement Point	Video output terminal
Measuring Instrument	Oscilloscope and TV monitor.
Specified Value	A=B, C=D, t=0 ± 0.1 msec

### Setting method:

- 1) Turn the auto focus off.
- 2) Adjust the focus using the focus knob.
- 3) Adjust the zoom and the camera direction, and set to the specified position.
- 4) Mark the position of the picture frame on the monitor display, and adjust the picture frame to this position in following adjustments using "color bar chart standard picture frame" and "white pattern standard picture frame".

### Check on the oscilloscope

### 1. horizontal period



### 2. Vertical period




Fig. 7-11.

### Check on the TV monitor




Fig. 7-12.

### 16. IRIS Level Adjustment (VC-122 board)

Subject	Color bar standard picture frame
Measurement Point	Pin ① of CN701 (IRIS OUT)
Measuring Instrument	Oscilloscope
Adjustment Page	F
Adjustment Address	63 (AGC MIN)
Specified Value	A=200 ± 5 mV

### Adjusting method:

- 1) Release the protect.
  - Page: 6, address: 00, data: 01
- Change the data of page: F, address: 63, and adjust so that the IRIS OUT signal level (A) becomes the specified value.
- 3) Press the PAUSE button of the adjusting remote control




Fig. 7-13.

### 17. MAX GAIN Adjustment (VC-122 board)

Subject	Color bar standard picture frame
Filter	ND filter 1.0 (2 sheets) and 0.4 (1 sheet), 0.1 (1 sheet)
Measurement Point	Pin ® of CN701 (CAM Y)
Measuring Instrument	Oscilloscope
Adjustment Page	F
Adjustment Address	64 (AE MIN L)
Specified Value	A=200 ± 5 mV

### Adjusting method:

- 1) Place the ND filter 2.5 (1.0+1.0+0.4+0.1) on the lens.
- 2) Release the protect.
  - Page: 6, address: 00, data: 01
- 2) Change the data of page: F, address: 64, and adjust so that the CAM Y signal level (A) becomes the specified value.
- 4) Press the PAUSE button of the adjusting remote control unit.




Fig. 7-14.

### 18. IRIS IN/OUT Adjustment

Subject	White pattern standard picture frame
Measurement Point	DDS display of the EVF or TV
Measuring Instrument	monitor
Adjustment Page	F
Adjustment Address	39 (AWB IRIS IN) 3A (AWB IRIS OUT)

### Adjusting method:

- 1) Set data: 11 to page: 6, address: 00. (Camera adjustment mode 2 setting)
- Set data: 40 to page: F, address: AF, and press the PAUSE button of the adjusting remote control unit. (HALL data display)
- Set data: OB to page: 6, address: 01, and press the PAUSE button of the adjusting remote control unit. (ND0.8 shutter mode setting)
- Read the DDS display data (the bottom two digits of the display data at the bottom right of the EVF or the TV monitor), and set to D39.
- 5) Set data: D39 to page: F, address: 39, and press the PAUSE button of the adjusting remote control unit.
- 6) Set data: 09 to page: 6, address: 01, and press the PAUSE button of the adjusting remote control unit. (ND0.5 shutter mode setting)
- 7) Read the DDS display data and set to D3A.
- 8) Set data: D3A to page: F, address: 3A, and press the PAUSE button of the adjusting remote control unit.

### Processing after completing adjustments

 Set data: 00 to page: 6, address: 01, and press the PAUSE button of the adjusting remote control unit. (Release of the ND0.5 shutter mode)

### 19. Pre-white Balance Adjustment

Subject	White pattern standard picture frame
Measurement Point	Video output terminal
Measuring Instrument	Vectorscope
Adjustment Page	F
Adjustment Address	33 (R CONT REF), 34 (B CONT REF)
Specified Value	The center of the white luminance point should lie within the circle with a diameter of 1mm and whose center is the principle point

### Adjusting method:

- Set data: OF to page: 6, address: 01, and press the PAUSE button of the adjusting remote control unit. (WB 3200K preset mode setting)
- 2) Set data: 11 to page: 6, address: 00. (Camera adjustment mode 2 setting)
- Change the data of addresses:33 and 34 of page: F alternately, and coincide the white luminance point to the principle point.

**Note:** Be sure to press the PAUSE button of the adjusting remote control unit before changing the addresses. If not, the new data will not written to the memory.

 Press the PAUSE button of the adjusting remote control unit.

- Set data: 00 to page: 6, address: 01, and press the PAUSE button of the adjusting remote control unit. (Release of the preset mode)
- Set data: 10 to page: 6, address: 00. (Protect mode setting)




Fig. 7-15.

### 20. Color Reproduction Adjustment

Subject	Color bar chart standard picture frame
Measurement Point	Video output terminal
Measuring Instrument	Vectorscope
Adjustment Page	F
Adjustment Address	18 (CORE B-Y GAIN), 19 (CORE R-Y GAIN), 1A (CORE R-Y HUE), 1B (CORE B-Y HUE)
Specified Value	All color luminance points should settle within each color reproduction frame.

### Adjusting method:


- 1) Release the protect.
  - Page: 6, address: 00, data: 01
- Set data: OF to page: 6, address: 01, and press the PAUSE button of the adjusting remote control unit. (Indoor white balance mode setting)
- Adjust the GAIN and PHASE of the vectorscope, and adjust the burst luminance point to the burst position of the color reproduction frame.
- 4) Change the data of addresses 18 to 1B of page: F, and settle each color luminance point in each color reproduction frame.

Note: Be sure to press the PAUSE button of the adjusting remote control unit before changing the addresses.

If not, the new data will not be written to the memory.

 Press the PAUSE button of the adjusting remote control unit.

- Set data: 00 to page: 6, address: 01 and press the PAUSE button of the adjustment remote control unit. (Release of the adjustment mode)
- 2) Set data: 10 to page: 6, address: 00. (Protect mode setting)






Fig. 7-17. Direction of the Movements of the Adjustment Address and Luminance Point

### 21. Auto White Balance Preset Adjustment

Subject	White pattern standard picture frame
Adjustment Page	F
Adjustment Address	2D (R REF L), 2E (R REF H), 2F (G REF L), 30 (G REF H), 31 (B REF L), 32 (B REF H)

### Adjusting method:

- 1) Turn the power of the unit OFF/ON.
- 2) Check that the data of page: 6, address: 09 is 00. (Auto white balance preset adjustment possible display)
- Set data: 11 to page: 6, address: 00, and wait at least 2 seconds.

(Camera adjustment mode 2 setting)

- 5) Set data: 11 to page: 6, address: 01, and press the PAUSE button of the adjusting remote control unit.(3200K preset data take in preparation mode)
- 6) Set data: 0D to page: 6, address: 01, and press the PAUSE button of the adjusting remote control unit.
  (When the 3200K preset data is taken in, the data will be automatically input to addresses 2D to 32 of page F.
- 7) Check that the data of page: 6, address: 09 is 01.(Auto white balance preset adjustment completion display)

### Processing after completing adjustments

- Set data: 00 to page: 6, address: 01, and press the PAUSE button of the adjusting remote control unit. (Release of the auto white balance preset mode)
- Set data: 10 to page: 6, address: 00.
   (Release of camera adjustment mode 2)

### 22. Auto White Balance Adjustment

Subject	White pattern standard picture frame
Filter	Filter C14 for color temperature correction
Measurement Point	Check with the DDS display on the EVF or TV monitor
Measuring Instrument	
Adjustment Page	F
Adjustment Address	35 (AWB NORM R) 36 (AWB NORM B)
Specified Value	R ratio 2980 ± 40 B ratio 5D80 ± 40

**Note:** Check that "Auto White Balance Preset Adjustment" have been completed.

### Adjusting method:

- Place the C14 filter for color temperature correction on the lens.
- 2) Set data: 11 to page: 6, address: 00. (Camera adjustment mode 2 setting)
- Set data: D0 to page: F, address: 60, and press the PAUSE button of the adjusting remote control unit.
   (Auto white balance adjustment mode setting)
- Set data: 82 to page: F, address: AF.
   (R ratio display mode setting)
- 5) Change the data of page: F, address: 35, and adjust the average value of the DDS display data (the display data at the bottom right of the EVF or the TV monitor) to 2980 ±
- Press the PAUSE button of the adjusting remote control unit.
- 7) Set data: 83 to page: F, address: AF. (B ratio display mode setting)
- 8) Change the data of page: F, address: 36, and adjust the average value of the DDS display data to  $5D80 \pm 40$ .
- Press the PAUSE button of the adjusting remote control unit.

- Set data: 00 to page: F, address: 60, and press the PAUSE button of the adjusting remote control unit. (Release of the white balance adjustment mode)
- 2) Set data: 10 to page: 6, address: 00. (Release of camera adjustment mode 2)

### 23. White Balance Check

Subject	White pattern standard picture frame
Filter	Filter C14 for color temperature correction ND filter 1.0 and 0.3
Measurement Point	Video output terminal
Measuring Instrument	Vectorscope
Specified Value	Fig. 7-18. A to C

### Checking method:

- 1) Check that the lens is not covered with either filter.
- Set data: 11 to page: 6, address: 00.
   (Camera adjustment mode 2 setting)
- Set data: OF to page: 6, address: 01, and press the PAUSE button of the adjusting remote control unit.
   (Indoor white balance mode setting)
- Check that the center of the white luminance point is within the circle shown in Fig. 7-18.A.
   (Indoor white balance check)
- Set data: 00 to page: 6, address: 01, and press the PAUSE button of the adjusting remote control unit. (Auto white balance mode setting)
- Set data: 01 to page: F, address: 5C, and press the PAUSE button of the adjusting remote control unit.
   (Auto white balance high speed tracking mode setting)
- 7) Set data: 91 to page: F, address: AF (R, B ratio (M) display mode setting), and check that the top 2 digits and bottom 2 digits of the DDS display are 3D to 43. Or check that the center of the white luminance point is within the circle shown in Fig. 7-18. A.
- 8) Place the C14 filter on the lens.
- Check that the center of the white luminance point settles in the circle shown in Fig. 7-18. B.
   (Auto white balance outdoor mode check)
- 10) Remove the C14 filter, and place the ND filter 1.3 (1.0+0.3) on the lens.
- Check that the center of the white luminance point settles in the circle shown in Fig. 7-18. C.
   (Auto white balance outdoor mode check)

- Set data: OC to page: F, address: 5C, and press the PAUSE button of the adjusting remote control unit. (Release of the auto white balance fast tracking mode)
- Set data: 10 to page: 6, address: 00.
   (Release of camera adjustment mode 2)
- 3) Set data: 00 to page: 6, address: 01, and press the PAUSE button.






Fig. 7-18. A





### 24. Linear Matrix Adjustment

Subject	Color bar standard picture frame
Filter	Filter C14 for color temperature correction
Measurement Point	DDS display on the EVF or TV monitor
Measuring Instrument	
Adjustment Page	F
Adjustment Address	3D (DMAT HUE) 3E (DMAT GAIN)

Note 1: Check that position that was set in the color bar chart picture frame "15. Picture Frame Setting" is maintained, before beginning adjustments.

### Adjusting method:

- 1) Remove the filter C14 for color temperature correction.
- 2) Release the protect.

Page: 6, address: 00, data: 01

- 3) Color bar data sampling mode setting
  - Set data: F1 to page: F, address: 60, and press the PAUSE button of the adjusting remote control unit.
  - 2. Set data: 2E to page: F, address: 14, and press the PAUSE button of the adjusting remote control unit.

Check that the colors on the monitor display at the color modulation stop mode have disappeared

- 4) Specifying the Yellow position
  - 1. Set data: C9 to page: 1, address: E6.
  - 2. Set data: B6 to page: 1, address: E7.
- Set data: 02 to page: F, address: AF, and press the PAUSE button of the adjusting remote control unit.
   (R-Y data display mode setting)
- Read the average value of the DDS display data (Note 2), and set to Y1.
- 7) Specifying the Red position
  - 1. Set data: 59 to page: 1, address: E6.
  - 2. Set data: 6D to page: 1, address: E7.
- 8) Select page: F and read the average value of the DDS display data (Note 2), and set to R1.
- Place the filter C14 for color temperature correction on the lens. (Ensure that the picture frame of the chart does not shift at this time.)
- 10) Specifying the yellow position.
  - 1. Set data: C9 to page: 1, address: E6.
  - 2. Set data: B6 to page: 1, address: E7.
- 11) Select page: F and read the average value of the DDS display data (Note 2), and set to Y2.
- 12) Specifying the Red position
  - 1. Set data: 59 to page: 1, address: E6.
  - 2. Set data: 6D to page: 1, address: E7.
- Select page: F and read the average value of the DDS display data (Note 2), and set to R2.

- 14) Convert Y1, R1, Y2, R2 to decimal notation to obtain Y1', R1', Y2' and R2'.
  - (Refer to Table 7-6. "Hexadecimal notation-decimal notation conversion table")
- 15) Calculate X1' from the following equation (decimal notation calculation).

X1'=Y2'-Y1'

16) Calculate D3D from the following table (D3D is hexadecimal notation)

Xı' value	DзD
$-1 \le X_1' \le 1$ $X_1' > 1$ $X_1' < -1$	F0 F1 FF

- 17) Set data: D3D to page: F, address: 3D, and press the PAUSE button of the adjusting remote control unit.
- 18) Calculate X2' from the following equation (decimal notation calculation).

X2'=R2'-R1'

19) Calculate D3E from the following table.

D3E
00
01
02

20) Set data: D3E to page: F, address: 3E, and press the PAUSE button of the adjusting remote control unit.

### Processing after completing adjustments

- Set data: 00 to page: F, address: 60, and press the PAUSE button of the adjusting remote control unit. (Release of the sampling mode)
- Set data: 38 to page: F, address: 14, and press the PAUSE button of the adjusting remote control unit.
   (Color modulation ON mode setting)
- Set data: 00 to page: F, address: AF, and press the PAUSE button of the adjusting remote control unit. (Release of the R-Y data display mode)
- 4) Turn the main power supply (6.3V) off.

Note 2: As the R-Y data and B-Y data are displayed alternatively, it will be difficult to read the R-Y data. Record this data on a tape, and perform frame advancing playback so that only the R-Y data is read. (Example)

If the frame advancing playback is performed, the following will be displayed.

81 → 7A → 82 → 7A → 80 → 7A → 81 → 7C → 81 → 79 As the R-Y data is above 80, and the B-Y data is below 7F, the data which is underlined is the R-Y data. If the average value is calculated, the R-Y data will become 81.

### 25. VIDEO OUT Level Check

Subject	Color bar chart standard picture frame
Measurement Point	Video output terminal (Terminated at 75 Ω)
Measuring Instrument	Oscilloscope
Specified Value	Y level=680 ± 40 mV SYNC level=300 ± 20 mV BURST level=300 ± 30 mVp-p

### Checking method:

1) Check that the Y level, SYNC level and BURST level satisfy the specified values.




Fig. 7-19.


## 7-3. ELECTRONIC VIEWFINDER SYSTEM ADJUSTMENTS

### 7-3-1. Horizontal Slant Adjustment

Model	Playback
Signal	Alignment tape: For checking operations (WR5-5CSP) Monoscope section
Specified Value	Refer to Fig. 7-21.

### Adjusting method:

- 1) Adjust RV504 (BRIGHT) so that the CRT can be seen easily and clearly.
- 2) Loosen the DY (deflection yoke) tightening nut.
- 3) Rotate DY, and adjust the image so that it is horizontal.
- 4) Tighten the DY tightening nut. (Do not tighten it too tightly.)



Specified value: The image should be within  $\pm$  1.5  $^{\circ}$  of the horizontal line.

Fig. 7-21.




Fig. 7-22.

### 7-3-2. Centering Adjustment

Model	Playback
Signal	Alignment tape: For checking operations (WR5-5CSP) Monoscope section
Specified Value	Refer to Fig. 7-23.

### Adjusting method:

 Use the centering adjustment ring and adjust so that the left, right, top, and bottom sides of the display are uniform. (Refer to Fig. 7-22.)

Note: As the centering position changes due to earth magnetism, rotate it 360 in the horizontal direction, and adjust with the center section of the modifying position.




Fig. 7-23.

### 7-3-3. Focus Adjustment

Model	Playback
Signal	Alignment tape: For checking operations (WR5-5CSP) Monoscope section

### Adjusting method:

1) Adjust the focus ring to obtain the optimum focus. (Refer to Fig. 7-22.)

### 7-3-4. Aberration Adjustment

Model	E-E
Signal	Dot pattern
Specified Value	Refer to Fig. 7-24.

### Adjusting method:

- Adjust the aberration adjustment ring so that the tracing of the dot becomes less than twice the diameter of the dot, or the fan aberration becomes less than the diameter of the dot.
- 2) If the centering becomes displaced here, perform the centering adjustment from the beginning again.



Fig. 7-24.

# 7-3-5. Horizontal Oscillation Frequency Adjustment (VF-42 board)

Model	Playback
Signal	Alignment tape: For checking operations (WR5-5CSP)
Measurement Point	Positive pole terminal of C516
Measuring Instrument	Digital voltmeter or oscilloscope (DC range)
Adjustment Element	RV501
Specified Value	2.60 ± 0.05 Vdc

### Adjusting method:

1) Adjust to  $2.60 \pm 0.05$  Vdc using RV501.

### 7-3-6. Horizontal Amplitude Adjustment (VF-42 board)

Model	Playback
Signal	Alignment tape: For checking operations (WR5-5CSP) Monoscope section
Adjusting Element	C504
Specified Value	6 ± 2%

### Adjusting method:

- Rotate RV502, and adjust the top and bottom sides of the monoscope image to the top and bottom edges of the display.
- 2) Rotate RV504 so that the brightness is the normal level.
- 3) Adjust the pattern (A) of the H size adjustment capacitor (C504) to "short" or "open", so that the horizontal direction over scan becomes 6 ± 2% (Left and right totals). (Refer to Fig. 7-26.)





Fig. 7-25.



Section A	Size H
Open	Small
Short	Big

Fig. 7-26.

### 7-3-7. Vertical Amplitude Adjustment (VF-42 board)

Model	Playback
Signal	Alignment tape: For checking operations (WR5-5CSP) Monoscope section
Adjusting Element	RV502
Specified Value	5 ± 2%

### Adjusting method:

1) Adjust RV502 so that the vertical direction over scan becomes  $5 \pm 2\%$  (Top and bottom totals).




Fig. 7-27.

## 7-3-8. Brightness, Contrast Adjustments (VF-42 board)

Model	Playback
Signal	Alignment tape: For checking operations (WR5-5CSP) Monoscope section
Adjusting Element	Brightness: RV504 Contrast: RV503

### Adjusting method:


 Rotate RV504 and RV503 alternately, and adjust so that the bright/dark sections of the gray scale are displayed correctly. (The bright section should be unsatisfactory till the cross hatch appears vague in the monoscope circle. The dark section should be unsatisfactory till the darkest section and the second darkest section of the gray scale cannot be differentiated.)

## 7-3-9. Horizontal Amplitude, Vertical Amplitude, Focus Check


"7-3-6. Horizontal Amplitude Adjustment" and "7-3-7. Vertical Amplitude Adjustment" should both satisfy the specified values. If not, perform the adjustments from the beginning again. In this case, perform [7-3-8. Brightness, Contrast Adjustments] again. Moreover, check the focus, and if it found to be vague, perform "7-3-3. Focus Adjustment" and "7-3-4. Aberration Adjustment".

## 7-4. ARRANGEMENT DIAGRAM FOR ADJUSTMENT PARTS


### DD-48 BOARD (COMPONENT SIDE)




## VC-122 BOARD (CONDUCTOR SIDE)



## VF-42 BOARD (COMPONENT SIDE)



### VF-42 BOARD (CONDUCTOR SIDE)



# SECTION 8 MECHANICAL SECTION ADJUSTMENTS

### For Mechanical Adjustments

Refer to the separate volume of mechanical adjustment "8 mm Video MECHANICAL ADJUSTMENT MANUAL IV (A Mechanism)" for the adjustments and checks of mechanism section and the mechanical parts replacement. (9-973-199-11) For setting of the track shift mode, however, refer to the following.

### 8-1. SETTING THE TRACK SHIFT MODE


Note: Camera part and video part should have been installed.

### [Setting Method]

- 1) Set the adjustment commander to the HOLD ON side.
- Set page: 1, address: 01 and data: 01, and then release the protector.
- 3) Set page: D and address: 01.
- Set adjustment data to 03 (test mode 3) by PLAY or STOP button.

When HOLD OFF once after the setting and HOLD ON again, the display of the address data will be changed. To set the another mode with shifting, repeat the procedures from 3).

5) Set to the HOLD OFF side in order to set the normal mode.



### 8-2. PREPARATION FOR ADJUSTMENT

- Clean the tape running surfaces (tape guides, drum, capstan shaft, pinch roller.)
- 2) Connect to the oscilloscope. CH1: VS-95 board CN002 pin ③ (PB RF) CH2: VS-95 board CN002 pin ④ (SWP)
- 3) Play back the tracking alignment tape (WR5-1CP: 8-967-995-07).
- 4) Check that the RF waveform of the oscilloscope is flat at both inlet and outlet side. (Refer to Fig. 8-1 and 8-2) If not flat, perform necessary adjustment according to the separate 8 mm Video Mechanical Adjustment IV (A Mechanism).




Fig.8-1.




Fig.8-2.

## CCD-TR303E/TR303EP

# SECTION 9 VIDEO SECTION ADJUSTMENT

When performing adjustments, refer to the layout diagrams for adjustment related parts beginning from page 232.

### 9-1. PREPARATIONS BEFORE ADJUSTMENT

The following adjusting instruments are used for adjusting the video section.

### 9-1-1. Equipments to be used

- 1) TV monitor
- 2) Oscilloscope: 2 phenomena, band 30 MHz or wider, with delay mode. (Use a 10:1 probe unless specified otherwise.)
- 3) Frequency counter
- 4) Pattern generator with video output terminal
- 5) Digital voltmeter
- 6) Audio generator
- 7) Audio level meter
- 8) Audio distortion meter
- 9) Audio attenuater
- 10) Regulated power supply
- 11) Alignment tape

For tracking adjustment (WR5-1CP)

Part Code: 8-967-995-07

For video frequency characteristics adjustment (WR5-6C)

Part Code: 8-967-995-17

For checking operations

(WR5-4CL)<sup>Note 1</sup>

Part Code: 8-967-995-56

(WR5-5CSP)Note 2

Part Code: 8-967-995-47

Note: The following alignment tapes can also be used.

- 1) WR5-3CL (8-967-995-36)
- 2) WR5-4CSP (8-967-995-46)
- 12) Remote control unit for adjustment (J-6082-053-B)
- 13) DD-48 board extension cord (42P, 0.8 mm)

Part Code: J-6082-195-A

14) AU-138 board, Cabinet (R) extension cord (20P, 0.8 mm)

Part Code: J-6082-196-A

15) Mecha deck extension cord (30P, 0.8 mm)

Part Code: J-6082-167-A

### 9-1-2. Connecting the equipments

Unless specified otherwise, connect the measuring instruments as shown in Fig. 9-1 and perform the adjustments.

- Camera/player power switch ······Position of the player
- Connect the adjusting remote control unit to the remote terminal (DD-48 board CN902).




Fig. 9-1.

### 9-1-3. How to Set the REC Mode

- 1. REC key forbidden accept mode cancel
  - Connect the adjustment remote controller to the REMOTE terminal.
  - 2. Turn on the power.
  - Turn on the HOLD switch of the adjustment remote controller.
  - 4. Select the page: 1 address: 00, and set the data to 01. (Protect mode cancel)
  - Select the page: D address: 02, and set the data to 8F [AF]. Note: (REC key forbidden accept mode cancel)
  - Press PAUSE button on the adjustment remote controller. (Write to the non-volatile memory)

The REC key is accepted through the above procedure.

### 2. REC mode setting

- Connect the collector of Q200 on the VS-95 board and GND with a jumper wire. (CCD delay (IC154) active mode setting)
- 2. Turn on the HOLD switch of the adjustment remote controller.
- 3. Select the page: 1 address: A3, and set data to 01.
- 4. Select the page: 1 address: 0B, and set data to C8. (Line input mode setting)
- Turn off the HOLD switch of the adjustment remote controller.
- Press REC buttons of the adjustment remote controller.
- Remove the jumper wire and perform "3. Procedure after completed the adjustment", after completing adjustment.

### 3. Procedure after completed the adjustment

Be sure to return the mode to REC key forbidden accept mode after adjustment.

- Connect the adjustment remoter controller to the REMOTE terminal.
- 2. Turn on the power.
- 3. Turn on HOLD switch of the adjustment remote
- Select the page: 1 address: 00, and set the data to 01. (Protect mode cancel)
- Select the page: D address: 02, and set the data to 8E [AE]. Note 1

(Setting of the REC key forbidden accept mode)

Press PAUSE button on the adjustment remote controller. (Write to the non-volatile memory)

Note 1: No mark: AEP, UK model
[ ]: E, Australian model

### 9-1-4. Precautions upon adjustment

The EVF (Electronic viewfinder) is not required for adjusting the video section.

Remove the following connector when removing the EVF section.

1. VS-95 board CN102 (6 PIN)

The front panel section assembly is required for adjusting the video section. Remove the following connectors when removing the front panel section assembly.

1. AU-138 board CN601 (5 PIN)

The cabinet (R) is required for adjusting the video section. Use the extension cord (J-6082-196-A) when adjusting the video section

### 9-1-5. Set-up during Adjustment

As the video signal obtained from the pattern generator is used as an adjustment signal during electric adjustments, ensure that this video output signal is within the specification. Connect the oscilloscope to pin ② of IC151 on the VS-95 board, and check that the amplitude of the sync signal of the video signal is approximately 0.15V, the amplitude of the video section is approximately 0.35V, the amplitude of the burst signal is approximately 0.15V and flat, and that the level ratio of the burst signal and the [red] signal is 0.30: 0.66. The video signal (color bar) used for electric adjustments is shown in Fig. 9-2.




Fig. 9-2. Color Bar Signal of the Pattern Generator

### 9-1-6. Alignment Tape

The following table lists alignment tapes which are available. Use the tape specified in the signal column for each adjustment. If the type of tape to be used for checking operations is not specified, use whichever type.

	Record	Tape	Tape	Recording	contents	Usage	
Name	-ing mode	type	speed	Video area	PCM area	Usage	
Tracking WR5-1CP	L	MP	SP	CH2: Signal for 1 MHz tape pa	nth adjustment	Tape path adjustment Switching position adjustment	
Video frequency characteristics WR5-6C	L	MP	LP	RF sweep 0 to 10 MHz Marker 1, 3.58, 5.5, 7 MHz		Frequency characteristics adjustment	
Operation check (SP mode) WR5-5CSP	L	МР	SP	Video signal Color bar 4 minutes Monoscope 4 minutes Audio signal (AFM) 400 Hz 60% modulation	Audio signal (PCM)     Monoscope section     20 Hz 20 sec.     400 Hz 20 sec.     14 kHz 20 sec.     Repeated 4 times     1 kHz 4 minutes	Checking operations	
Operation check (LP mode) WR5-4CL	L	MP	LP	Video signal Color bar 4 minutes Monoscope 4 minutes Audio signal (AFM) 400 Hz 60% modulation	,		

Note: Recording mode

L ..... Conventional mode

E ····· hi8 (hi band) mode

Tape type

MP ···· Particle type metal tape

ME····· Evaporated type metal tape

Table 9-1.

Fig. 9-3, shows the 75% color bar signals recorded on the alignment tape.

**Note:** Measure using the video input/output terminal (Terminated at 75  $\Omega$ )




Fig. 9-3. Color Bar Signals of the Alignment Tape

### 9-1-7. Output Level and Impedance

Video output Pin jack

Output signal: 1 Vp-p, 75 unbalanced, sync

negative

Audio outputPin jack

Specified output: -7.5~dBs Output impedance: Below  $2.2~k\Omega$ 


### 9-1-8. Service Mode


### 1. Setting the Service mode

The service mode consists of the adjustment mode which adjusts the EVR and the test mode which displays the condition of the unit.


The unit can be shifted into the test mode and adjustment mode by connecting the adjusting remote control unit (set the HOLD switch to the HOLD side).

### (1) Service LANC memory map






Adjusting remote control unit RM-95 (J-6082-053-B)



Page	Page allocation	Description
0	Not used	
1	Mode Control RAM, I/O	RAM and I/O interface data memory area required for operating the mode controller. Data is not held when the power is turned off because this area is not ROM.
2~4	Mechanical Control RAM, I/O	RAM and I/O memory area of the mechanical controller.
5	Not used	
6~8	Camera Control RAM, I/O	RAM and I/O memory area of the camera control.
9	Not used	
A	Camera Control RAM, I/O	RAM and I/O memory area of the camera control.
B, C	Not used	
D	VTR EE-PROM	ROM memory area of the VTR part. Data of this area is held by EE-PROM when the power is turned off. Releasing protect is required for changing data.
E	Not used	
F	Camera EE-PROM	ROM memory area of the camera part. Data of this area is held by EE•P•ROM when the power is turned off.

# (2) Shifting to the Service Mode Using the Adjusting Remote Control Unit



Command Name	Command Function	Normal LANC command
Page Up	Page +1	Edit Search +
Page Down	Page -1	Edit Search -
Direc Page Set	Sets the specified page	Event Clear
Address Up	Address +1	Fast Forward
Address Down	Address -1	Rewind
Data Up	Data +1	Play Back
Data Down	Data -1	Stop
Store	Write the data to the EE PROM. RAM	Pause

### 2. Types of Self-diagnostic Feature

	MODE	Contents
	Camera adjustment	Refer to Camera Adjustment
TEST	Switching position adjustment	
TE	Battery DOWN adjustment	Refer to each adjustment page
	Video, Audio adjustment	
	Pass Adjustment track shift	When adjusting tape pass, set this mode and shift the tracking.
	Emergency STOP inhibition	Detection of emergency is inhibited. This allows the following items.  • Power is not turned off when the battery is ended.  • SP/LP is not automatically distinguished.  • Emergence is not detected except for TOP/END detection of the TAPE.
	Read of emergence code	The following functions are added to the emergency display function currently in use.  ① The lithium battery is not required because to memorize into EE-PROM is allowed. ② The first emergency and the last emergency are memorized. ③ The mode when the emergency is generated is memorized, in addition to the emergency contents.
ADJUST	Motor single check	Rotating in forward direction, reverse direction, stopping of each motor can be separately controlled.  • Drum motor  • Capstan motor  • Loading motor
	Function switch check	The acceptance of the function switch of the unit can be confirmed by designating an address.  On the contrary, RM-95 can command the substitution for the function switch of the unit.
	Mechanical switch check	The contents of the mechanical switch and the mode switch can be confirmed.
	Sensor check	The following sensor is input by performing A/D converting, and the A/D converted value can be confirmed.  TOP sensor, End sensor, S REEL FG, T REEL FG, Thermistor for SWP correction, DEW sensor.
	Reception contents check of wireless remote control	The received code contents of the remote control code can be confirmed.

### 3. Page D Write Protect

Release/set the page D write protect.

Page 1	Address 00

Data	Function	
00	Normal (Write protect condition)	
01	Write protect release	

## 4. Page F Write Protect

Release/set the page F write protect.

Page 6	Address 00
	•

Data	Function	
10	Normal (Write protect condition)	
01	Write protect release	

### 5. Test Mode Setting

Each type of test mode is set/released. Release the protect (page: 1, address: 00, data: 01), before setting the data.

Page D Address 01
-------------------

Data	Function
00	Normal
01	Test mode 1 Various emergency inhibition and release Drum, capstan, loading motor, reel, tape top, end, DEW SP/LP automatic distinction inhibition, manual switchover 5 minutes pause release inhibition Power off inhibition • release by battery end
02	Test mode 2 1'CH frequency response adjustment (Not used) SP/LP automatic distinction inhibition, manual switchover
03	Test mode 3 Track shift Plays back the track shift Rear lock distinction inhibition during PB SP/LP automatic distinction inhibition, manual switchover
04	Test mode 4 Rear lock mode Rear lock playback is performed SP/LP automatic distinction inhibition, manual switchover
05	Test mode 5 SP/LP automatic distinction inhibition, manual switchover

- This address data will be recorded on the non-volatile memory by pressing the PAUSE button on the adjusting remote control unit. Take note, as when this happens, the test mode will not be released even if the main power is turned off (6.3 Vdc).
- Be sure to return the data of this address data to 00 after completing adjustments/repairs.

### 6. Emergency code

Troubles (errors) can be checked.

Page D	Address 06

First emergency code

·····The first error code generated

Page D Ad	ldress 07

Last emergency code

····· The last error code generated (this data will be modified each time an error occurs.)

- Be sure to rewrite the data of addresses 06 and 07 to 00 after completing repairs/adjustments.
- When rewriting data, be sure to press the PAUSE button of the remote control unit after resetting the data.

Code	Error condition
00	No error
01	Loading motor error
02	Reel error during unloading
03	Other reel errors
04	Capstan error
05	DRUM FG error during drum start up
06	DRUM PG error during drum start up
07	DRUM FG error during drum regular condition
08	DRUM PG error during drum regular condition
09	DRUM Phase error during drum regular

### 7. Emergency mode

The operation mode during an error outbreak can be checked.

Page D	Address 08
--------	------------

First emergency mode

·····The operation mode when the first error is generated

Page D	Address 09

Last emergency mode

·····The operation mode when the last error is generated (This data will be modified each time an error occurs.)

- Be sure to rewrite the data of addresses 08 and 09 to 00 after completing repairs/adjustments.
- When rewriting data, be sure to press the PAUSE button of the remote control unit after setting the data.
- Addresses 08 and 09 of page 0 and addresses 08 and 09 of page D have the same functions.

Code	Error condition
00	BEFOR INITIALIZE
01	EJECTED
02	NORMAL STOP
03	FF
04	NORMAL REC
06	NORMAL PB
07	PB PAUSE
12	LOADING
14	REC PAUSE
26	X1
27	1/5 SLOW
31	UNLOADING
36	-X1
37	-1/5 SLOW
46	CUE
47	1/10 SLOW
56	REVIEW
57	-1/10 SLOW
62	STOP TAPE END
66	X2
67	FRAME
72	STOP TAPE TOP
76	-X2
77	-FRAME
83	REWIND
85	REC REVIEW(+)
95	REC REVIEW(-)
A2	EMERGENCY STOP
A5	EDIT SEARCH(+)
B1	EMERGENCY UNLOADING
B2	STOP EMERGENCY 1
B5	EDIT SEARCH(-)
C2	STOP EMERGENCY 2
E2	STOP NO CASSETTE
F5	EDIT PAUSE

### 8. Bit value Discrimination

It is necessary to discriminate the bit value by the adjusting remote control unit display data for the following items. Discriminate if the bit value is "1" or "0" using the following table.





Discriminates the bit 7 to bit 4 value

	Remote		Bit Value					
	Control Unit Display	bit 3 or bit 7	bit 2 or bit 6	bit 1 or bit 5	bit 0 or bit 4			
	0	0	0	0	0			
	1	0	0	0	1			
	2	0	0	1	0			
	3	0	0	1	1			
	4	0	1	0	0			
	5	0	1	0	1			
	6	0	1	1	0			
	7	0	1	1	1			
$\bigoplus$	8	1	0	0	0			
	9	1	0	0	1			
	A(8)	1	0	1	0			
	B(b)	1	0	1	1			
	C(c)	1	1	0	0			
	D(d)	1	1	0	1			
₿→	E(ξ)	1	1	1	0			
	F(F)	1	1	1	1			

(Example) When the remote control unit display data is "8E", the bit values of bit 7 to bit 4 can be discriminated from column (A), and that of bit 3 to bit 0 can be discriminated from column (B).

### 9. Check of Tape Distinction Switch, etc.






Page 1		Address 42					
Bit7	Bit6	Bit5	Bit4	Bit3	Bit2	Bit1	Bit0
						DEW	
<u> </u>			<u> </u>	A	<del></del>		"0"=Dew outb "1"=Others

### 10. Mode Switch Check

The mode switch position (mechanical section condition) can be checked.

Pag	2		Addre	ss E9						
	Bit7	Bit6	Bit5 Bit4		4	Bit3	Bit2	Bit1	Bit0	
	MSW 0	MSW 1	MSW 2 CC DOV		OWN					
			•	POSITION			FUNCTION	ON		CC DOWN
	1	1	1	BL	Interva	al of each position				
	0	1	1	END	FULL	L END processing (T side lock removal)				1
	0	0	1	EJECT	Casset	ssette compartment ejection				1
	1	0	1	USE	EJECT	TED (Unskate end)				1
	0	0	1	LOAD	LOAD	ADING (Skate in)			0	
	1	0	0	READY	NORM	IAL STOP p	osition			0
	1	1	0	TURN	OFF of	of pinch roller only with PB ↔ REV (oscillating position)			g position)	0
	0	1	0	RP	PB, RI	REC, RVS, REV, REW				0
	0	0	0	FF	FF/CU	E				0



### 11. Mechanism Control A/D Port Input Voltage Check

Page 4	Address 14
--------	------------

### Checking method:

- 1) Set data: 02 to page: 4, address: 0E. (A/D conversion processing active)
- Set the data in the following table to page: 4, address: 13, and select the A/D port to be displayed.

Data	A/D Port
00	Pin @: ANO (T REEL FG)
01	Pin (1): AN1 (S REEL FG)
02	Pin @: AN2 (ATF ERROR)
03	Pin @: AN3 (BATT SENS)
04	Pin 🐯 : AN4 (DEW)

### 3) Check the data of page: 4, address: 14.

Adjusting Remote Control Unit Display Data	A/D Port Input Voltage	
FF to 00	Approx. 5 Vdc to 0 Vdc	

### 12. Tape Top/End Sensor Condition Check

ſ	Page 4	Address 0A

### Checking method:

- 1) Set data: 10 to page: 4, address: 0E.
  - (Tape top/end sensor condition sampling processing active)

Tape Top/End Sensor

Condition

2) Check the data of page: 4, address: 0A.

**Adjusting Remote Control** 

**Unit Display Data** 

0 0	Tape present (Middle of tape)	
0 1	Tape end	
1 0	Tape top	
1 1	No tape	
Tape top sense	dition (Not receiving light)	

### 13. Battery Voltage Check

Page 4	Address 10

Adjusting Remote Control Unit Display Data	Battery Voltage	
FF	Approx. 10 Vdc	
F0	Approx. 9.4Vdc	
E0	Approx. 8.8Vdc	
D0	Approx. 8.2Vdc	
C0	Approx. 7.5Vdc	
В0	Approx. 6.9Vdc	
A0	Approx. 6.3Vdc	
90	Approx. 5.6Vdc	
80	Approx. 5.0Vdc	

# 14. Individual Operations of the Drum, Capstan, and Loading Motor

Page 4	Address 11

- 1) Adjust the mechanical section to the loading completion condition.
- 2) Release the protect.
  - Page: 1, address: 00, data: 01
- 3) Set data: 01 to page: 4, address: 0E.(Control permission from the adjusting remote control unit of the motor)
- 4) By setting the data in the following table to page: 4, address: 11, the corresponding motors can be operated individually.
- After checking the operations, turn off the main power (6.3 Vdc).

Data	Operation
00	Normal
02	Drum forward rotation
04	Drum reverse rotation
06	Capstan forward rotation
08	Capstan reverse rotation
0A	Loading motor forward rotation
0C	Loading motor reverse rotation
01	
03	
05	
07	All motors ston
09	All motors stop
0B	
0D	
0F	

### 15. Mode control micro processor key matrix check

The key input can be checked.

Page 1		Address 68	Address 68~6D					
	Bit7	Bit6 (K IN 6)	Bit5 (K IN 5)	Bit4 (K IN 4)	Bit3 (K IN 3)	Bit2 (K IN 2)	Bit1 (K IN 1)	Bit0 (K IN 0)
Address 68 (K OUT 0)		LENS COVER OPEN (MF-191 S973)	VTR POWER (VK-27 S977)	EDIT SEARCH (CUE) (VK-27 S981)	PAUSE (VK-27 S984)	EDIT SEARCH (+) (VK-27 S981)	EJECT (DD-48 S901)	
Address 69 (K OUT 1)		BUZZER ON/OFF (ED-35 S986)	CAMERA POWER (VK-27 S977 (SW-205 S519)	FF (VK-27 S983)	PLAY (VK-27 S980)	REW (VK-27 S979)	STOP (VK-27 S976)	
Address 6A (K OUT 2)		NIGHT (CF-32 S997)			EDIT SEARCH (REV) (VK-27 S978)	EDIT SEARCH (-) (VK-27 S978)	COUNTER RESET (CF-32 S995)	SP/LP EDIT ON/OFF (ED-35 S990)
Address 6B (K OUT 3)		PORTREIT (CF-32 S997)			TIME (CF-32 S996)	DATE (CF-32 S993)		
Address 6C (K OUT 4)		SPORTS (CF-32 S997)		AUTO FOCUS ON/OFF (MF-191 S971)				
Address 6D (K OUT 5)		HIGH SPEED SHUTTER (CF-32 S997)	AREA (ED-35 S989)	DST or SUMMER TIME (ED-35 S987)		FADER (CF-32 S991)	START/ STOP (SW-205 S520)	REMOTE COMMANDER (ED-35 S988)

<sup>&</sup>quot;1"=key switch ON

# 16. Wireless Remote Control Unit Reception Content Check

Page 1	Address 1E			
Wireless remote control	unit key pressed	Data		
None		FF		

Wholess telliote collider and key proceed	2000
None	FF
TELE	9A
WIDE	9B
Start/stop	99
Rewind	1B
Fast forward	1C
Stop	18
Playback	1A
Data screen	5A
Pause	19
SLOW	23

<sup>&</sup>quot;0"=key switch OFF

### 17. EDIT Switch, Remote Commander Switch Check

Pag	ge 1		Address 0A					
	Bit7	Bit6	Bit5	Bit4	Bit3	Bit2	Bit1	Bit0
	REC MODE (SP/LP)	REMOTE COMMANDER		EDIT				
			"1"=OFF "0"=ON		"1"=EDIT ON			
		'1"=LP '0"=SP						

# 18. White Balance Mode and Focus Mode Display/Switchover

1	Page 1	Address 9A
---	--------	------------

The mode can be switched when the data of page: 1, address: A3 is set to 04.

Data	White Balance Mode
* 1	INDOOR
* 2	OUTDOOR
* 3	HOLD
<b>*</b> 6	AUTO

Data	Focus Mode
0 *	Manual
1 *	Automatic

\*:0 to F

### 19. LCD, LED Check, etc.

Page 1	Address A3

Data	Mode	
00	Normal	
01	Key input prohibited	
04	Camera function renewal prohibited	

### 20. Page D Address List

Note 1: The adjustment data initial value is the data to be input before performing video section adjustment (page D), when the page D data has been erased due to some cause

**Note 2:** The data listed in the adjustment data memo column are the fixed data.

Check that these data have not been accidentally rewritten, after completing adjustments.

\*1 No mark : AEP, UK model
[ ]: E, Australian model

		Function		Adjustment data	
Address	Name	[ ] Indicate the adjustment voltage output terminal	Initial value	Memo column	
00	Category code	Not used			
01	Test mode		00	00	
02	Destination flag		8E[AE]*1	8E[AE]*1	
03	BATT END	Battery end adjustment	8C		
04	SW POSITION	SW POSITION adjustment	00		
05	SW POSITION	SW POSITION adjustment	0A		
06	EMERGENCY code (FIRST)		00	00	
07	EMERGENCY code (LAST)	Error code and mode are memorized.	00	00	
08	EMERGENCY mode (FIRST)	Rewrite the data of these addresses to 00 after repairs/adjustments	00	00	
09	EMERGENCY mode (LAST)		00	00	
0A	SR DATA (MP Normal SP)	CXA1207 serial data	24	24	
0B	SR DATA (MP Normal LP)	CXA1207 serial data	16	16	
0C	SR DATA (ME Hi8 SP)	CXA1207 serial data	24	24	
0D	SR DATA (ME Hi8 LP)	CXA1207 serial data	16	16	
0E	SR DATA (ME Normal SP)	CXA1207 serial data	24	24	
0F	SR DATA (ME Normal LP)	CXA1207 serial data	16	16	
10	SR DATA (MP Hi8 SP)	CXA1207 serial data	24	24	
11	SR DATA (MP Hi8 LP)	CXA1207 serial data	16	16	
12	SR DATA (EDIT ON Normal)	CXA1207 serial data	16	16	
13	SR DATA (EDIT ON Hi8)	CXA1207 serial data	16	16	
14	CAM TITLE BLU R-Y	Camera titler color adjustment [Blue]. Not used			
15	CAM TITLE BLU B-Y	Camera titler color adjustment [Blue]. Not used			
16	CAM TITLE GRN R-Y	Camera titler color adjustment [Green]. Not used			
17	CAM TITLE GRN B-Y	Camera titler color adjustment [Green]. Not used			
18	CAM TITLE CYN R-Y	Camera titler color adjustment [Light blue]. Not used			
19	CAM TITLE CYN B-Y	Camera titler color adjustment [Light blue]. Not used			
1A	CAM TITLE RED R-Y	Camera titler color adjustment [Red]. Not used			
1B	CAM TITLE RED B-Y	Camera titler color adjustment [Red]. Not used			
1C	CAM TITLE VIO R-Y	Camera titler color adjustment [Violet]. Not used			
1D	CAM TITLE VIO B-Y	Camera titler color adjustment [Violet]. Not used			
1E	CAM TITLE YEL R-Y	Camera titler color adjustment [Yellow]. Not used	1		
1F	CAM TITLE YEL B-Y	Camera titler color adjustment [Yellow]. Not used			
20	Permission plug		04	04	
21	Adjustment plug	FORCED VTR ON, CAM ON etc  DATA MODE  01 FORCED CAMERA POWER ON 02 FORCED VTR POWER ON	00	00	
22~29		Not used			

			Adjustn	nent data
Address	Name	Function [ ] indicate the adjustment voltage output terminal	Initial value	Memo column
2A	SLOW ADJ (FOWARD)		00	00
2B	SLOW ADJ (REVERSE)		00	00
2C	STILL ADJ		00	00
2D	BATT REMAIN LEVEL 1	Amount of remaining battery 1	A0	
2E	BATT REMAIN LEVEL 2	Amount of remaining battery 2	99	
2F	BATT REMAIN LEVEL 3	Amount of remaining battery 3	94	
30~42		Not used		
43	1-ch M.T NORMAL	1 ch playback frequency characteristic adjustment [IC158 ②]	CO	
44				
45	2-ch M.T NORMAL	2 ch playback frequency characteristic adjustment [IC158 ③]	C0	
46	REC C RF (EE)	REC C RF level adjustment (EE) [IC156 10]	B8	
47	REC C RF (PB)	REC C RF level adjustment (PB) [IC156 10]	00	00
48	RF CONT (ME)	ATF RF level (ME) [IC158 ⑤]	64	64
49	RF CONT (MP)	ATF RF level (MP) [IC158 ⑤]	70	70
4A	EE LEVEL	EE level adjustment [IC156 (5)]	70	70
4B		Not used		
4C	COMB ADJ	Chroma comb filter adjustment [IC156 ③]	A8	
4D	SR-IR	IR adjustment [IC156 ②]	AE	
4E	Y-FM CARRIER (Hi8)			
4F	Y-FM CARRIER (NORMAL)	Y-FM carrier frequency adjustment [IC156 ⑤]	A8	
50	Y-FM DEVIATION (Hi8)			
51	Y-FM DEVIATION (NORMAL)	Y-FM deviation adjustment [IC156 ®]	95	
52	REC Y LEVEL (EE Hi8 ME)			
53	REC Y LEVEL (EE Hi8 MP)			
54	REC Y LEVEL (EE NOR ME)	REC Y recording current adjustment (ME) [IC156 ⑦]	95	
55	REC Y LEVEL (EE NOR MP)	REC Y recording current adjustment (MP) [IC156 ⑦]	95	
56	REC Y LEVEL (PB)	Playback REC Y level [IC156 ⑦]	00	00
57	PB Y LEVEL (EE)	EE PB Y level [IC158 (6)]	00	00
58	PB Y LEVEL (Hi8)			
59	PB Y LEVEL (NORMAL)	Normal PB Y level adjustment [IC158 (15)]	В0	
5A	EMPHASIS INPUT LEVEL	EE emphasis input level adjustment [IC156 4]	A5	
5B	PB LINE LEVEL	Playback emphasis input level adjustment [IC156 4]	AF	
5C~79		Not used		
7A	1.5 IR	1.5 MHz IR adjustment [IC158 ⑥]	A0	
7B	1.5 DEV	1.5 MHz deviation adjustment [IC158 ⑦]	A0	
7C~FF		Not used		

Table 9-2 (2)

### 9-2. POWER SYSTEM ADJUSTMENTS

### 1. Oscillator Frequency Check (DD-48 board)

Mode	Camera record
Subject	Arbitrary
Measurement Point	Q903 collector
Measuring Instrument	Frequency counter
Specified Value	510 ± 35 kHz

### Adjusting method:

1) Check that the oscillator frequency satisfies the specified value.

### 2. Power Voltage Check (DD-48 board)

Mode	Camera record		
Subject	Arbitrary		
Measuring Instrument	Digital voltmeter		
EVF 5V check			
Measurement Point	Pin ① of CN901		
Specified Value	4.93 ± 0.15 Vdc		
D5V check			
Measurement Point	Pins ⑤ and ⑧ of CN901		
Specified Value	4.92 ± 0.15 Vdc		
D4V check			
Measurement Point	Pin 4 of CN901		
Specified Value	3.98 ± 0.15 Vdc		
VID 5V check			
Measurement Point	Pins ①, ② of CN901		
Specified Value	4.90 ± 0.10 Vdc		
RP 5V check			
Measurement Point	Pin ② of CN901		
Specified Value	4.89 ± 0.15 Vdc		
AU5V check			
Measurement Point	Pin (19) of CN901		
Specified Value	4.90 ± 0.15 Vdc		
CAM5V check			
Measurement Point	Pins ⑦ and ⑩ of CN901		
Specified Value	4.86 + 0.15 - 0.11 Vdc		
CAM15V check			
Measurement Point	Pin ② of CN901		
Specified Value	15.05 ± 0.4 Vdc		
CAM -9V check			
Measurement Point	Pin ® of CN901		
Specified Value	-8.5 ± 0.4 Vdc		

### 9-3. SYSTEM CONTROL SYSTEM ADJUSTMENTS

### 1. Page D Initial Value Input

If the page D data has been erased due to some cause, input the page D initial value before performing adjustments. For details on the initial value, refer to "Page D address list" in "9-1-8. Service Mode".

Mode	E-E
Signal	Arbitrary
Adjustment Page	D
Adjustment Address	00 to 7D

### Input method:

- 1) Release the write protect. Page: 1, address: 00, data: 01
- 2) Select page D, and input the initial value to each address. (After setting the data (initial value), be sure to press the PAUSE button of the adjusting remote control unit before changing the address.)

### 2. Battery End Adjustment

Mode	Camera record	
Signal	Arbitrary	
Measurement Point	LCD display of the adjusting remote control unit	
Measuring Instrument		
Adjustment Page	D	
Specified Value	03 (BATT END) 2D (BATT REMAIN LEVEL 1) 2E (BATT REMAIN LEVEL 2) 2F (BATT REMAIN LEVEL 3)	

### Connection:

1) Connect the regulated power supply and the digital voltmeter as shown in Fig. 9-4.




Fig. 9-4.

### Adjusting method:

- 1) Adjust the output voltage of the regulated power supply so that the digital voltmeter display is  $6.3 \pm 0.1$  Vdc.
- 2) Release the protect.
  - Page: 1, address: 00, data: 01
- 3) Set data: 01 to page: D, address: 01. (Test mode 1 setting)
- 4) Set to the camera recording mode.
- 5) Adjust the output voltage of the regulated power supply so that the digital voltmeter display is 5.50  $\pm$  0.01 Vdc.
- 6) Select page: 4, address: 10, read the adjusting remote control unit display data, and set to DEND.
- Set data DEND to page: D, address: 03, and press the PAUSE button of the adjusting remote control unit.
- Convert DEND to decimal to obtain DEND'. (Refer to Table 7-6. "Hexadecimal notation – decimal notation conversion table")
- Obtain the adjustment data (decimal) by following formula (decimal notation calculation), convert to hexadecimal and enter the data into each adjustment address.

Address: 2D D2D'=DEND'+18

Address: 2E D2E'=DEND'+14

Address: 2F D2F'=DEND'+8

**Note:** After setting the data, be sure to press the PAUSE button of the adjusting remote control unit before changing the address.

- 10) Set data: 00 to page: D, address: 01, and press the PAUSE button of the adjusting remote control unit. (Test mode 1 release)
- 11) Perform "Battery Down Check".

### 3. Battery Down Check

Mode	Camera record
Subject	Arbitrary

### Connection

1) Connect the regulated power supply and the digital voltmeter as shown in Fig. 9-4.

### Checking method:

Remove the adjusting remote control unit, and perform the following check. If the check is not satisfied, perform from the beginning again.

- 1) Adjust the output voltage of the regulated power supply so that the digital voltmeter display becomes  $6.3 \pm 0.1$  Vdc.
- 2) Set to the camera recording mode.
- 3) Decrease the output voltage of the regulated power supply so that the digital voltmeter display becomes  $5.70 \pm 0.01$  Vdc.
- 4) Check that the \(\Omega\) mark on the EVF (viewfinder) display is not lighted up. (TALLY lamp lights up).
- 5) Decrease the the output voltage of the regulated power supply so that the digital voltmeter display becomes 5.58 ± 0.01 Vdc.
- 6) Check that the 🖾 mark and the TALLY lamp on the EVF display on the EVF display blinks every second.
- 7) Decrease the the output voltage of the regulated power supply so that the digital voltmeter display becomes  $5.42 \pm 0.01 \, \text{Vdc}$ .
- 8) Check that the 🖎 mark and the TALLY lamp on the EVF display are blinking faster, the VTR stops and the power supply turns off.

### 9-4. SERVO SYSTEM ADJUSTMENTS

### 1. Switching Position Adjustment (VS-95 board)

Mode	Playback
Signal	Alignment tape: For tracking adjustment (WR5-1CP)
Measurement Point	CH1: Pin (4) of CN002 (RF SWP) CH2: Pin (3) of CN002 (PB RF)
Measuring Instrument	Oscilloscope
Adjustment Page	D
Adjustment Address	04 (SW POSITION) 05 (SW POSITION)
Specified Value	t <sub>1</sub> =0 ± 10 μsec

### Adjusting method:

1) Release the protect.

Page: 1, address: 00, data: 01

- 2) Set data: 0A to page: D, address: 05.
- Change the data of page: D, address: 05 and minimize "t1".
   (Coarse adjustment)
- 4) Press the PAUSE button of the remote control unit.
- Change the data of page: D, address: 04, and adjust so that the switching position (t1) becomes the specified value. (Fine adjustment)
- Press the PAUSE button of the adjusting remote control unit.




Fig. 9-5.

### 9-5. VIDEO ADJUSTMENTS

The adjustments of the video system must be performed according to the following adjustment procedure.

The color video signal supplied from the pattern generator is used as the video input signal for adjusting the video system in recording mode. Check that the sync signal and the color burst signal satisfy the specification specified during the adjustment set-up shown in Fig. 9-2.

### [Adjusting procedure]

- 1) Playback frequency characteristic adjustment
- 2) Flying erase check
- 3) VXO oscillation frequency check
- 4) EE level adjustment
- 5) IR adjustment
- 6) Y/C separation adjustment
- 7) Emphasis input level adjustment
- 8) PB Y level adjustment
- 9) PB LINE OUT level adjustment
- 10) Y FM carrier frequency adjustment
- 11) Y FM deviation adjustment
- 12) Chroma emphasis fo adjustment
- 13) REC Y level adjustment
- 14) REC C level adjustment
- 15) REC ATF level check
- 16) REC AFM level check

# 1. Playback Frequency Characteristic Adjustment (VS-95 board)

Note 1: The adjusting element for CH2 is shown in parentheses

Mode	Playback
Signal	Alignment tape: For frequency characteristic adjustment (WR5-6C)
Measurement Point	CH1: Pin ③ of CN002 EXT TRIG: Pin ④ of CN002
Measuring Instrument	Oscilloscope TRIG SLOPE: +, [–]
Adjustment Page	D
Adjustment Address	43 (MT 1CH) [45 (MT 2CH)]
Specified Value	3.58 MHz level: 5.5 MHz level= 4: (3 ± 0.3)

### Adjusting method:

- 1) Release the protect.
  - Page: 1, address: 00, data: 01
- After memorizing the data of page: D, address: 05, set data:
   10.
- 3) Press the PAUSE button of the adjusting remote control unit.
- 4) Change the data of address: 43 [45] of page D, and adjust the level ratio of 3.58 MHz and 5.5 MHz of PB RF output waveform to the specified value.
  - Note 2: After each address adjustment, be sure to press the PAUSE button of the adjusting remote control unit and memorize the data.
- 5) Set the data memorized at step 2) to page: D, address: 05, and press the PAUSE button of the adjusting remote control unit.




Fig. 9-6.

### 2. Flying Erase Check (VS-95 board)

Mode	Record
Signal	Arbitrary
Measurement Point	Pin ② of W001 (FE (X))
Measuring Instrument	Oscilloscope and frequency counter
Specified Value	Frequency: approx. 7.5 MHz Voltage: Above 1.5 Vp-p

Note: Use a MP type tape.

### Checking method:

1) Check that the oscillation frequency is approx. 7.5 MHz and that the oscillation voltage is above 1.5 Vp-p.




Fig. 9-7.

### 3. VXO Oscillation Frequency Check (VS-95 board)

Mode	STOP
Signal	Color bar
Measurement Point	Pin ② of IC152
Measuring Instrument	Frequency counter
Specified Value	4433618 ± 70 Hz

Note: Connect the frequency counter via a high impedance (approximately  $10~M\Omega$ ) and low capacity (below 10~pF) buffer.

### Adjusting method:

1) Check that the oscillation frequency of pin 2 of IC152 is 4433618  $\pm$  70 Hz.




Fig. 9-8.

### 4. EE Level Adjustment (VS-95 board)

Mode	E-E
Signal	Color bar
Measurement Point	Pin ② of CN101 (VIDEO OUT)Note
Measuring Instrument	Oscilloscope
Adjustment Page	D
Adjustment Address	4A (EE LEVEL)
Specified Value	A=1.00 ± 0.025V

Note: Terminate pin ② of CN101 at 75  $\Omega$  . After completing adjustments, remove the 75  $\Omega$  resistor.

### Adjusting method:

1) Release the protect.

Page: 1, address: 00, data: 01

- Change the data of page: D, address: 4A, and adjust so that the Y signal level (A) becomes the specified value.
- Press the PAUSE button of the adjusting remote control unit.




Fig. 9-9.

### 5. IR Adjustment (VS-95 board)

Mode	E-E
Signal	Color bar
Measurement Point	Pin ⑦ of IC151 (Y COMB OUT)
Measuring Instrument	Oscilloscope
Adjustment Page	D
Adjustment Address	4D (SR IR)
Specified Value	Residual chroma component (A) is minimum (below 80 mVp-p)

### Connection


1) Connect pin (4) of IC151 (VREF: 3.5 Vdc) or pin (2) of IC159 to pin (5) of IC151 with a jumper wire.

### Adjusting method:

1) Release the protect.

Page: 1, address: 00, data: 01

- 2) Change the data of page: D, address: 4D, and adjust so that the residual chroma component (A) becomes minimum.
- Press the PAUSE button of the adjusting remote control unit.



# 6. Y/C Separation Adjustment (VS-95 board)

Mode	E-E
Signal	Color bar
Measurement Point	Pin (1) of IC151 (C+CD)
Adjusting Element	Oscilloscope
Measuring Instrument	RV051 (Phase)
Adjustment Page	D
Adjustment Address	4C (Y/C SEP DL LEVEL)
Specified Value	Residual chroma component (A) is minimum.

#### Adjusting method:

- 1) Release the protect. Page: 1, address: 00, data: 01
- 2) Change the data of page: D, address: 4C, and adjust the residual chroma component to minimum.
- 3) Adjust RV051 so that the residual chroma component (A) becomes minimum.
- 5) Press the PAUSE button of the adjusting remote control unit.





Fig. 9-11.

# 7. Emphasis input Level Adjustment (VS-95 board)

Mode	E-E
Signal	Color bar without burst signal
Measurement Point	Pin ③ of IC155 (or Pin ③ of IC151)
Measuring Instrument	Oscilloscope
Adjustment Page	D
Adjustment Address	5A (EMPHASIS INPUT LEVEL)
Specified Value	A=0.50 ± 0.025V

# Adjusting method:

- 1) Release the protect. Page: 1, address: 00, data: 01
- 2) Change the data of page: D, address: 5A, and adjust so that the Y signal level (A) becomes the specified value.
- Press the PAUSE button of the adjusting remote control unit.



# 8. PB Y Level Adjustment (VS-95 board)

Mode	Playback
Signal	Alignment tape: For checking operations (WR5-5CSP) Color bar section
Measurement Point	Pin @ of IC151
Measuring Instrument	Oscilloscope
Adjustment Page	D
Adjustment Address	Normal mode     59 (NORMAL PB Y LEVEL)
Specified Value	A=0.50 ± 0.025V

#### Adjusting method:

1) Release the protect.

Page: 1, address: 00, data: 01

- Playback the color bar section of the normal mode alignment tape (WR5-5CSP).
- 3) Change the data of page: D, address: 59, and adjust so that the Y signal level (A) becomes the specified value.
- Press the PAUSE button of the adjusting remote control unit.




Fig. 9-13.

#### 9. PB LINE OUT Level Adjustment

Mode	Playback
Signal	Alignment tape: For checking operations (WR5-5CSP) Color bar section
Measurement Point	Video output terminal (terminated at 75 $\Omega$ )
Measuring Instrument	Oscilloscope
Adjustment Page	D
Adjustment Address	5B (PB LINE LEVEL)
Specified Value	A=1.0 ± 0.025V

# Adjusting method:

1) Release the protect.

Page: 1, address: 00, data: 01

- 2) Change the data of page: D, address: 5B, and adjust so that the video signal level (A) becomes the specified value.
- Press the PAUSE button of the adjusting remote control unit.




Fig. 9-14.


# 10. Y FM Carrier Frequency Adjustment (VS-95 board)

Mode	E-E
Signal	No signal
Measurement Point	Pin ⑤ of IC003 (REC Y RF OUT)
Measuring Instrument	Frequency counter
Adjustment Page	D
Adjustment Address	4F (Y FM CARRIER)
Specified Value	4.38 ± 0.04 MHz

#### Adjusting method:

- 1) Release the protect.
  - Page: 1, address: 00, data: 01
- 2) Change the data of page: D, address: 4F, and adjust so that the Y FM carrier frequency becomes the specified value.
- 3) Press the PAUSE button of the adjusting remote control unit.
- 4) Perform "Deviation Adjustment".

#### Pin ⑤ of IC003 waveform



#### 11. Deviation Adjustment (VS-95 board)

Mode	Record and playback
Signal	Color bar
Measurement Point	Pin ② of IC151
Measuring Instrument	Oscilloscope
Adjustment Page	D
Adjustment Address	51 (Y FM DEVIATION)
Specified Value	A=0.50 ± 0.025V

**Note:** Check that "Emphasis Input Level Adjustment", "PB Y Level Adjustment" and "Y FM Carrier Frequency Adjustment" have been completed.

#### Adjusting method:

- 1) Release the protect.
  - Page: 1, address: 00, data: 01
- 2) Record the color bar signal.
- 3) Playback the recorded signal.
- 4) Check the playback signal level (A). Specification:  $A=0.50 \pm 0.025V$
- 5) If the specification is not satisfied, change the data of page: D, address: 51, and repeat steps 2) to 4).

	Playback signal level	Changing the data
ı	When smaller than the specified value	Increase
ı	When bigger than the specified value	Decrease

 Press the PAUSE button of the adjusting remote control unit.




Fig. 9-16.

# 12. Chroma Emphasis fo Adjustment (VS-95 board)

Mode	E-E
Signal	Color bar
Measurement Point	Pin 2 of IC152
Measuring Instrument	Oscilloscope
Adjustment Element	FL153
Specified Value	Minimum fo component


# Connection:

1) Connect pin  $\mathfrak{P}$  of IC152 to GND with a 3.3 k $\Omega$  resistor (1-249-423-11).

#### Adjusting method

1) Adjust FL153 so that the amplitude of the latter section of the chroma signal (yellow section) becomes minimum.

Minimize the amplitude of the latter section of the yellow section.



#### 13. REC Y Level Adjustment (VS-95 board)

Mode	Record (SP)
Signal	No signal
Measurement Point	Pin ⑤ of IC003
Measuring Instrument	Oscilloscope
Adjustment Page	D
Adjustment Address	55 (REC Y LEVEL EE NOR MP) 54 (REC Y LEVEL EE NOR ME)
Specified Value	A=205 ± 5 mVp-p

**Note:** Use a MP type tape.

#### Adjusting method:

- 1) Release the protect.
  - Page: 1, address: 00, data: 01
- 2) Change the data of page: D, address: 55, and adjust so that the Y signal level (A) becomes the specified value.
- 3) Press the PAUSE button of the adjusting remote control
- 4) Set the data of page: D, address: 55 to page: D, address: 54.
- Press the PAUSE button of the adjusting remote control unit.




Fig. 9-18.

# 14. REC C Level Adjustment (VS-95 board)

Mode	Record (SP)
Signal	Color bar
Measurement Point	Pin ③ of IC003
Measuring Instrument	Oscilloscope
Adjustment Page	D
Adjustment Address	46 (REC C RF (EE))
Specified Value	A=110 ± 10 mVp-p

Note: Use a MP type tape.


Adjusting method:

1) Release the protect.

Page: 1, address: 00, data: 01

2) Change the data of page: D, address: 46, and adjust so that the REC C level (A) becomes the specified value.

3) Press the PAUSE button of the adjusting remote control unit.



# 15. REC ATF Level Check (VS-95 board)

Mode	Record (SP)
Signal	No signal
Measurement Point	Pin 29 of IC001 (REC 1CH)
Measuring Instrument	Oscilloscope
Specified Value	A=8 ± 2 mVp-p

Note: Use a MP type tape.

Connection:

1) Remove the AU-138 board CN602.

Checking method:


1) Release the protect.

Page: 1, address: 00, data: 01

2) To reduce the REC Y signal, set data: 00 to page: D, address: 55.

Note: Don't press the PAUSE button of the adjusting { remote control unit.

- 3) Check that the REC ATF signal level (A) satisfies the specified value.
- 4) Turn the main power supply (6.3V) off.



Center of the luminance line width

Fig. 9-20.

#### 16. REC AFM Level Check (VS-95 board)

Mode	Record (SP)
Signal	No signal
Measurement Point	Pin 29 of IC001 (REC 1CH)
Measuring Instrument	Oscilloscope
Specified Value	A=9 ± 2 mVp-p

Note: Use a MP type tape.

#### Connection:

1) Connect Pin 9 of IC404 and GND with a 0.01  $\mu$ F capacitor (1-101-004-00).

#### Checking method:

1) Release the protect.

Page: 1, address: 00, data: 01

To reduce the REC Y signal, set data: 00 to page: D, address: 55.

**Note:** Don't press the PAUSE button of the adjusting remote control unit.

- Check that the REC AFM signal level (A) satisfies the specified value.
- 4) Turn the main power supply (6.3V) off.




Fig. 9-21.

#### 9-6. AUDIO SYSTEM ADJUSTMENT

 Perform the adjustment using the color bar signal as a video signal input.

# [Connecting the measuring instruments for the audio]

Connect the audio system measuring instruments besides the video system measuring instruments as shown in Fig. 9-22, and perform adjustments with the power switch [player] position.




Fig. 9-22.

### [Adjustment Procedure]

- 1) E-E output level check
- 2) IR adjustment
- 3) Deviation adjustment
- 4) Carrier frequency check
- 5) Recording level check
- 6) Overall level characteristics, distortion check
- 7) Overall noise level check

# 1. E-E Output Level Check (AU-138 board)

Mode	Record
Signal	400 Hz, -36.1 dBs, pin ① of CN601
Measurement Point	Audio output terminal
Measuring Instrument	Audio level meter
Specified Value	$-7.5 \pm 2 \text{ dBs}$

#### Checking method:

1) Check that the 400 Hz signal level satisfies the specified value.

# 2. IR Adjustment (AU-138 board)

Mode	Playback
Signal	Alignment tape: For checking operations (WR5-5CSP)
Measurement Point	+: Pin ⑥ of IC601 -: Pin ⑭ of IC601 (C629 ⊕)
Measuring Instrument	Digital voltmeter
Adjustment Page	D
Adjustment Address	7A (1.5 IR)
Specified Value	The DC voltage difference between pins (4) and (6) is $0 \pm 10$ mVdc

#### Adjusting method:

1) Release the protect.

Page: 1, address: 00, data: 01

- 2) Change the data of page: D, address: 7A and adjust so that the DC voltage becomes  $0 \pm 10 \text{ mVdc}$ .
- 3) Press the PAUSE button of the adjusting remote control unit.

#### 3. Deviation Adjustment

Mode	Playback
Signal	Alignment tape: For checking the operation (WR5-5CSP)
Measurement Point	Audio output terminal
Measuring Instrument	Oscilloscope
Adjustment Page	D
Adjustment Address	7B (1.5 DEV)
Specified Value	−7.5 ± 0.5 dBs

#### Adjusting method:

1) Release the protect.

Page: 1, address: 00, data: 01

- 2) Change the data of page: D, address: 7B, and adjust so that the 400 Hz signal level becomes the specified value.
- Press the PAUSE button of the adjusting remote control unit.

#### 4. Carrier Frequency Check (AU-138 board)

Mode	Record
Signal	No signal
Measurement Point	Pin (1) of CN602 (REC AFM)
Measuring Instrument	Frequency counter (Note 1)
Specified Value	1.500 ± 0.002 MHz

Note: Use a high impedance (above 1  $M\Omega$  ) and low capacity (below 20 pF) probe.

# Checking method:

 Check that the 1.5 MHz carrier frequency satisfies the specified value.

# 5. Record Level Check (AU-138 board)

Mode	Record
Signal	No signal
Measurement Point	Pin (1) of CN602 (REC AFM)
Measuring Instrument	Oscilloscope
Specified Value	A=48 ± 8 mVp-p

#### Checking method:

1) Check that the 1.5 MHz carrier level satisfies the specified value.

(Read the center of the luminance line width and note down (the level read.)




Fig. 9-23.


# 8 mm Video MECHANICAL ADJUSTMENT MANUAL IV



# A MECHANISM

Video 8

File with the SERVICE MANUAL



8 VIDEO RECORDER SONY.

# TABLE OF CONTENTS

Sec	tion Title	Page	Section	<u>Title</u>	<u>Page</u>
1.	PREPARATION FOR MECHANICAL CHECK,		3-10. Supply I	Reel Table Assembly and TG-1 Arm Assembl	ly23
	ADJUSTMENT AND REPLACEMENT		3-11. TG-2 Ro	oller Assembly	24
			3-12. TG-7 A	m Assembly	25
1-1.	Cassette compartment Assembly	3	3-13. LM Mot	or Assembly	26
	Operation with Cassette compartment Assembly Removed		3-14. LS Arm		27
	Handling of Mode Selector		3-15. M Slide	Assembly	28
	Mode Selector Schematic Diagram			ess Arm Assembly	
	Mode Selector Parts List		3-17. Cam		30
			3-18. GL Arm	Assembly	31
2.	PERIODIC CHECK AND MAINTENANCE		3-19. L Gear	A and L Gear B	32
			3-20. Relay Po	alley and Change Gear Assembly	33
2-1.	Cleaning of Rotaly Drum Assembly	8	3-21. Rotary (	Jpper Drum Replacement	34
	Cleaning of Tape Path		3-22. Adjustm	ent of Tension Regulator Position	35
	Periodic Check Items		3-23. FWD B	ack Tension Adjustment	35
	Service Jigs List		3-24. Reel To	rque Check	35
3.	MECHANICAL CHECK, ADJUSTMENT AND		4. TAPE P	ATH ADJUSTMENT	
	REPLACEMENT				
				on for Adjustment	
3-1.	Retainer, Gooseneck Assembly	12	4-2. Tracking	Adjustment	38
	Protector Base Assembly		4-3. No.2 Gui	de (TG-2) Adjustment	38
	Drum Assembly			uide (TG-2) Height Presetting	
	Capstan Motor Assembly			uide (TG-2) Adjustment	
	Take-UP Reel Assembly and T-Soft Assembly		4-4. No.7 Gui	de (TG-7) Adjustment	39
	Pinch Arm Assembly			REW Waveform Check	
	LS Chassis Assembly			fter Adjustment	
	Guide Base T Assembly and Guide Base S Assembly			ng Check	
	Guide Arm T Assembly and Guide Arm S Assembly		_	Check	
			4-6-3. Tape P	ath Check	40

# 1. PREPARATION FOR MECHANICAL CHECK, ADJUSTMENT AND REPLACEMENT

For removal of the cabinet and boards, refer to "Disassembly" in each Service Manual.

Mechanical adjustment is done in the USE mode. (To select the USE mode, refer to "1-3, Handling of Mode Selector".)

#### 1-1. CASSETTE COMPARTMENT ASSEMBLY

- 1. Removal (Fig. 1)
- 1) Select the USE mode.
- 2) Push the part (a) of lock arm (1) toward the arrow (A) to unlock from lock guide (2), and raise the cassette compartment as shown in Fig. a.
- 3) Remove two screws 3 and remove the LS frame 4 toward the arrow 3.
- 4) With the cassette compartment assembly pushed in arrow direction, distort tabs and for MD side plate toward the arrow to disengage from catches and for cassette compartment assembly respectively.
- In such a case, insert a screwdriver between MD side plate and catch and disengage the tab (a) first, then disengage the tab (a) for easy removal as shown in Fig. b.
- 5) Raise the cassette compartment assembly 5 in the opposite direction of arrow 6 until the shafts 1 and 8 are disengaged, and push left and right side plates toward arrow 1 to remove the cassette compartment assembly.




Fig. 1

#### 2. Mounting (Fig. 2)

- 1) Select the USE mode.
- 2) Draw the cassette holder 6 of cassette compartment assembly 5 toward the arrow 6, and lower the LS frame 4 toward the arrow 6.
- 3) With the cassette compartment assembly 5 tilted by about 45° against MD, insert shafts ① and ② of cassette compartment assembly into holes ⑤ and ① of MD side plate respectively.

At this time, the part  $\oplus$  of torsion bar must be positioned on the side  $\otimes$  of LS flexible board (FP-443) (not on the side  $\oplus$ ), as shown in Fig. c.

4) Holding holes ® and ® of MD side plate, press the cassette compartment assembly 5 so that its catches @ and @ are

- engaged with tabs **(b)** and **(c)** of MD side plate. In such a case, the lock arm **(l)** of cassette compartment assembly must be inserted into a groove in the guide rail **(l)** on the MD side plate as shown in Fig. d.
- 5) Insert left and right side plates @ and @ of LS frame I inside the LS chassis 3.
- 6) Push down the cassette compartment to lock.

Note: Make sure that the shafts ①, ② and the tabs ②, ② are set in the MD side plate properly.

7) Tighten two screws 3.




Fig. 2

# 1-2. OPERATION WITH CASSETTE COMPARTMENT ASSEMBLY REMOVED (Fig. 3)

- Referring to the Service Manual, supply power with the cabinet and camera removed. (Make the mechanical deck ready to operate.)
- 2) Place the cap 2 on the Reflector C 1.
- 3) Press the pin of the push switch 3 (ON state) and fix it with adhesive tape 4 in that state.

Note: Press the asterisked (\*) pin to set the REC mode.
(This is not required for the other modes.)

4) Push the cassette compartment DOWN switch 5 in an arrow direction as shown in Fig. a.




Fig. 3

#### 1-3. HANDLING OF MODE SELECTOR

· Stick the MD process table label to the mode selector IV panel, then mount the panel on the mode selector. U,U', FL, O, O' and A mechanisms have different mode indications respectively. Select your disired type. (Fig.4)

#### 1 Construction (Fig.5)

#### 2 Connection (Fig.6)

#### For CCD-FX410 series

1) Insert the FP-425 flexible connector 11 and M-SW connector 2 into the mode selector IV conversion connector 3 respectively.

# 3. Handling

- 1) Use the M mode selector buttons only.
- 2) During mode selection, "BLANK" lights up when no mode is being selected.
- 3) If the right M mode selector button is kept pressed, END, EJECT, USE, LOAD, READY, TURN, REC and FF light up
- 4) When changing over from the FF mode back to the END mode, press the left M mode selector botton to select your desired mode.




Fig. 4




Fig. 5

#### For CCD-FX410 series





Fig. 6

# 1-4. MODE SELECTOR SCHEMATIC DIAGRAM



#### 1-5. MODE SELECTOR PARTS LIST

T-3. M	ODE SELECTO	K PAKIS LISI						
Ref. No	Part No.	Description		Ref. No	Part No.	Description	!	
	CAPAC	CITOR			<u>ıc</u>			
C1	1-108-579-00	MILER 0.01 µ	F 50V	IC1	8-752-240-28	IC TC402	8BP	
C2	1.123-333-00	ELECT 100µ		1C2	8-752-120-03	IC #PA20	03C	
СЗ	1-108-579-00	MILER 0.01 µ		1C3	8-759-240-28	IC TC402	8BP	
C4	1-123-333-00	ELECT 100µ		IC4	8-759-120-03	IC #PA20		
C101	1-108-579-00	MILER 0.01 µ				,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,		
					RESIST	TOR		
C102	1-123-333-00	ELECT 100µ	F 24V					
C103	1-108-579-00	MILER 0.01 µ		R1	1-247-179-00	CARBON	100K	1/44
		•		R2	1-247-179-00	CARBON	100K	1/44
	DIODE			R3	1-247-179-00	CARBON	100K	1/44
				R4	1-247-131-00	CARBON	1K	1/44
D1	8-719-812-31	DIODE TLR123		R5	1-247-121-00	CARBON	390	1/44
D2	8-719-812-31	DIODE TLR123		•••		***************************************	030	-,
D3	8-719-812-31	DIODE TLR123		R6	1-247-131-00	CARBON	1K	1/44
D4	8-719-812-31	DIODE TLR123		R7	1-247-179-00	CARBON	100K	1/44
D5	8-719-812-31	DIODE TLR123		R8	1-247-179-00	CARBON	100K	1/44
				R9	1-247-179-00	CARBON	100K	1/44
D6	8-719-812-33	DIODE TLG123/	A	R10	1-247-121-00	CARBON	390	1/44
D7	8-719-812-31	DIODE TLR123		1120	1.47.111.00	OFFICE OFF	330	-/
D8	8-719-812-31	DIODE TLR123		R901	1-214-594-00	METAL	10	1W
D9	8-719-812-31	DIODE TLR123		11301	1.514.00	***************************************	10	
D10	8-719-812-31	DIODE TLR123						
D11	8-719-812-31	DIODE TLR123						
D12	8-719-812-31	DIODE TLR123						
D13	8-719-812-33	DIODE TLG123	A					

# 2. PERIODIC CHECK AND MAINTENANCE

 Carry out the following maintenance and periodic checks in order not only to fully exhibit the functions and performance of the set, but also for the equipment and tape. After repairing, service the set as follows, regarless of the length of use.

# 2-1. CLEANING OF ROTARY DRUM ASSEMBLY

 Gently apply chamois cloth (Ref. No. J-2) soaked in cleaning liquif (Ref. No.J-1) to the rotary drum assembly.
 Clean it by rotating the upper rotary drum assembly slowly counterclockwise by hand.

Note: Do not rotate the motor by power or rotate the upper rotary drum assembly clockwise by hand. Also, the head tip is highly likely to be damaged if the chamois cloth is moved in a pependicular direction to the it. make sure to follow the instructions above for cleaning the rotarydrum assembly.

# 2-2. CLEANING OF TAPE PATH (Fig.7)

1) In the USE mode, clean the tape running system (TG - 1,- 2,- 3,- 4,- 5, - 6, - 7, pinch roller, and capstan shaft) and the lower drum, using a super fine applicator (Ref. No. J - 3) soaked in the cleaning liquid.

Note: Note that no oil or grease of each link mechanism adheres to the super fine applicator (Ref. No. J - 3).




Fig. 7

#### 2-3. PERILDIC CHECK ITEMS

	Location of Maintenance	Hours of Use (H)										Remarks
	and check		1000	1500	2000	2500	3000	3500	4000	4500	5000	Remarks
trans- n System	Cleaning of tape path surface	0	0	0	0	0	0	0	0	0	0	Be careful of oil
Tape trans- portion System	Cleaning and degaus- sing of rotary assembly	0	0	0	0	0	0	0	0	0	0	Be careful of oil
	Relay belt	-	☆	-	☆	-	☆	_	☆	-	朴	3-944-539-01
ng m	Capstan shaft	_	0	-	0	-	0	_	0	_	0	Be adsolutely careful
Driving System	Relay pulley shaft	_	0	_	0	-	0	_	0		0	not to get oil on the tape path surface.
L S	Loading motor	_	☆	-	☆	_	☆	_	☆	_	☆	A-7040-304-A
	Abnormal noise	☆	☆	☆	☆	☆	☆	☆	. ☆	☆	☆	
Performance Confirmation	Back tension measurement	_	☆	-	☆	_	☆	_	☆	-	☆	
firn	Brake system	T -	☆	_	☆	_	☆	_	☆	_	☆	
Per	FWD. RVS torque measurement	-	☆	_	☆	-	☆	_	☆	_	☆	

O: Cleaning O: Oil ☆: Confirmation


**Note:** When overhauling, refer to the items above to replace parts.

Note: Concerning oil

• Be sure to use specified oil. (If you use oil with different visicosity, etc., it may cause troubles.)

Oil: Part No. 7-661-018-18 (Mitsubishi Diamond Oil Hydrofluid NT - 68)

- When lubricating bearings, be sure use oil free from dust, etc. (If you use oil with dust, etc. contained, it may cause bearings to be worn out or seized.)
- A drip of oil refers to an amount attached to the tip of a \( \phi \) 2mm stick shown in the right figure.




# 2-4. Service jigs list

Ref. No.	Name	Part No.	Fixture No.	Usage and Others
J-1	Cleaning fluid	Y-2031-001-0		
J-2	Chamois cloth	2-034-697-00		
J-3	Super fine applicator (Made by NIPPON APPLICATOR, P752D)			
J-4	Head degausser	Widely available		
J-5	Small mirror for adjustment Spare mirror	J-6080-029-A J-6080-030-1	SL-5052	Tape path
J-6	Alignment tape NTSC (WR5-1N) PAL (WR5-1C)	8-967-995-01 8-967-995-06		Tape path
J-9	FWD and RVS winding torque cassette	J-6080-824-A	GD-2086	
J-10	Rotary drum jig	(Attached to the m	aintenance rotary	upper drum)
J-11	Screwdriver for tape path	J-6082-026-A		For tape guide adjustment
J-12	Mode selector N panel	J-6082-105-A		
J-13	Mode selector	J-6080-825-A		For all models
J-14	Mode selector IV conversion connector	J-6082-167-A		
J-15	FWD B.T. adjusting driver	J-6082-182-A		
J-16	Adjusting remote controller	J-6082-053-B		Tape path (Setting of PATH mode)
J-17	MD process table label	J-6082-166-A		

Other equipment •Oscilloscope

<sup>●</sup>Analog tester (20 kΩ)



# 3. MECHANICAL CHECK, ADJUSTMENT AND REPLACEMENT

Note	:	Use	the	mode	selecto	r (Ref.	No.	J-13)	for	the	follov	ving
		med	han	ical ch	ecks, a	ljustme	nts a	and re	plac	eme	ents.	

Note: The modes in \_\_\_\_\_are those set by pressing the mode

selector buttons.

# 3-1. RETAINER, GOOSENECK ASSEMBLY (Fig. 8)

#### 1. Removal

- 1) Referring to 1-1, remove the cassette compartment assembly.
- 2) Remove a screw 1.
- 3) Remove the Retainer, Gooseneck assembly 2.

# 2. Mounting

- 1) Mount the Retainer, Gooseneck assembly 2 with its two tabs and holes of LS chassis engaged with its hole and a boss of LS chassis.
- 2) Tighten the screw 1.
- 3) Referring to 1-1, mount the cassette compartment assembly.




Fig. 8

# 3-2. PROTECTOR BASE ASSEMBLY (Fig. 9)

- 1. Removal
- 1) Referring to 1-1, remove the cassette compartment assembly.
- 2) Remove two screws **11**, then the protector base assembly **2**.

# 2. Mounting

- 1) Mount the protector base assembly 2 with its three hole, engaged with two dowels of mechanical chassis, and a dowel of TG-5 Base Holder 3.
- 2) Tighten two screws II.
- 3) Referring to 1-1, mount the cassette compartment assembly.




Fig. 9

#### 3-3. DRUM ASSEMBLY (Fig. 10)

#### 1. Removal

- 1) Referring to 1-1, remove the cassette compartment assembly.
- 2) Referring to 3-2, remove the protect base assembly.
- 3) Disconnect the connector of FP-444 flexible board 11 on the back of MD.
- 4) Remove three screw 2, then the drum assembly 3.

Note: Do not touch the outer surfaced of drum (hold portions and so of drum).

#### 2. Mounting

Mount the drum assembly while aligning with two dowels
 of chassis.

**Note**: Do not touch the outer surfaced of drum (hold portions A and B of drum).

2) Tighten three screw assemblies 2 in the order of 1, 2 and 3.

Note: Tighten lightly not to deform the drum lead.

Apply a screw locking agent to prevent screws from loosening.

Note: In tightening the screws, pushing down the drum extremely will allow the drum to float up.

- Connect the connector of FP-444 flexible board on the back of MD.
- 5) Referring to 3-2, mount the protect base assembly.
- 6) Referring to 1-1, mount the cassette compartment assembly.

Note: After mounting, make tape path adjustment in Section 4.




Fig. 10

# 3-4. CAPSTAN MOTOR ASSEMBLY (Fig. 11)

- 1. Removal
- 1) Referring to 1-1, remove the cassette compartment assembly.
- 2) Remove two screw 1, then the capstan cover 2.
- 3) Remove the screw 3, then the capstan motor assembly 4.

#### 2. Mounting

1) Mount the capstan motor assembly 4 and tighten the scre 3.

Note: In mounting the capstan motor assembly, hold lightly the capstan motor assembly until the rotor gear aligns with the change gear Assy, then insert fully the assembly when both gears are engaged completely by manually rotating the rotor. (Take care not to damage the change gear Assy.)

- 2) Mount the capstan cover 2 and tighten two screws 1.
- 3) Referring to 1-1, mount the cassette compartment assembly.




Fig. 11

# 3-5. TAKE-UP REEL TABLE ASSEMBLY AND T- SOFT ASSEMBLY (Fig. 12)

- 1. Removal
- 1) Referring to 1-1, remove the cassette compartment assembly.
- 2) Referring to 3-1, remove the Retainer, Gooseneck assembly.
- 3) Remove the take-up reel table assembly 11.
- 4) Remove the T soft assembly 2, then the T soft arm 2.

#### 2. Mounting

- 1) Mount the T soft arm **3** with its long hole © engaged with the boss **3** of LS chassis.
- 2) Mount the T soft assembly 2 with its tab @ engaged with a square hole @ of T soft arm, as shown in Fig. a.
- 3) Mount the take-up reel table assembly 11 and rotate it toward the arrow (2) to be latched with T hard claw.
- 4) Referring to 3-1. mount the Retainer, Gooseneck assembly.
- 5) Referring to 1-1, mount the cassette compartment assembly.




Fig. 12

#### 3-6. PINCH ARM ASSEMBLY (Fig. 13)

- 1. Removal
- 1) Referring to 1-1, remove the cassette compartment assembly.
- 2) Select the READY mode.
- 3) Remove a washer 11, then the pinch arm assembly 22.

#### 2. Mounting

- 1) Select the READY mode.
- 2) Hooking a spring of pinch arm assembly 2 to the cassempositioning boss on the chassis, mount the pinch arm assembly on the shaft of LS chassis assembly as shown in Fig. a.
- 3) Push in the spring with tweezers up to the root of boss as shown in Fig. b.
- 4) Mount the washer 1.
- 5) Referring to 1-1, mount the cassette compartment assembly.




Fig. 13

# LS CHASSIS ASSEMBLY (Fig. 14)

#### 1. Removal

- 1) Referring to 1-1, remove the cassette compartment assembly.
- 2) Referring to 3-1, remove the Retainer, Gooseneck assembly.
- 3) Referring to 3-2, remove the protector base assembly.
- 4) Remove a screw 1, TG-5 base holder 2, and LS flexible board 3.
- 5) Remove a lock washer 4, then the gooseneck as sembly 5.
- 6) Remove four screws 6, then the LS chassis assembly 7.

#### 2. Mounting

- 1) Select the USE mode.
- 2) Confirm that the T hard claw and the outsert on the back of LS chassis are positioned as shown in Fig. a. (The T hard claw must be higher than corner @ of chassis hole.) If not high, turn the outsert in the arrow direction while pushing the T hard claw from LS chassis to the chassis.
- 3) Sliding the GL slider, align the top edge of long hole (a) in GL slider with the edge face (a) of LS chassis hole as shown in Fig. b.
- 4) Mount the LS chassis assembly 7 on the chassis.

Note: At this time, aligh a dowel @ on LS chassis with a long hole @ of No.7 guide on chassis, a long hole of GL slider with a GL arm pin, a groove of LS cam plate with an LS arm pin respectively as shown in Fig. c and d.

- 5) Tighten four screws 6.
- 6) Mount the LS flexible board 3 and TG-5 base holder 2, then tighten the screw 1.
- 7) Mount the Gooseneck assembly 5 and fix it with a washer 4.

**Note:** Using the mode selector, confirm that loading and unloading are performed smoothly.

- 8) Referring to 3-2, mount the protector base assembly.
- 9) Referring to 3-1, mount the Retainer, Gooseneck assembly.
- 10) Referring to 1-1, mount the cassette compartment assembly.




Fig. 14

# 3- GUIDE BASE T ASSEMBLY AND GUIDE BASE S ASSEMBLY (Fig. 15, 16)

#### 1. Removal

- 1) Referring to 1-1, remove the cassette compartment assembly.
- 2) Referring to 3-1, remove the Retainer Gooseneck assembly.
- 3) Referring to 3-2, remove the protector base assembly.
- 4) Referring to 3-7, remove the LS chassis assembly.
- 5) Push in the GL slider 11 toward the arrow 2, and remove the guide base T assembly 2 and guide base S assembly 3 from the guide rail respectively as shown in Fig. 15.

Note: Do not invert the LS chassis up side down, otherwise the T reel table assembly, T soft arm and T sofr assembly will drop. Also, take care not to allow the S reel table to float up, or the tension regulator string bends. (Refer to 3-5 T Reel Table Assembly and T Soft Assembly, and 3-10 S Reel Table Assembly and TG-1 Arm Assembly.)

6) Turning the guide base T assembly 2 and guide base S assembly 3 respectively, align the shaft to hole to remove as shown in Fig. a.

#### 2. Mounting

- 1) Turning the guide base T assembly 2 and guide base S assembly 3 respectively, align the shaft with a hole to mount as shown in Fig. a (Fig. 15).
- 2) On the back side of chassis, insert the guide arm T assembly 4, guide arm S assembly 5 and GL slider 1 from position shown in Fig. b to position shown in Fig. c. Also, aligning the guide base T assembly 2 and guide base S assembly 3 with the respective guide rails, push in the GL slider 1 toward the arrow 2 as shown in Fig. 16.

Note: Do not invert the LS chassis up side down, otherwise the T reel table assembly, T soft arm and T soft assembly will drop. Also, take care not to allow the S reel table to float up, or the tension regulator string bends. (Refer to 3-5 T Reel Table Assembly and T Soft Assembly, and 3-10 S Reel Table Assembly and TG-1 Arm Assembly.)

- 3) Referring to 3-7, mount the LS chassis assembly.
- 4) Referring to 3-2, mount the protector base assembly.
- 5) Referring to 3-1, mount the Retainer, Gooseneck assembly.

**Note**: At this time, confirm that the T soft assembly is surely engaged with the T soft arm.

6) Referring to 1-1, mount the cassette compartment assembly.




Fig. 15




Fig. 16

# GUIDE ARM T ASSEMBLY AND GUIDE ARM S ASSEMBLY (Fig. 17)

#### 1. Removal

- 1) Referring to 1-1, remove the cassette compartment assembly.
- 2) Referring to 3-1, remove the Retainer, Gooseneck assembly.
- 3) Referring to 3-2, remove the protector base assembly.
- 4) Referring to 3-7, remove the LS chassis assembly.
- 5) Referring to 3-8, remove the guide base T assembly and guide base S assembly.
- 6) Remove lock washers 11, then the guide arm T assembly 2 and guide arm S assembly 3 respectively from the back side of chassis.

Note: Do not invert the LS chassis up side down, otherwise the T reel table assembly, T soft arm and T soft assembly will drop. Also, take care not to allow the S reel table to float up, or the tension regulator string bends. (Refer to 3-5 T Reel Table Assembly and T Soft Assmbly, and 3-10 S Reel Table Assembly and TG-1 Arm Assembly.)

#### 2. Mounting

1) Mount the guide arm T assembly 2 and guide arm S assembly 3, then fix them with a lock washer 11 respectively.

Note: Do not invert the LS chassis up side down, otherwise the T reel table assembly, T soft arm and T soft assembly will drop. Also, take care not to allow the S reel table to float up, or the tension regulator string bends. (Refer to 3-5 T Reel Table Assembly and T Soft Assembly, and 3-10 S Reel Table Assembly and TG-1 Arm Assembly.)

- 2) Referring to 3-8, mount the guide base T assembly, guide-base S assembly and GL slider.
- 3) Referring to 3-7, mount the LS chassis assembly.
- 4) Referring to 3-2, mount the protector base assembly.
- 5) Referring to 3-1, mount the Retainer, Gooseneck assembly.
- 6) Referring to 1-1, mount the cassette compartment assembly.




Fig. 17

# 3-10. SUPPLY REEL TABLE ASSEMBLY AND TG-1 ARM ASSEMBLY (Fig. 18)

#### 1. Removal

- 1) Referring to 1-1, remove the cassette compartment assembly.
- 2) Referring to 3-1, remove the Retainer, Gooseneck assembly.
- 3) Referring to 3-2, remove the protector base assembly.
- 4) Referring to 3-7, remove the LS chassis assembly.
- 5) Referring to 3-8, remove the guide base S assembly.
- 6) Remove a screw 1, then the string 2 from the supply reel table assembly 3. For easy removal of string block 4, insert a flat-blade screwdriver into a groove 3 and push it up (Fig. a).
- 7) Remove the supply reel table assembly 3.
- 8) Remove a tension coil spring 5.
- 9) Turn the TG-1 arm assembly 6 up to a portion © of LS chassis hole in the arrow direction so that its tab 6 can be disengaged (Fig. b).

#### 2. Mounting

- 1) Pushing the S soft brake 77 toward the arrow 33, mount thesupply reel table assembly 33.
- 2) Route the string 2 under the TG-1 arm asembly 6, andinsert the tab 6 of TG-1 arm assembly into the LS chassis hole 6, then turn the TG-1 arm assembly in the reverse direction of arow 4 (Fig. b).

 Wind the string 2 along the groove of supply reel t assembly 3 (Fig. a).

**Note**: Do not curl the string extremely. Also, avoid adhesion : oil, otherwise the image will be distorted.

- 4) Using the FWD B.T. adjusting driver (Ref. No. J-15), shift the string block 4 toward the arrow 6 and tighten the screw 1 (Fig. a).
- 5) Engage the tension coil spring 5 to the chassis hook.

Note: Confirm that the string 2 is surely wound around the groove of supply reel table assembly (Fig.a).

- 6) Referring to 3-8, mount the guide base S assembly.
- 7) Referring to 3-7, mount the LS chassis assembly.
- 8) Referring to 3-2, mount the protector base assembly.
- 9) Referring to 3-1, mount the Retainer, Gooseneck assembly.

Note: At this time, confirm that the T soft assembly is surely engaged with the T soft arm. (Refer to 3-5 Take-up Reel Table Assembly and Take-up Soft Assembly.)

10) Referring to 1-1, mount the cassette compatrment assembly.

Note: Referring to 3-22, adjust the tension regulator position.

Note: Referring to 3-23, adjust the forward back tension.




Fig. 18

# 3 TG-2 ROLLER ASSEMBLY (Fig. 19)

- 1. Removal
- 1) Remove the TG-2 roller assembly
- 2) Remove a compression coil spring 2.

#### 2.Mounting

- Insert a compression coil spring into the boss on chassis.
- 2) Rotate gently the TG-2 roller assembly **1** until the screw is engaged.
- 3. Presetting of TG-2 Roller Height (Fig. a)
- 1) Rotating the TG-2 upper flange, adjust the height of bottom face of TG-2 lower flange from the top face of dowel on the mechanical chassis to 3.  $3 \pm 0.05$ mm.

**Note**: After adjustment, perform 4. TAPE PATH ADJUST-MENT.




Fig. 19

#### 3-12. TG-7 ARM ASSEMBLY (Fig. 20)

#### 1. Removal

- 1) Referring to 1-1, remove the cassette compartment assembly.
- 2) Referring to 3-1, remove the Retainer, Gooseneck assembly.
- 3) Referring to 3-2, remove the protector base assembly.
- 4) Referring to 3-7, remove the LS chassis assembly.
- 5) Raise a portion @ of TG-7 arm Leaf spring II in arrow direction with a flat-blade screwdriver or tweezers to disengage the tab from the chassis, then remove the TG-7 arm Leaf spring as shown in Fig. a.
- Remove the TG-7 assembly from the shaft of mechanicalchassis.

#### 2. Mounting

- Mount the TG-7 arm assembly 2 to the shaft of mechanic chassis.
- Mount the TG-7 arm Leaf spring 1 to the mechanicalchasis.
  - \*Push in the tab of Leaf spring until it clicks into a detent of chassis (Fig. a).
- 3) Referring to 3-7, mount the LS chassis assembly.
- 4) Referring to 3-2, mount the protector base assembly.
- 5) Referring to 3-1, mount the Retainer, Gooseneck assembly.
- 6) Referring to 1-1, mount the cassette compartmnet assembly.

Note: After mounting, perform 4. TAPE PATH ADJUST-MENT.




Fig. 20

#### S LM MOTOR ASSEMBLY (Fig. 21)

#### 1. Removal

- 1) Referring to 1-1, remove the cassette compartment assembly.
- 2) Referring to 3-1, remove the Retainer, Gooseneck assembly.
- 3) Referring to 3-2, remove the protector base assembly.
- 4) Referring to 3-7, remove the LS chassis assembly.
- 5) Select the LOAD mode (at the position where the FF arm assembly is not above the screw 1).
- 6) Remove two screws 11, then the LM motor assembly 2.

#### 2. Mounting

- Aligning the dowel (a) of LM motor assembly (b) with the hole (b) of mechanical chassis, mount the LM motor assembly with its hole (c) inserted into the mechanical chassis shaft (a)
- 2) Tighten two screws 11.
- 3) Referring to 3-7, mount the LS chassis assembly.
- 4) Referring to 3-2, mount the protector base assembly.
- 5) Referring to 3-1, mount the Retainer, Gooseneck assembly.
- 6) Referring to 1-1, mount the cassette compartment assembly.




Fig. 21

#### 3-14. LS ARM (Fig. 22)

#### 1. Removal

- 1) Referring to 1-1, remove the cassette compartment assembly.
- 2) Referring to 3-1, remove the Retainer, Gooseneck assembly.
- 3) Referring to 3-2, remove the proctector base assembly.
- 4) Referring to 3-7, remove the LS chassis assembly.
- 5) Remove the LS arm 11 from the shaft of mechanical chassis.

Note: Take care not to drop the LS roller 2.

#### 2. Mounting

1) Mount the LS arm **1** meeting with mechanical chassis shand cam groove.

**Note:** Move the LS arm in arrow direction to confirm that the LS roller is surely inserted.

- 2) Referring to 3-7, mount the LS chassis assembly.
- 3) Referring to 3-2, mount the protector base assembly.
- 4) Referring to 3-1, mount the Retainer, Gooseneck assembly.
- 5) Referring to 1-1, mount the cassette compartment assembly.




Fig. 22

#### . M SLIDER ASSEMBLY (Fig. 23)

#### nemoval

- 13 Referring to 1-1, remove the cassette compartment assembly.
- 2) Referring to 3-1, remove the Retainer, Gooseneck assembly.
- 3) Referring to 3-2, remove the protector base assembly.
- 4) Referring to 3-7, remove the LS chassis assembly.
- 5) Remove two screws 11, then the gear holder 22.
- 6) Remove two lock washers 3; then the M slider assembly 4.

#### 2. Mounting

- 1) Mount the M slider assembly 4, aligning long holes and b of M slider assembly with shafts c and d of mechanical chassis, and a long hole with shaft f of press arm assembly, and also shaft w with outer groove f of cam respectively.
- 2) Mount two lock washers 3.
- 3) Mount the gear holder ② with its outserts ⊕ and ⊕ inserted into holes in the mechanical chassis.
- 4) Tighten two screws 11.
- 5) Referring to 3-7, mount the LS chassis assembly.
- 6) Referring to 3-2, mount the protector base assembly.
- 7) Referring to 3-1, mount the Retainer, Gooseneck assembly.
- 8) Referring to 1-1, mount the cassette compartment assembly.




Fig. 23

#### 3-16. PINCH PRESS ARM ASSEMBLY (Fig. 24)

#### 1. Removal

- 1) Referring to 1-1, remove the cassette compartment assembly.
- 2) Referring to 3-1, remove the Retainer, Gooseneck assembly.
- 3) Referring to 3-2, remove the protector base assembly.
- 4) Referring to 3-3, remove the drum assembly.
- 5) Referring to 3-7, remove the LS chassis assemvly.
- 6) Referring to 3-15, remove the M slider assembly.
- 7) Remove a lock washer 11, then pinch press arm assembly 2.

#### 2.Mounting

- Mount the pinch press arm assembly 2, inserting its shall into the cam groove 6 of HC drive arm, and hole 6 in the shaft 6 of mechanical chassis.
- 2) Mount the lock washer 11.
- After mounting, shift the pinch press arm assembly toward the arrow direction.
- 4) Referring to 3-15, mount the M slider assembly.
- 5) Referring to 3-7, mount the LS chassis assembly.
- 6) Referring to 3-3, mount the drum assembly.
- 7) Referring to 3-2, mount the protector base assembly.
- 8) Referring to 3-1, mount the Retainer, Gooseneck assembly.
- 9) Referring to 1-1, mount the cassette compartment assembly.




Fig. 24

#### . CAM (Fig. 25)

#### :emoval

Referring to 1-1, remove the cassette compartment assembly. Referring to 3-1, remove the Retainer, Gooseneck assembly. Referring to 3-2, remove the protector base assembly.

- 4) Referring to 3-7, remove the LS chassis assembly.
- 5) Referring to 3-14, remove the LS arm assembly.
- 6) Referring to 3-15, remove the M slider assembly.
- 7) Remove the cam 1.

#### 2. Mounting

1) Referring to 3-13, remove the LM motor assembly.

**Note**: Take care not to allow grease of LM motor assembly to stick to the TG-2 roller assembly.

2) Mount the cam ■, aligning its center hole with shaft of mechanical chassis, and the cam groove with the shaft of GL arm assembly. At this time, make sure that the ▲ mark on L gear B is aligned with that on the cam and also a recess is aligned with the phase aligning hole respectively as shown in Fig. a.

Note: Apply grease to the cam groove if it scarecely remains.

- 3) Mount the LM motor assembly.
- 4) Referring to 3-15, mount the M slider assembly.
- 5) Referring to 3-14, mount the LS arm assembly.
- 6) Referring to 3-7, mount the LS chassis assembly.
- 7) Referring to 3-2, mount the protector base assembly.
- 8) Referring to 3-1, mount the Retainer, Gooseneck assembly.
- 9) Referring to 1-1, mount the cassette compartment assembly.




Fig. 25

#### 3-18. GL ARM ASSEMBLY (Fig. 26)

#### 1. Removal

- 1) Referring to 1-1, remove the cassette compartment assembly.
- 2) Referring to 3-1, remove the Retainer, Gooseneck assembly.
- 3) Referring to 3-2, remove the protector base assembly.
- 4) Referring to 3-7, remove the LS chassis assembly.
- 5) Referring to 3-14, remove the LS arm assembly.
- 6) Referring to 3-15, remove the M slider assembly.
- 7) Referring to 3-17, remove the cam.
- 8) Remove the GL arm assembly 1.

#### 2. Mounting

- 1) Mount the GL arm assembly **1** with its hole ⓐ inserted in the shaft ⓑ of mechanical chassis.
- 2) Referring to 3-17, mount the cam.
- 3) Referring to 3-15, mount the M slider assembly.
- 4) Referring to 3-14, mount the LS arm assembly.
- 5) Referring to 3-7, mount the LS chassis assembly.
- 6) Referring to 3-2, mount the protector base assembly.
- 7) Referring to 3-1, mount the Retainer, Gooseneck assembly.
- 8) Referring to 1-1, mount the cassette compartment assembly.




Fig. 26

#### 9. L GEAR A AND L GEAR B (Fig. 27)

#### Removal

- : Referring to 1-1, remove the cassette compartment assembly.
- 2) Referring to 3-1, remove the Retainer, Gooseneck assembly.
- 3) Referring to 3-2, remove the protector base assembly.
- 4) Referring to 3-7, remove the LS chassis assembly.
- 5) Referring to 3-14, remove the LS arm assembly.
- 6) Referring to 3-15, remove the M slider assembly.
- 7) Referring to 3-17, remove the cam.
- 8) Referring to 3-13, remove the LM motor assembly.
- 9) Remove the FF arm assembly 11.
- 10) Remove the L gear A 2.
- 11) Remove the L gear B 3.

#### 2. Mounting

- Insert the L gear B 
   into the shaft of mechanical chassis.
   (At this time, the phase aligning mark ▲ should be faced toward the carn mounting shaft ②.)
- 2) Insert the L gear A 2 into the shaft of mechanical chassis.
- Mount the FF arm assembly with its two shafts inserted into the cam groove of L gear B and the hole of mechanical chassis.
- 4) Referring to 3-17, mount the cam.
- 5) Referring to 3-13, mount the LM motor assembly.
- 6) Referring to 3-15, mount the M sleder assembly.
- 7) Referring to 3-14, mount the LS arm assembly.
- 8) Referring to 3-7, mount the LS chassis assembly.
- 9) Referring to 3-2, mount the protector base assembly.
- 10) Referring to 3-1, mount the Retainer, Gooseneck assembly.
- 11) Referring to 1-1, mount the cassette compartment assembly.




Fig. 27

### 3-20. RELAY PULLEY AND CHANGE GEAR ASSEMBLY (Fig. 28)

#### 1. Removal

- Referring to 1-1, remove the cassette compartment assembly.
- 2) Referring to 3-1, remove the Retainer, Gooseneck assembly.
- 3) Referring to 3-2, remove the protector base assembly.
- 4) Referring to 3-3, remove the drum assembly.
- 5) Referring to 3-7, remove the LS chassis assembly.
- 6) Referring to 3-14, remove the LS arm assembly.
- 7) Referring to 3-15, remove the M slider assembly.
- 8) Referring to 3-17, remove the carn.
- 9) Referring to 3-18, remove the GL arm assembly.
- 10) Referring to 3-16, remove the pinch press arm assembly.
- 11) Remove a lock washer 11, then remove together the Change gear assembly 2, relay belt 3 and relay pulley 4.

#### 2. Mounting

- \*Give one or two drips of oil to the conversion gear shaft and relay pulley shaft respectively. (Oiling range is under the neck as shown in Fig. a.)
- 1) Hooking the relay belt 3 to the relay pulley 4 and Change gear assembly 2, mount respective parts.
  - \* At first, insert the relay pulley into the mechanical chassisshaft, then the change gear assembly by engaging with the capstan motor gear.

**Note**: Take care not to damage the Change gear by the capstan motor gear.

- 2) Mount a lock washer 1.
- 3) Referring to 3-16, mount the pinch press arm assembly.
- 4) Referring to 3-18, mount the GL arm asembly.
- 5) Referring to 3-17, mount the cam.
- 6) Referring to 3-15, mount the M slider assembly.
- 7) Referring to 3-14, mount the LS arm assembly.
- 8) Referring to 3-7, mount the LS chassis assembly.
- 9) Referring to 3-3, mount the drum assembly.
- 10) Referring to 3-2, mount the protector base assembly.
- 11) Referring to 3-1, mount the Retainer, Gooseneck assembly.
- 12) Referring to 1-1, mount the cassette compartment assembly.




Fig. 28

#### 3-21. ROTARY UPPER DRUM REPLACEMENT

#### 1. Removoal

- · If possible, make a recording before removal.
- 1) Remove the two screws 1 (Fig. 29).
- 2) Mount the jig 2 (Ref. No. J-10) with the two supplied screws 3, then screw the attached hexagon socket screws 4 to the jig 2. The rotary upper drum 5 will move upward and come off (Fig. 30).




Fig. 29




Fig. 30

#### 2. Installation

- Wipe clean the flange surface and the rotary upper drum surface that makes contact with it, and confirm that they are free from dirt and scratches.
- 2) Insert the jig [3] (Ref. No. J-10) into the drum positioning hole, then set then set the rotary upper drum [5] by passing the jig through its positioning hole [7]. (Fig. 31)
- 3) Remove the jig 3 and push down the rotary upper drum 3 gently by hand. If it does not go all the way down, secure it temporarily by tightening the two screws 1 alternately (Fig.29).
- 4) Insert the jig **3** into the positioning hole **2** again and confirm that it goes in smoothly. If it does not, loosen the two screws **1**, repeat step 2) of the Removal paragraph and restart the setting procedure.
- 5) Tighten the screws 1.

**Note**: After installing, be sure to perform tape path adjustment as described in section 4.




Fig. 31

# 3-22. ADJUSTMENT OF TENSION REGULATOR POSITION (Fig. 32)

#### 1. Adjustment

- 1) Set a cassett tape and run the tape in the PB mode.
- 2) With the tape running, check that the distance from No.1 guide to No. 2 guide upper flange is 4.2 mm.
- 3) If they are not at the specified positions, perform adjustment in step 4) and subsequent steps.
- 4) Loosen the screw 1.
- 5) If No.1 guide is located inside the specified position, shift the string block toward the arrow (a) using the FWD B.T. adjusting driver (Ref No. J-15). Or, if it is located outside, shift toward the arrow (a).
- 6) Tighten the screw .




Fig. 32

#### 3-23. FWD BACK TENSION ADJUSTMENT (Fig.33)

- 1) Select the TEST mode 1 using the adjusting remote controller (Ref No. J-17).
- 2) Set the torque cassette (Ref No.J-10).
- 3) Select the FWD mode, and check that the torque of S reel table is  $8.5 \sim 11.5$  g  $\cdot$  cm.

If it is out of standard, adjust the TG-1 spring hook position using the FWD B.T. adjusting driver (Ref No. J-15).




Fig. 33

#### 3-24. REEL TORQUE CHECK

- 1) Set the torque cassette.
- 2) Select the FWD mode, and check that the preque fluctuation center of T reel table is  $7 \sim 17 \text{ g} \cdot \text{cm}$
- Select the REV mode, and check that the brique fluctuation center of S reel table is 25 ~ 39 g · cm.
- 4) Select the REV mode, and check that the torque of T reel table is  $7 \sim 17 \, \text{g} \cdot \text{cm}$ .
- 5) If the above data is not satisfied, the tension egulator band, T hard tab or T soft assembly will be faulty. Check them first, and if no abnormality is found, replace respective reel tables.

#### 4. TAPE PATH ADJUSTMENT

The 8mm video system uses ATF (Automatic Track Finding) which instantaneously controls a tape running speed based on 4 types of pilot signals and performs high-precision tracking.

This does away a tracking control knob and allows accurate track tracing.

On the other hand, however, the ATF system has a problem in adjusting the tape path system. That is, if head tracing is out of order a little, the ATF automatically corrects it, which means that perfect adjustment cannot be done.

Therefore, in the A mechanism, the ATF system is forcibly operated to shift a tracking amount constantly (approx. 1/4) by setting the PATH mode with the adjusting remote controller (Ref No.J-16). So, fine tracking adjustment can be easily done. Also, the PATH mode setting varies with the model, and therefore, refer to the Service Manual.

Example) For CCD-FX410 series
Set the adjusting remote controller to the HOLD ON side.

- Set PAGE: 1, ADDRESS: 00, DATA: 01 to cancel the PROTECT mode.
- Set PAGE: D, ADDRESS: 01, DATA: 03 to select the PATH mode.

Note: Setting of PATH mode = TRACK SHIFT mode

If the adjusting remote controller (Ref No.J-16) is set to
HOLD OFF once, then set to HOLD ON again after
mode setting, the display of ADDRESS and DATA
changes.

 After adjustment is over, set DATA: 00, and press the PAUSE buttom on the adjusting remote controller (Ref No. J-16).




Fig. 34-A

#### [Note on Adjustment of No.7 Gulde (TG-7)]

The height adjustment screw for No.7 guide (TG-7) is located at some distance from the guide (refer to Fig.41).

Therefore, when performing section 4-4. No.7 Guide (TG-7) Adjustment it is convenient to use the alignment tape for tracking (Ref. No. J-6), modified as follows, and perform adjustment in playback mode.




Fig. 34-B

#### 4-1. PREPARATION FOR ADJUSTMENT

- 1) Clean the tape running surface (tape guides, drum, capstan shaft, pinch roller) (Fig. 34-A).
- 2) Set the PATH mode using the adjusting remote controller.
- connect an oscilloscope to the check pin connector of the set. Example) For CCD-FX410 series

CH1: CN001 pin ③ (PB RF OUT) on CS-31 board CH2: CN001 pin ④ (RF SWP) on CS-31 board

- 4) Play back a tracking alignment tape (NTSC: WR5-1N, or PAL: WR5-1C).
- 5) Check that a RF waveform is flat at the inlet and outlet of the oscilloscope (Fig. 35 @).

If not flat, make adjustment with the procedures below. When the RF waveform is not flat at the inlet/outlet; See Fig. 35 5 and c.




Fig. 35

#### 4-2. TRACKING ADJUSTMENT (Fig. 36, 37)

- 1) Play back the tracking alignment tape.
- 2) Loosen the No.3 guide (TG-3) lock screw and turn the No.3 guide to flatten the waveform at the inlet.
- 3) Tighten the No.3 guide (TG-3) lock screw 1 to lock the No.3 guide.
- 4) Loosen the No.6 guide (TG-6) lock screw 2 and turn the No.6 guide to flatten the waveform at the outlet.
- 5) Tighten the No.6 guide (TG-6) lock screw 2 to lock the No.6 guide. When this is done, make sure that the waveform does not change at the outlet.

Note: Be careful not to loosen the lock screw too much because the guide is easily moved.

: Take care not to allow interference between No.6 guide and drum when tightening the No.6 guide lock screw.




Fig. 36




Fig. 37

#### 4-3. No.2 GUIDE (TG-2) ADJUSTMENT

When the No.2 guide has been turned or replaced, perform height presetting before this adjustment.

#### 4-3-1, No. 2 GUIDE (TG-2) HEIGHT PRESETTING (Fig. 38)

1) Rotating the TG-2 upper flange, adjust the height of bottom face of TG-2 lower flange from the top face of dowel on the mechanical chassis to  $3.3 \pm 0.05$  mm.




Fig. 38

#### [Reference]

This A mechanism is equipped with four adjustable guides (TG-2, 3, 6 and 7). To raise or lower the respective guide rotate the corresponding adjustment screw as shown below.

Guide	Guide adjustment	Rotating direction of adjustment screw	
TG-2, 3, 6	Raise	Counterclockwise	
	Lower	Clockwise	
TG-7	Raise	Clockwise	
	Lower	Counterclockwise	

#### 4-3-2. No. 2 GUIDE (TG-2) ADJUSTMENT (Fig. 39, 40)

- Play back a thin tape like the P6-120MP, etc. and set the REV mode.
- Confirm that the tape is not bent at the lower flange ≥ of the No.2 guide (TG-2) (Fig. 39). If it is, turn the upper flange of the No.2 guide (TG-2) clockwise with a screwdriver, lowering it until the tape is straightened.
- 3) Play back the alignment tape for tracking adjustment.
- 4) Perform tracking adjustment and trcking fine adjustment as described in sections 4-2.
- 5) In the track shift mode, CUE/REV the tape, then play it back and confirm that the RF waveform rises flat within 2 seconds.
- 6) If the waveform is not normal (Fig. 40), turn the upper flange of the No. 2 guide (TG-2) 90° counterclockwise and repeat step 5.

Repeat steps 5) and 6) until a normal waveform is obtained. Then, confirm that the tracking waveform has not changed. If it has, perform fine adjustment of entrance side tracking and repeat step 5).




Fig. 39




Fig. 40

#### 4-4. No.7 GUIDE (TG-7) ADJUSTMENT (Fig. 41)

Note: This adjustment requires the No. 7 guide adjusting cassetetape (Fig. 34-B).

- Play back the No.7 guide adjusting cassetetape and set the REV mode.
- 2) Confirm that the tape is not bent between the No.6 guide (TG-6) 11 and the capstan 2. If it is, turn the hight adjusting screw 4 of the No.7 guide (TG-7) 12 until the tape is straightened
- 3) Set the playback mode again and confirm that the tape is not bent between the capstan and the hight adjusting screw of the No.7 guide (specification: 0.5mm or less). If the tape is bent beyond the specification, turn the No.7 guide (TG-7) until bending is within the specification (0.5mm).
  If in the REV mode tape bending between the No. 6 guide (TG-6) and the capstan is 0.3mm or less, adjustment can be considered completed.




Fig. 41

#### 4-5. CUE AND REV WAVEFORM CHECK (Fig. 42)

- Play back the alignment tape for tracking adjustment and set the REV mode. Confirm that waveform peaks maintain a constant pitch of 5 seconds or more (Fig. 42). In case pitch is not constant, perform section 4-2. Tracking Fire Adjustment and section 4-4. No.7 Guide Adjustment.
- Set the CUE mode. Confirm that waveform paks still maintain a constant pitch of 5 seconds or more (Fig. 4-2).
   Otherwise, perform section 4-2 Tracking Fine Adjustment.




Fig. 42

#### 4-6. CHECK AFTER ADJUSTMENT

#### 4-6-1, TRACKING CHECK

- 1) Confirm that the amplitude of RF waveform is reduced to approx. 3/4 when the track shift mode is set (Fig. 43).
- 2) Then, confirm that the minimum amplitude value (EMIN) is 65 % of the maximum value (EMAX) or larger (Fig. 44).
- Confirm that no large fluctuations occur on the waveform (Fig. 45).




Fig. 43




Fig. 44




Fig. 45

#### 4-6-2. RISING CHECK (Fig. 46)

- 1) Play back the alignment tape for tracking adjustment.
- 2) Cancel the track shift mode.
- 3) Eject the tape, then load it again.
- 4) Set the playback mode and confirm that the RF wave form rises flat within 2 seconds. Also confirm that the tape is not bent around the pinch roller.
- 5) CUE/REV and FF/REW the tape, then play it back and confirm that the RF waveform rises flat within 2 seconds, Also confirm that the tape is not bent around the pinch roller.
- 6) Repeat steps 3) to 5) once more.




Fig. 46

#### 4-6-3. TAPE PATH CHECK (Fig. 47)

- Play back a thin tape like the P6-120MP (NTSC) or P5-90MP (PAL), etc. and confirm that no tape rising occurs, and that curling is less than 0.3mm, at the lower flange of the No. 2 guide, the upper flange of the No.3 guide, the upper flange of the No.6 guide and the No.7 guide upper and lower flanges.
- 2) Confirm that no tape rising occurs and that curling is less than 0.3mm at the flange of all guide when pressing the FF button in the playback mode to set the CUE mode, or the REW button to set the REV mode.




Fig. 47

# 8 mm Video MECHANICAL ADJUSTMENT MANUAL $\mathrm{IV}$

# A MECHANISM

# Video 8

### **SUPPLIMENT-2**

#### **Connection of Mode Selector IV Conversion Connector**

In use of Mode selector IV conversion connector(J-6082-167-A), there are two different connecting methods depending on the model connected:

#### 1. CCD-FX series

With the SL board mounted on mechanical deck, connect 30-pin(or 32-pin) connector to 30-pin(or 32-pin) Mode selector IV conversion connector.


CCD-FX300 series, FX400 series. FX500 series

→ 30-pin connector (FP425 or FP600)

CCD-FX700 series → 32-pin connector (FP477)

#### 2. Models other than above


Connect the extension cord (J-6082-197-A) to loading motor 4-pin connector and extension cord (J-6082-198-A) to mode switch 6-pin connector in mechanical deck, then connect the other end of cord to 4-pin and 6-pin connectors of Mode selector IV conversion connector respectively, as shown below.



#### *(CORRECTION)*

P10. 2-4 Service jigs list		Incorrect	Correct	
	J-15	FWD B.T adjusting driver	J-6082- <u>182</u> -A →	J-6082- <u>187</u> -A

### **MECHANISM CHASSIS ASSEMBLY (2)**



Sony Corporation
Personal Video Group

English 93E18163-1 Printed in Japan ©1993.5 Published by CV Quality Engineering DIV.

### 8mm Video MECHANICAL ADJUSTMENT MANUAL ${ m IV}$